

TID No. 7030

TO: Mr R Stubbington LAS IPT

DATE: 21st July 2008

TASK: 36046

**CERTIFICATE OF CONFORMANCE
FOR****CARRIER MAINTENANCE FULL TRACKED FV434 MK 1 & 1/1
(BOWMAN)**

PUBLICATION NUMBER: 2350-T-252-201
TITLE: Operating Information
AMENDMENT/STATUS: 2
CHAPTER(S): Various

It is certified that the AESP listed above, presented as a Portable Document Format (PDF) master on Compact Disk (CD) is approved for issue in that:

- a) It incorporates all necessary Safety Precautions and Warnings.
- b) It incorporates all agreed comments and amendments requested by the MoD and BAE.
- c)
- d)

Signed.....Date.....

For BAE Systems Land Systems

Note:

This certificate is to be signed by the Design Engineer or a nominated authorised representative.

TID No. 7111

TO: Mr R Stubbington LAS IPT

DATE: 12th August 2008

TASK: 36034 & 36041

CERTIFICATE OF CONFORMANCE**FOR****CARRIER PERSONNEL FULL TRACKED FV434 MK 1 & MK
1/1 (BOWMAN)**

PUBLICATION NUMBER: 2350-T-252

TITLE: All Categories

AMENDMENT/STATUS: Various

CHAPTER(S): Various

It is certified that the AESP listed above, presented as a Portable Document Format (PDF) master on Compact Disk (CD) is approved for issue in that:

(Add applicable wording)

- a) It incorporates all necessary Safety Precautions and Warnings.
- b) It incorporates all agreed comments and amendments requested by the MoD and BAE.
- c)
- d)

Signed Yc ShortDate 12th August 2008

For BAE Systems Land Systems

Note:

This certificate is to be signed by the Design Engineer or a nominated authorised representative.



029487



ANZAS
74 NOV 2005
LIBRARY INFO
SVC

CONDITIONS OF RELEASE

- 1 This information is released by the UK Government for defence purposes only.
- 2 This information must be afforded the same degree of protection as that afforded to information of an equivalent security marking originated by the recipient Government or as required by the recipient Government's security regulations.
- 3 This information may be disclosed only within the Defence Department of the recipient Government, except as otherwise authorized by the Ministry of Defence (Army).
- 4 This information may be subject to privately owned rights.

CARRIER MAINTENANCE FULL TRACKED FV434 MK 1 AND 1/1 (BOWMAN)

OPERATING INFORMATION

THIS DOCUMENT IS THE PROPERTY OF HER BRITANNIC MAJESTY'S GOVERNMENT, and is issued for the information of such persons only as need to know its contents in the course of their official duties. Any person finding this document should hand it into a British forces unit or to a police station for its safe return to the MINISTRY OF DEFENCE, (DSy (Pol)), MAIN BUILDING, WHITEHALL, LONDON, SW1A 2HB, with particulars of how and where found. THE UNAUTHORIZED RETENTION OR DESTRUCTION OF THIS DOCUMENT MAY BE AN OFFENCE UNDER THE OFFICIAL SECRETS ACTS OF 1911-89. (When released to persons outside Government service, this document is issued on a personal basis and the recipient to whom it may be entrusted in confidence, within the provisions of the Official Secrets Acts 1911-89, is personally responsible for its safe custody and for seeing that its contents are disclosed only to authorized persons.)

BY COMMAND OF THE DEFENCE COUNCIL

Ministry of Defence
Issued by

DEFENCE LOGISTICS ORGANISATION

AMENDMENT RECORD

Amdt No.	Incorporated By (Signature)	Date
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		
23		
24		
25		
26		
27		
28		
29		
30		
31		

Amdt No.	Incorporated By (Signature)	Date
32		
33		
34		
35		
36		
37		
38		
39		
40		
41		
42		
43		
44		
45		
46		
47		
48		
49		
50		
51		
52		
53		
54		
55		
56		
57		
58		
59		
60		
61		
62		

CONTENTS

PRELIMINARY MATERIAL

	Page
Front cover (title page).....	(i)/(ii)
Amendment record	(iii)/(iv)
CONTENTS (this list).....	(v)
PREFACE	(vi)
Introduction	(vi)
Related and Associated Publications	(vi)
Related Publications	(vi)
Associated Publications.....	(viii)
Abbreviations	(viii)
Warnings	(viii)
Cautions	(xiii)
Comment on AESP.....	Final leaf

OPERATING INFORMATION

Chap

- 1-0 General – List of Chapters
- 2-0 Vehicle Systems – List of Chapters
- 3 Crane and Hydraulic Lockout System
- 4 Destruction of Equipment

PREFACE

Sponsor: LASS IPT DLO Andover
File ref: 13072
Publication Agency:
Project No:

INTRODUCTION

1 Service users should forward any comments concerning this Publication through the channels prescribed in AESP 0100-P-011-013. An AESP Form 10 is provided at the end of this document; it should be photocopied and used for forwarding comments on this AESP.

2 AESPs are issued under Defence Council authority and where AESPs specify action to be taken, the AESP will of itself be sufficient authority for such action and also for the demanding of the necessary stores, subject to the provision of Para 3 below.

3 The subject matter of this Publication may be affected by Defence Council Instructions (DCIs), Standard Operating Procedures (SOPs) or by Local Regulations. When any such Instruction, Order or regulation contradicts any portion of this Publication it is to be taken as the overriding authority.

RELATED AND ASSOCIATED PUBLICATIONS**Related Publications**

4 The Octad for the subject equipment consists of the Publications shown. All references are prefixed with the first eight digits of this Publication. The availability of the publications can be checked by reference to the relevant Group Index (see AESP 0100-A-001-013).

5 This publication has been produced in both hard copy and microfiche formats. Each page therefore carries a page number and a frame number.

6 AESP 2350-T-250-601 Maintenance Schedule also contains references to all oils and greases used within those schedules.

Category/Sub-category		Information level				
		1 User/ Operator	2 Unit Maintenance	3 Field Maintenance	4 Base Maintenance	
1	0	Purpose and Planning Information	101	101	101	101
	1	Equipment Support Policy Directives	*	*	*	*
2	0	Operating Information	201	201	201	201
	1	Aid Memoire	*	*	*	*
	2	Training Aids	221	*	*	*
3		Technical Description	201	302	302	302
4	1	Installation Instructions	*	*	*	*
	2	Preparation for Special Environments	*	*	*	*
5	1	Failure Diagnosis	201	522	522	522
	2	Maintenance Instructions	201	522	523	524
	3	Inspection Standards	*	532	533	534
	4	Calibration Standards	*	*	*	*
6		Maintenance Schedules	*	*	*	*
7	1	Illustrated Parts Catalogues	711	711	711	711
	2	Commercial Parts Lists	*	*	*	*
	3	Complete Equipment Schedule, Production	*	*	*	*
	4	Complete Equipment Schedule, Service Edition (Simple Equipment)	741	741	741	741
	5	Complete Equipment Schedule, Service Edition (Complex Equipment)	*	*	*	*
8	1	Modification Instructions	811	811	811	811
	2	General Instructions, Special Technical Instructions and Servicing Instructions	821	821	821	821
	3	Service Engineered Modification Instructions (RAF only)	*	*	*	*

* Categories/Sub-categories not published

Associated Publications

<u>Reference</u>	<u>Title</u>
AESP 0200-A-100	Equipment Care Inspection and Mandatory Equipment Inspection
AESP 0200-A-190	Engineering Hygiene in the Field
AESP 1015-C-100	Equipment 81 mm Mortar
AESP 2300-A-201	Introduction to A, B and C vehicle hydraulic systems
AESP 2350-T-250	Carrier, Full Tracked FV430
AESP 2350-T-251	Carrier, Personnel, Full Tracked FV432
AESP 2350-T-254-741	Complete equipment schedule (FV434)
AESP 5680-C-100	Pipe Fascine, Mini
AESP 5800-H-201-201	Operating Information C3I installation in Carrier Tracked AFV432
AESP 5800-H-204-741	C.E.S. Command control comms and info system (CCCI) in FV434
AESP 6140-A-100-013	Secondary batteries lead-acid
AESP 6920-D-100-101	Direct fire weapon effect simulator family (DFWES)
AESP 6920-D-102-201	Target weapon effects simulator (TAGWES)
AESP 6920-D-210-211	TAGWES on fighting vehicle FV432 and fighting vehicle FV434
Army Code 45268	IKEE CLANSMAN Basic Harness for FV434
Army Code 45317	MODIFICATION KIT, Electronic Equipment, RadioStation UK/VRC353 for FV434
Army Code 63723	Health and Safety in Management in ESO/REME
Army Code 64193	Warning card for Steering and Braking
Army Code 71276	All Arms Standing Orders for the Safety of Crews of AFV's
Army Code 71576	Unit Equipment Care Guide
EMER Comms Inst H225	Command Control Communications and Information (C3I) Installation in Carrier, Maintenance, Full Tracked FV434, Technical Handbook – installation Instructions)
IETP (TBA)	Bowman radio publications

ABBREVIATIONS

5 Throughout this Publication any reference to right or left is as seen from the rear of the vehicle looking forward, unless otherwise stated. Where non-standard abbreviations are used the full meaning is written out in full the first time the subject is mentioned in the text, followed by the abbreviation in brackets.

WARNINGS

- (1) **PERSONNEL SAFETY. IN THE EVENT OF A FIRE ENSURE ALL PERSONNEL HAVE BEEN EVACUATED FROM THE VEHICLE AND THAT ALL NON-ESSENTIAL PERSONNEL HAVE BEEN EVACUATED TO A SAFE AREA.**
- (2) **ASPHYXIATION HAZARD. THE VAPOURS OF ALL FIRE EXTINGUISHERS DISPLACE AIR AND CAN CAUSE ASPHYXIA IN CONFINED SPACES. OPEN ALL HATCHES AND ALLOW TIME FOR FUMES TO DISPERSE BEFORE PERSONNEL RE-ENTER THE VEHICLE.**
- (3) **PERSONNEL SAFETY. IN THE EVENT OF A FIRE ENSURE ALL PERSONNEL HAVE BEEN EVACUATED FROM THE VEHICLE AND THAT ALL NON-ESSENTIAL PERSONNEL HAVE BEEN EVACUATED TO A SAFE AREA.**
- (4) **ASPHYXIATION HAZARD. THIS EQUIPMENT CONTAINS A HECTOFLUOROPROPANE (FM 200) FIRE SUPPRESSED SYSTEM. IF FM 200 VAPOUR IS BREATHED, IT CAN CAUSE SUFFOCATION. ONLY TRAINED PERSONNEL UNDER SUPERVISION ARE ALLOWED TO WORK ON THE SYSTEM. ANYONE WHO HAS BREATHED FM 200 VAPOUR IS TO RECEIVE MEDICAL ATTENTION.**

(5) **HEAVY WEIGHT.** THE STEERING UNIT ACCESS COVER IS EXTREMELY HEAVY AND LIFTING OPEN THE ACCESS COVER SHOULD BE CARRIED OUT BY TWO MEN. DUE CONSIDERATION SHOULD BE GIVEN TO THE REGULATIONS GOVERNING THE LIFTING OF HEAVY WEIGHTS.

(6) **PERSONNEL DANGER.** FATAL OR SERIOUS INJURY CAN OCCUR IF A SMOKE GRENADE DISCHARGES DURING THE LOADING PROCEDURE. ENSURE THE SMOKE DISCHARGER SWITCH IS IN THE OFF POSITION AND THAT ALL NON-ESSENTIAL PERSONNEL ARE CLEAR OF THE AREA TO A DISTANCE OF 200 METRES.

(7) **FIRE HAZARD.** CARE MUST BE TAKEN WHEN WORKING ON THE FUEL SYSTEM WITHIN THE POWER PACK COMPARTMENT. SPILT FUEL COULD COME INTO CONTACT WITH HOT EXHAUST SYSTEM, WHICH MAY CREATE A RISK OF FIRE.

(8) **PERSONAL INJURY.** CARE MUST BE TAKEN WHILST WORKING ON COMPONENTS AND ASSEMBLIES WITHIN THE POWER PACK COMPARTMENT. THERE MAY BE A RISK OF BURNS TO SKIN AND CLOTHING.

(9) **PERSONAL INJURY.** KEEP OUT OF THE LINE OF FIRE OF DISCHARGER BARRELS WHEN LOADING OR UNLOADING SMOKE GRENADES.

(10) **RADIO TRANSMISSION.** RADIO TRANSMISSION, DURING THE LOADING PROCEDURE, CAN CAUSE SMOKE GRENADES TO DISCHARGE. ENSURE NO TRANSMISSION TAKES PLACE DURING THE LOADING PROCEDURE.

(11) **PERSONNEL DANGER.** FATAL OR SERIOUS INJURY CAN OCCUR IF A SMOKE GRENADE DISCHARGES DURING THE UNLOADING PROCEDURE. ENSURE THE ARMING SWITCH IS IN THE OFF POSITION AND THAT ALL NON-ESSENTIAL PERSONNEL ARE CLEAR OF THE AREA TO A DISTANCE OF 200 METRES.

(12) **SAFETY HAZARD.** RADIO TRANSMISSION, DURING THE UNLOADING PROCEDURE, CAN CAUSE SMOKE GRENADES TO DISCHARGE. ENSURE NO TRANSMISSION TAKES PLACE DURING THE UNLOADING PROCEDURE.

(13) **PERSONAL INJURY.** KEEP OUT OF THE LINE OF FIRE OF DISCHARGER BARRELS WHEN LOADING OR UNLOADING SMOKE GRENADES.

(14) **PERSONAL INJURY.** THE NO SMOKING OR NAKED LIGHT REGULATIONS MUST BE FOLLOWED WHENEVER FUEL IS BEING TRANSFERRED OR WHEN ANY PART OF THE FUEL SYSTEM IS OPEN.

(15) **FIRE HAZARD.** DO NOT USE PLASTIC CONTAINERS FOR FILLING PURPOSES, AS STATIC ELECTRICITY MAY BE PRESENT AND CAUSE IGNITING SPARKS.

(16) **ENVIRONMENTAL HAZARD.** DO NOT DRAIN THE FLUID CONTENTS OF THE HULL ONTO THE GROUND. SUITABLE CONTAINERS SHOULD BE USED TO COLLECT THE DRAINED FLUIDS

(17) **VEHICLE MOVEMENT.** THE DRIVER SHOULD NOT LEAVE THE VEHICLE WHEN THE ENGINE IS RUNNING UNLESS THEIR OWN SAFETY IS ENDANGERED.

(18) **PERSONAL INJURY.** DO NOT REMOVE THE COOLANT FILLER CAP WHILE THE ENGINE IS RUNNING. ALWAYS WAIT UNTIL THE TEMPERATURE IS BELOW 93 deg C (200 deg F) BEFORE REMOVING THE COOLANT FILLER CAP OR SEVERE SCALDING MAY RESULT.

(19) **TOXIC HAZARD.** ANTI-FREEZE IS BOTH TOXIC AND HAZARDOUS. MINIMUM PRECAUTION AFTER USE IS TO WASH THE AFFECTED SKIN AREAS WITH SOAP AND WATER.

- (20) SAFETY HAZARD. PERSONNEL INSPECTING TRACKS MUST REMAIN IN SIGHT OF THE COMMANDER. THEY ARE NOT TO STAND BEHIND THE VEHICLE WHILST IT IS IN MOTION. THEY ARE TO RETAIN VISUAL CONTACT WITH THE COMMANDER. THEY ARE NOT TO MAKE PHYSICAL CONTACT WITH ANY PART OF THE TRACK AND RUNNING GEAR WHILST THE VEHICLE IS IN MOTION.
- (21) SAFETY HAZARD. THE COMMANDER MUST ALWAYS REMAIN IN SIGHT OF THE DRIVER AND MAINTAIN VISUAL CONTACT WITH PERSONNEL INSPECTING THE TRACKS. SHOULD ANY OF THE PERSONNEL DISAPPEAR FROM VIEW OR NOT RESPOND TO HIS COMMANDS HE IS TO IMMEDIATELY INSTRUCT THE DRIVER TO HALT THE VEHICLE.
- (22) SAFETY HAZARD. THE DRIVER MUST HALT THE VEHICLE IF THE COMMANDER GOES OUT OF HIS SIGHT.
- (23) SAFETY HAZARD. IT IS NOT SAFE PRACTICE TO HAVE BOTH TRACKS REMOVED AT THE SAME TIME, AS NO VEHICLE BRAKING IS AVAILABLE. IF TWO TRACK REMOVAL IS UNAVOIDABLE SECURE THE VEHICLE BY CHOCKING THE ROAD WHEELS BEFORE SPLITTING THE SECOND TRACK.
- (24) SAFETY HAZARD. BEFORE PERSONNEL ARE ALLOWED UNDER THE VEHICLE, THE PARKING BRAKE MUST BE FULLY APPLIED, THE ENGINE STOPPED AND THE VEHICLE SECURED TO PREVENT MOVEMENT.
- (23) PERSONNEL HAZARD. THE VOLTAGES USED ON SOME OF THE EQUIPMENT ON THE VEHICLE, EG RADIOS, CAN BE LETHAL. DO NOT TAMPER WITH THESE EQUIPMENTS OR ATTEMPT ANY REPAIR OR ADJUSTMENT WITH THE BATTERY SWITCHES ON.
- (25) PERSONAL INJURY. THE ALTERNATORS GET EXTREMELY HOT WHEN RUNNING.
- (26) FIRE HAZARD. THE GASES RELEASED FROM THE BATTERY ARE HIGHLY INFLAMMABLE; THEREFORE, ELECTRICAL CONNECTIONS MUST BE MAINTAINED CLEAN AND TIGHT TO PREVENT IGNITION OF GASES. BEFORE REMOVING OR REPLACING CONNECTORS, PUT THE APPROPRIATE BATTERY SWITCH TO OFF AND ENSURE THAT THE VENT TUBES ARE FITTED TO CELL COVERS. DO NOT ATTEMPT TO REMOVE OR REPLACE THE POSITIVE, WITH THE NEGATIVE (EARTH) CONNECTED. FRESHLY CHARGED BATTERIES MUST NOT BE INSTALLED UNTIL ALL GASSING HAS CEASED. A NAKED LIGHT MUST NEVER BE USED WHEN EXAMINING A BATTERY.
- (27) EQUIPMENT DAMAGE. CONNECTION AND DISCONNECTION OF THE HARNESS MUST BE MADE AT THE BOILING VESSEL BY MEANS OF THE PUSH-ON/PULL-OFF CONNECTOR.
- (28) PERSONAL INJURY. PETROL OR OIL DERIVATIVES MUST NOT BE USED UNDER ANY CIRCUMSTANCES. THEY CAUSE SILICONE SEALS TO SWELL AND SEALS THAT HAVE SWOLLEN ARE TOXIC. ANY SEAL THAT HAS BECOME CONTAMINATED MUST BE CHANGED BEFORE THE VESSEL IS AGAIN USED.
- (29) ROAD SAFETY HAZARD. DEPRESSING THE ACCELERATOR FULLY TOO RAPIDLY CAN CAUSE A DOWN CHANGE AND RELEASING IT QUICKLY, AN UP CHANGE. THE CONTINUAL EMPLOYMENT OF THIS TYPE OF DRIVING AND CAN BE DANGEROUS WHEN DRIVING IN TRAFFIC.
- (30) PERSONAL INJURY. FRESHLY CHARGED BATTERIES MUST NOT BE INSTALLED UNTIL ALL GASSING HAS CEASED.

(31) **RADIOACTIVE GAS.** THE VEHICLE LEVEL INDICATORS CONTAIN TRILUX LAMPS. WHEN A LAMP IS BROKEN A SMALL QUANTITY OF RADIOACTIVE TRITIUM GAS IS RELEASED. IF A LAMP IS BROKEN, VACATE THE VEHICLE IMMEDIATELY. IN CONFINED SPACES, DOORS AND WINDOWS SHOULD BE OPENED. ALLOW 30 MINUTES FOR THE TRITIUM GAS TO DISPERSE. DO NOT HANDLE BROKEN LAMP PARTS. ENSURE NO ONE BREATHES IN CONTAMINATED AIR.

(32) **PERSONNEL HAZARD.** FIRING ARTILLERY AT RANGES OF 500 METRES OR LESS AND FIRING RIFLE GRENADES OR ANTI-TANK ROCKETS SHOULD BE FROM COVER

(33) **PERSONNEL HAZARD.** WHERE ROOF MOUNTED EQUIPMENT PREVENTS THE RIGHT HAND MORTAR HATCH BEING OPENED, A RESTRICTION OF A MAXIMUM OF 4 PERSONNEL CAN BE TRANSPORTED IN THE REAR OF THE VEHICLE.

(34) **PERSONAL INJURY.** FRESHLY CHARGED BATTERIES MUST NOT BE INSTALLED UNTIL ALL GASSING HAS CEASED.

(35) **EQUIPMENT DAMAGE.** IF FOR ANY REASON THE WHEEL NUTS HAVE BEEN SLACKENED AND RE-TIGHTENED, THEY MUST BE CHECKED FOR TIGHTNESS DAILY FOR THE NEXT THREE DAYS THAT THE VEHICLE IS OPERATED. ONE MAN USING THE SPANNER SUPPLIED FOR THIS PURPOSE MUST TIGHTEN THE WHEEL NUTS. PIPES, BARS ETC MUST NOT BE USED TO INCREASE THE LEVERAGE, AS THE TORQUE MUST NOT EXCEED 244 NM (180 LB/FT).

(36) **PERSONNEL HAZARD.** THE VOLTAGES USED ON SOME OF THE EQUIPMENT ON THE VEHICLE, EG RADIOS, CAN BE LETHAL. DO NOT TAMPER WITH THESE EQUIPMENTS OR ATTEMPT ANY REPAIR OR ADJUSTMENT WITH THE BATTERY SWITCHES ON.

(37) **LETHAL VOLTAGE.** WHEN DISCONNECTING BATTERIES, REMOVE ALL THE TERMINALS FROM THE EARTH (NEGATIVE) (-) TERMINAL POSTS BEFORE REMOVING THE SUPPLY (POSITIVE) (+) TERMINALS. REPLACE IN THE REVERSE ORDER (POSITIVE TERMINALS FIRST).

(38) **LETHAL VOLTAGE.** BEFORE REMOVING OR REPLACING BATTERY CONNECTION, ENSURE THAT THE ENGINE IS STOPPED. SET THE BATTERY SWITCH, LOCATED ON THE DISTRIBUTION PANEL AND RADIO DISTRIBUTION BOX, TO OFF.

(38) **HEAVY WEIGHT.** EACH BATTERY WEIGHS 38 KG (84 LB). DUE CONSIDERATION MUST BE GIVEN TO THE REGULATIONS GOVERNING THE LIFTING OF HEAVY WEIGHTS WHEN MOVING EQUIPMENT.

(39) **PERSONAL INJURY.** THE ACID IN THE CELLS IS HARMFUL AND MUST NOT BE ALLOWED TO CONTACT THE EYES, SKIN OR CLOTHING.

(40) **EQUIPMENT DAMAGE.** CONNECTION AND DISCONNECTION OF THE HARNESS MUST BE MADE AT THE BOILING VESSEL BY MEANS OF THE PUSH-ON/PULL-OFF CONNECTOR.

(41) **PERSONAL INJURY.** TO AVOID CANS PRESSURISING IT IS ESSENTIAL WHEN HEATING COMPO RATIONS UNDECANTED THAT THE TOPS OF THE CANS ARE PIERCED AND THAT THE TINS ARE NOT TO BE PLACED ONE ON TOP OF THE OTHER.

(42) **PERSONNEL INJURY.** DEEP FRYING MUST NOT BE ATTEMPTED. THE OIL/FAT COULD BOIL OVER AND A SERIOUS FIRE OR INJURY RESULT

(43) **PERSONNEL INJURY.** THE BASE OF THE WATER COMPARTMENT BECOMES RED HOT WHEN FRYING, DO NOT ATTEMPT TO COOL BY POURING WATER INTO THE COMPARTMENT. SERIOUS SCALDING MAY RESULT.

- (44) PERSONNEL INJURY. CARE MUST BE TAKEN WHEN REFILLING WITH WATER SOON AFTER FRYING. SERIOUS SCALDING MAY RESULT.
- (45) PERSONAL INJURY. PETROL OR OIL DERIVATIVES MUST NOT BE USED UNDER ANY CIRCUMSTANCES. THEY CAUSE SILICONE SEALS TO SWELL AND SEALS THAT HAVE SWOLLEN ARE TOXIC. ANY SEAL THAT HAS BECOME CONTAMINATED MUST BE CHANGED BEFORE THE VESSEL IS AGAIN USED.
- (46) DAMAGE TO EYESIGHT. THE INFRA RED (IR) DRIVING LIGHTS ARE FITTED WITH 100 WATT LAMPS. THESE LIGHTS ARE NO LONGER USED. NEVER LOOK AT THE IR LIGHT WHEN THE FILTER IS FITTED AND THE LIGHT IS SWITCHED ON AS SERIOUS AND PERMANENT DAMAGE TO THE EYE MAY RESULT.
- (47) ROAD SAFETY HAZARD. DEPRESSING THE ACCELERATOR FULLY TOO RAPIDLY CAN CAUSE A DOWN CHANGE AND RELEASING IT QUICKLY, AN UP CHANGE. THE CONTINUAL EMPLOYMENT OF THIS TYPE OF DRIVING AND CAN BE DANGEROUS WHEN DRIVING IN TRAFFIC.
- (48) PERSONNEL DANGER. WHEN THE SUBJECT VEHICLE IS LOADED, ITS LOAD MUST NOT EXCEED THAT DETAILED IN PARA 4.
- (49) PERSONNEL DANGER. THE LOADED SUBJECT VEHICLE IS NOT ALLOWED TO EXCEED 35 m/h (56 km/h).
- (50) PERSONNEL DANGER. THE LOADED SUBJECT VEHICLE MUST NOT CARRY THE AMMUNITION FOR MORE THAN 186 MILES (300 KILOMETRES).
- (51) RISK OF EXPLOSION. NO RADIOS ARE TO BE FITTED OR USED IN THE VEHICLE WHEN CARRYING 105mm AMMUNITION
- (52) PERSONNEL HAZARD. FIRING ARTILLERY AT RANGES OF 500 METRES OR LESS AND FIRING RIFLE GRENADES OR ANTI-TANK ROCKETS SHOULD BE FROM COVER.
- (53) PERSONNEL HAZARD. ENSURE THAT ALL LOCAL STANDING OPERATING PROCEDURES AND ALL CURRENT HEALTH AND SAFETY REGULATIONS ARE COMPLIED WITH, WHEN CARRYING OUT ANY OF THE PROCEDURES DETAILED WITHIN THIS PUBLICATION.
- (54) PERSONAL INJURY. CARE MUST BE TAKEN WHEN DRAINING OILS FROM POWER PACK. THE ENGINE OIL COULD BE HOT AND A DANGER OF SCALDING IS POSSIBLE.
- (55) SAFETY HAZARD. BEFORE PERSONNEL ARE ALLOWED UNDERNEATH, THE VEHICLE IS TO BE PARKED ON FIRM LEVEL GROUND WITH THE PARKING/STEERING BRAKE FULLY APPLIED, THE ENGINE STOPPED, AND THE VEHICLE SECURED AGAINST ANY MOVEMENT.
- (56) PERSONAL INJURY. WHEN TOW STARTING WITH A CHAIN, WIRE ROPE OR KINETIC ENERGY ROPE, BOTH DRIVER AND COMMANDER'S HATCHES MUST BE CLOSED DOWN. ONCE THE VEHICLE HAS STARTED, THE VEHICLE IS TO BE HALTED IN A SAFE PLACE AND THE TOWING EQUIPMENT DISCONNECTED.
- (57) PERSONAL INJURY. WHEN TOWING WITH A CHAIN, WIRE ROPE OR KINETIC ENERGY ROPE, BOTH DRIVER AND COMMANDER'S HATCHES MUST BE CLOSED DOWN.

(58) **PERSONNEL HAZARD. BEFORE USING ANY HAZARDOUS SUBSTANCE OR MATERIAL, ENSURE THAT YOU KNOW THE SAFETY AND FIRST AID INSTRUCTIONS:**

(58.1) **ON THE LABEL OF THE CONTAINER IT WAS SUPPLIED IN.**

(58.2) **ON THE MATERIAL SAFETY DATA SHEET.**

(58.3) **IN THE LOCAL SAFETY ORDERS AND REGULATIONS.**

(59) **PROLONGED APPLICATION OF THE STEERING/BRAKE LEVERS COULD LEAD TO OVERHEATING OF THE STEERING/BRAKE SYSTEM, WHICH COULD CAUSE PREMATURE FAILURE.**

(60) **LETHAL VOLTAGES. DANGEROUS VOLTAGES EXIST IN THIS EQUIPMENT. WHEN CARRYING OUT WORK ON ANY BOWMAN RADIO EQUIPMENT DURING FAILURE DIAGNOSTICS, REFER TO EMER MGMT S-262**

(61) **FIRE HAZARD. BOWMAN EQUIPMENT MAY CAUSE FLAMMABLE SUBSTANCES TO IGNITE AT REFUELLING POINT. BOWMAN SYSTEM MUST BE TURNED TO STANDBY DURING REFUELLING**

(62) **PERSONNEL INJURY. BOWMAN ANTENNAS MAY TRANSMIT AT ANY TIME. SHOULD A CREW MEMBER GRAB AN ANTENNA WHILST TRANSMITTING THEY MAY SUFFER RF BURNS. UNDER NO CIRCUMSTANCES MUST AN ANTENNA BE TOUCHED WHEN FITTED TO THE VEHICLE UNLESS EQUIPMENT IS TURNED TO STANDBY.**

(63) **PERSONNEL INJURY. CARE MUST BE TAKEN WHILST MOVING THE VEHICLE WITH THE ANTENNAS FITTED. TOUCHING OF OVERHEAD CABLES MAY INDUCE HIGH VOLTAGES INTO THE VEHICLE CAUSING POSSIBLE ELECTROCUTION OF CREW MEMBERS.**

(64) **PERSONNEL INJURY. WHEN CARRYING OUT ANY TYPE WORK ON THE FV432 (BOWMAN) VEHICLE ATTENTION MUST BE MADE TO THE VARIOUS SAFETY NOTICES WHICH ARE POSITIONED THROUGHOUT THE VEHICLE.**

(65) **PERSONAL INJURY. ALL USERS AND MAINTAINERS MUST PAY ATTENTION TO THE BOWMAN SAFETY NOTICES AS ISSUED BY BOWMAN LAND DIGITIZATION (BLD) TO UNITS.**

CAUTIONS

(1) **SMOKE SOURCE. Before operating a fire extinguisher, consideration should be given to the possible cause of smoke. Allowance should be made for smoke from surplus oil, new engine paintwork, new insulation on the exhaust system and any other normal vapour.**

(2) **EQUIPMENT DAMAGE. The glass surfaces must be kept absolutely clean; they must not be touched directly with the fingers.**

(3) **EQUIPMENT DAMAGE. Always stand the filter on the brass plug head; never place it on its side, especially on steel or iron as this may cause loss of magnetism.**

(4) **EQUIPMENT DAMAGE. The engine must not be run with the automotive batteries disconnected.**

(5) **EQUIPMENT DAMAGE. Report immediately any signs of distortion or defects, which might impair the air seal. This is essential to prevent overheating power pack components.**

(7) **EQUIPMENT DAMAGE. To prevent damage to the engine fans, ensure the spent case bins are emptied at the specified intervals**

(8) **EQUIPMENT DAMAGE. Coolant may collect on top of the baffle plate so that at a glance a false impression of the level can be given.**

- (9) **EQUIPMENT DAMAGE.** When working in sub-zero conditions the batteries must be kept fully charged, otherwise the electrolyte may freeze. For further maintenance, reference should be made to the appropriate AESP listed under Associated Publications.
- (10) **EQUIPMENT DAMAGE.** Each pair of batteries must be of the same type, (i.e. both maintenance free)
- (11) **EQUIPMENT DAMAGE.** To avoid seriously damaging the electrical element, the inner container must be in place within the vessel when boiling less than 1.14 litres (2 pints) of water.
- (12) **EQUIPMENT DAMAGE.** Do not make coffee, soups etc in the water compartment as this heavy fluid will cause the drain tap to malfunction.
- (13) **EQUIPMENT DAMAGE.** The vessel must not be stood on a damp surface, especially if the vessel is hot, as moisture can be drawn up into the insulation material.
- (14) **EQUIPMENT DAMAGE.** If the engine is started with the distribution link box warning light illuminated, internal damage to the generating system will result.
- (15) **EQUIPMENT DAMAGE.** Running the engine for long periods with the engine/traverse gearbox dis-connector clutch out of engagement may damage the clutch.
- (16) **EQUIPMENT DAMAGE.** The engine must not be run with the automotive batteries disconnected.
- (17) **EQUIPMENT DAMAGE.** The 'towed dead' vehicle must be towed in as near a straight line as possible (minimum).
- (18) **EQUIPMENT DAMAGE.** When the engine of the 'towed' vehicle starts, stop both vehicles immediately and dis-connect the tow equipment.
- (19) **EQUIPMENT DAMAGE.** Serious damage can be caused to the gearbox if downshifts are made manually when the vehicle is travelling at speeds exceeding those given in table 2 below.

CHAPTER 1-0
GENERAL – LIST OF CHAPTERS
CONTENTS

Para

- 1 List of chapters

LIST OF CHAPTERS

- 1 This chapter is further sub-divided as follows:

Chap

- 1-1 Introduction and outline data
- 1-2 Evacuation of casualties
- 1-3 Stowage and tools

CHAPTER 1-1
INTRODUCTION AND OUTLINE DATA
CONTENTS

Para

1	Introduction
9	Power Pack
	Suspension and Tracks
10	Suspension
12	Tracks
	Transmission
13	Gearbox
14	Steering
	Electrical equipment
15	System
16	Batteries
17	Fuel system
18	Cooling system
	Hull and Controls
19	General
21	Hull
23	Controls
24	Data

Table

Page

1	Physical data	5
---	---------------------	---

Fig

Page

1	Three quarter front view of FV434 Mk1	2
2	Three quarter rear view of FV434 Mk 1	2
3	Overall dimensions	3

INTRODUCTION

NOTE

Throughout this handbook any reference to left or right, is as seen from the rear of the vehicle looking forward.

1 The vehicle is a Carrier Maintenance Full Tracked FV434 (Fig 1 and 2), designed to carry major assemblies or replacement power packs for AFV casualties and to provide workshop facilities and services. A crew of four is carried, a commander, driver and two vehicle mechanics.

2 The lifting device is a hydraulic crane, having a two piece hinged jib with a telescopic extension. Stowage is provided on the vehicle for special tools and equipment to facilitate replacement of the damaged assemblies.

3 The rear part of the hull forms the load carrying compartment.


4 The vehicle is powered by a K60 multi-fuel engine, which drives the tracks via a six-speed automatic gearbox and a controlled differential type steering unit.

5 Braking is achieved by using the steering unit brakes.

6 The vehicle is wired on the 24 volt negative earth system; it has two sets of batteries which are charged by the rectified output of two alternators.


7 Access to the interior of the closed down vehicle is via the crane operator's hatch, the other hatches being locked from inside the vehicle and operable only from the inside.

8 Torsion bar suspension is used. Hydraulic shock absorbers are fitted at the front and rear stations, which can be locked hydraulically when the crane is being used.




430/20154

Fig 1 Three quarter front view of Mk 1 vehicle



434/002a

Fig 2 Three quarter rear view of Mk 1 vehicle



430/30000

Fig 3 Overall dimensions

POWER PACK

9 The power pack fitted to Carrier, Maintenance, Full Tracked, (FV434) is similar to that fitted to the Carrier Personnel Full Tracked FV432 MK 2 & 2/1, except that to supply power for the hydraulically operated crane an additional power take-off for a hydraulic pump is fitted to an intermediate (idler) gear of the transfer gearbox.

SUSPENSION AND TRACKS

Suspension

10 The suspension of the Carrier, Maintenance (FV434) is similar to that fitted to the Carrier Personnel Full Tracked FV432 MK 2 & 2/1 except that hydraulic shock absorbers capable of being locked as solid struts are fitted to the front and rear stations, instead of friction type shock absorbers. The torsion bars, although similar to those fitted to FV432, require a different initial setting.

11 Field repairs to hydraulic shock absorbers/lock out struts are confined to assembly change and bleeding.

Tracks

12 Each track consists of 91 links when new, and these are rubber bushed with rubber-padded links and are connected by hexagonal pins. The condemnation limit of the tracks is 88 links with the hydraulic ram fully extended. A hydraulic track adjuster adjusts track tension. The adjusting movement is effected by a hydraulic ram. The ram is extended by pumping grease through a nipple in the head and retracted by unscrewing a relief screw, which is adjacent to the nipple. A lug welded to the rear of the stub axle extension contacts the adjuster bracket and acts as a limit stop when the full effective travel of the ram plunger has been reached.

TRANSMISSION

Gearbox

13 All transmission assemblies fitted to the Carrier, Maintenance, Full Tracked (FV434) are similar to those fitted to the Carrier Personnel Full Tracked FV432 MK 2 & 2/1. A PTO and hydraulic pump is fitted to the transfer gearbox as detailed in Para 9.

Steering

14 Steering is aided by the use of a controlled differential unit. The vehicle is steered by pulling back the steering levers, which apply the brakes in the steering unit. Pull back the right lever to turn right and the left lever to turn left.

ELECTRICAL EQUIPMENT

System

15 24 V negative earth system is used within the vehicle, with an ac generating system that is rectified for battery charging and general purposes.

Batteries

16 There are four batteries fitted within the vehicle, two connected in series for automotive purposes, and two connected in series for radio equipment.

Fuel system

17 Fuel is carried in a single tank located under the load compartment immediately behind the crew compartment bulkhead. The filler tube is on the right of the tank and extends upwards through the load compartment floor almost to the top of the bulkhead to which it is attached. It is closed by a hinged cover under which is the fuel cap.

COOLING SYSTEM

18 The cooling system is similar to that of the Carrier Personnel Full Tracked FV432 MK 2 & 2/1, detailed in AESP 2350-T-251-201.

HULL AND CONTROLS

General

19 The controls fitted to the Carrier, Maintenance, Full Tracked FV434, less those fitted for operating the crane and shock absorber lock out struts, are similar to those fitted to the Carrier Personnel Full Tracked FV432 MK 2 & 2/1, except that an additional hand throttle is fitted for remote control of the engine when the crane is being operated.

20 This hand throttle control consists of a quadrant mounted lever linked to the accelerator cross shaft. The connecting rods are fitted with adjustable fork ends. Access to all items is readily obtainable but removal of drivers seat is necessary to gain access to the fork end on the accelerator cross shaft.

Hull

21 The hull of the Carrier, Maintenance (FV434) is similar to the hull of FV432, except that the load carrying compartment of the Carrier Maintenance is constructed of mild steel sheet, welded the to armoured front and bottom sections of the vehicle.

22 Hull details relevant to the crane are detailed in Chap 2-2.

Controls

23 All controls, less those fitted for operating the crane and shock absorber/lock out strut assemblies are identical to those fitted to the Carrier Personnel Full Tracked FV432 MK 2 & 2/1.

DATA

24 Table 1 lists the physical data relevant to the Carrier Maintenance Full Tracked FV434 Mk 1.

TABLE 1 PHYSICAL DATA

Serial (1)	Item (2)	Detail (3)
1	Crew	Four, (driver, commander and two fitters)
2	Dimensions	Refer to Fig 3
3	Weights	
	3.1 Unladen (fully fuelled and with driver)	13,780 kg (30352 lb)
	3.2 Laden	15,057 kg (33166 lb)
	3.3 Pay load	2717 kg (5985 lb)
4	Bridge classification	19
5	Fuel	Multifuel – diesel, gas turbine.
6	Engine	K60 Mk 4F or Mk 6F, two stroke, multi-fuel, compression ignition. Opposed piston type
7	Gearbox	GM-Allison TX200-4A semi-automatic gearbox having six forward gears and one reverse, with a torque converter operating in 1st, 3rd, and reverse

(continued)

TABLE 1 PHYSICAL DATA (continued)

Serial (1)	Item (2)	Detail (3)
8	Governed speed	
	8.1 Maximum	3,750 rev/min
	8.2 Idle	780 to 800 Rev/min
9	Gears and speed	
	Gear	Speed
	9.1 1	8.9 km/h (5.56 mile/h)
	9.2 2	12.3 km/h (7.72 mile/h)
	9.3 3	17.5 km/h (10.93 mile/h)
	9.4 4	24.3 km/h (15.2 mile/h)
	9.5 5	33.8 km/h (21.16 mile/h)
	9.6 6	47.3 km/h (29.42 mile/h)
	Reverse	7.8 km/h (4.87 mile/h)
10	Performance	
	M	
11	Fuel consumption	
	1	
	1	
12		
13	Range of operation	
14	Fording depth	1.25 m
15	Maximum gradient	30 degrees
16	Maximum vertical obstacle	609 mm (2 ft)
17	Minimum turning circle	5.334 m (17 ft 6 in.)
18	Suspension	Torsion bar, five units on each side with axle arms in the trailing position. Track adjuster at rear
	Type	
	Wheels	609 mm (24 in.) diameter, rubber tyred. Two on each suspension unit and track adjuster
	Shock absorber	Hydraulic on front and rear stations. Lockable to afford stability when using crane.
19	Tracks	
	19.1 Links per track (new)	90
	19.2 Condemnation limit	88 (with hydraulic ram fully extended)
20	Track guide rollers	Two for each track
21	Steering	Lever operated controlled differential unit

(continued)

TABLE 1 PHYSICAL DATA (continued)

Serial (1)	Item (2)	Detail (3)	
22	Armament	Pintle mounting on cupola for commanders machine gun in ground role	
23	Smoke protection	Two forward facing multi-barrelled smoke dischargers	
24	Ammunition Machine gun Smoke discharger	Eight boxes of 200 rounds, belted for GPMG Six rounds (loaded in dischargers)	
25	Vision Driver Commander	Head out for opened up position. Single wide angled AFV No. 33 Mk1 periscope. Facilities for replacing with image intensified. periscope. 360 degree rotation cupola with three periscopes, both outer periscopes fixed. Centre AFV No. 32 Mk 1 periscope can be pivoted axially in vertical plane. (Periscope AFV No 32 Mk 1)	
26	Electrical equipment System Batteries Alternators Lamps	24V negative earth with AC generating system rectified for battery charging and general purposes Four, No. 4 Mk 3, 12V, maintenance free batteries, rated at 110amp/hour Two No. 1 Mk 1 alternators. Max. output 100amp/hours, regulated to 28.5V at 1,750 rev/min (alternator speed) Refer to Chap 2-6	
27	Capacities	Litres	Imperial
	27.2 Engine lub system	33	58 pints
	27.3 Gearbox (modified)	16.5	29 pints
	27.4 Engine governor	1.15	2 pints
	27.5 Coolant system	44.3	78 pints
	27.6 Hydraulic fan drive	22.2	39 pints
	27.7 Steering unit	26.7	47 pints
	27.8 Final drives (each)	4.3	7.5 pints
	27.9 Road and track adjuster wheels (each)	1.7	3 pints
28	Crane Type Drive	HIAB 61, hydraulic, 2 piece hinged jib with 3 position telescopic extension Gear type pump driven from PTO in transverse gearbox	
29	Load capacity	Radius	Load
	Main hook	2.261 m (7 ft 5 in.)	3048 kg (6720 lb)
		2.591 m (8 ft 6 in.)	2585 kg (5700 lb)
		2.896 m (9 ft 6 in.)	2392.6 kg (5270 lb)
	Extension hook	3.200 m (10 ft 6 in.)	1525 kg (3360 lb)
		3.962 m (13 ft 0 in.)	1247 kg (2750 lb)

CHAPTER 1-2
EVACUATION OF CASUALTIES

CONTENTS

Para

- Introduction
- 1 General (WARNING)
- 4 Medical aspects of rescue
- 8 Rescue priority
- 10 Action in an emergency
- Rescue drills
- 18 General
- 21 Access hatches
- 22 Escape hatch

Chart

Page

- | | | |
|---|-------------------------|---|
| 1 | Rescue priorities | 3 |
|---|-------------------------|---|

Fig

- | | | |
|---|---------------------------------|---|
| 1 | Escape hatch | 5 |
| 2 | Hull bottom plate | 6 |
| 3 | Cupola and driver's hatch | 7 |
| 4 | Crane operators hatch | 8 |

INTRODUCTION

General

WARNING

PERSONNEL INJURY. DUE TO THE DIFFERING VARIANTS OF THE FV 430 SERIES AND BOWMAN RADIO FITS THE EVACUATION DRILLS WILL CHANGE FROM VARIANT TO VARIANT. BEFORE USE, ADVICE FOR EVACUATION DRILLS SHOULD BE SOUGHT FROM THE U.E.M. (UNIT EQUIPMENT MANAGER)

- 1 The drills described in this chapter assume that the following conditions exist at the time of rescue:
 - 1.1 One member only of the AFV's crew is incapacitated.
 - 1.2 The rescue is carried out by the other members of the crew without outside assistance.
 - 1.3 The AFV is closed down at the start of the drill, with the hatches locked.
 - 1.4 Crewmen are wearing NBC protective clothing and crewman's helmets but no webbing equipment.
- 2 More serious incidents concerned with more than one incapacitated crewman per AFV will need outside assistance. However, the same rescue drills will still apply.
- 3 In the worst type of incident very prompt action to fight fire and/or recover an AFV will be needed before the rescue drills described can begin.

Medical aspects of rescue

4 The ability to perform prompt and effective first aid, particularly that aimed at the maintenance of breathing and control of bleeding is an essential requirement for all soldiers.

5 First aid, by definition, is the application of simple precautions pending the arrival of professional help. Remember that professional help may not be readily at hand. The man on the spot must therefore always act decisively, accepting any risks in making his decision.

6 The casualties' helmet must remain on throughout rescue operations and if possible the crew must support the casualties' head at all times.

7 The Action in an EMERGENCY listed in the following paragraphs show the main points to look for and the priority of action.

Rescue priority

8 Whilst, as a general rule, first aid is most efficiently applied outside an AFV there are important exceptions. There are also rare occasions when first aid hardly matters at all initially. The following table shows the decisions to be made at the start of the rescue, by the senior active crewman.

9 Check for consciousness:


9.1 A - Open the Airway.

9.2 B - Check for Breathing.

9.3 C - Check for Circulation (pulse).

9.4 D - Check for Disabilities i.e. unconscious, breaks, burns etc.

CHART 1 – RESCUE PRIORITIES



Action in an EMERGENCY

10 Are you or the casualty in danger?

11 Remove the danger. Move the casualty only if absolutely necessary.

12 Under active service conditions, or where there is immediate danger of fire, fumes or flood, priority must be given to restoring breathing and stemming bleeding, followed by the immediate evacuation of the casualty from the vehicle to a place of safety where medical attention can be provided. An injured man in a sitting position may quickly die under certain circumstances, and as a general rule he should be in the recovery position as soon as possible. While the casualty is in a sitting or upright position his head must, at all times, be supported and held up to ensure that he can breath freely.

13 Where there is no immediate danger from enemy action, fire, flood and fumes, priority must be given to administering first aid and sending for skilled medical personnel. Breathing should be restored, bleeding arrested and the casualty treated for shock. Only if the casualty is in physical danger, as from a burning vehicle, should he be evacuated before medical attention arrives.

14 More serious incidents concerned with more than one incapacitated crewman per vehicle will need outside assistance. However, the same rescue drills will still apply.

15 In the worst type of incidents very prompt action to fight fire and/or recover a vehicle will be needed before the rescue drills described can begin.

16 The following paragraphs contain all the drills necessary for the rescue of any incapacitated member of the crew.

17 Each drill must be carried out in conjunction with Paras 4 to 7 "Medical aspects of rescue".

RESCUE DRILLS

General

18 The drills in this chapter assume that the following conditions exist at the time of rescue:

18.1 One member of the crew is incapacitated.

18.2 The rescue, is carried out by the other members of the crew, without outside assistance.

18.3 The vehicle is closed down at the start of the drill, with the hatches locked from the inside.

18.4 Crewmen are wearing NBC protective clothing and crewman's helmets but no webbing equipment.

19 Each drill must be carried out in conjunction with para 4 to 7 "Medical Aspects of Rescue".

20 In the worst type of incidents very prompt action to fight fire and/or recover a vehicle will be needed before the rescue drills described can begin.

Access hatches

21 When access is required through the hatches they are opened as follows:

21.1 The driver's hatch is accessed from the top of the vehicle or through the commanders or personnel compartment. The hatch is opened using a rotatable catch (Fig 3 (2)). A spring-loaded catch retains the door in the open position.

21.2 The commander's cupola is accessed through the personnel compartment and the hinged door in the top of the cupola, and is opened by rotating two catches (Fig 3(1)). A stop bracket and spring catch retains the door in the open position.

21.3 The escape hatch (Fig 2(6)) is a small square hatch in the floor located underneath the commander's seat. This hatch is to enable escape through the floor if the vehicle overturns.

21.4 The crane operators hatch (Fig 4(2)) is located just behind the commander's hatch. A spring-loaded catch retains the door in the open position.

Escape hatch

22 An escape hatch (Fig 1) is provided in the hull bottom plate below the crew compartment as an alternative means of exit should the roof door be obstructed. The hatch cover (4) is secured to the hull bottom plate by a cruciform clamp (1). The hatch well is covered by a removable floor plate.


23 To open the hatch grasp the floor plate catch handles and rotate them a quarter turn, then lift the floor plate clear. Unscrew the clamp by turning the handle (3) anti-clockwise until the cruciform clamp can be turned and the hatch cover removed.

24 When replacing the hatch cover, check that the seals and sealing faces are clean, in good order, then position the cover over the hatchway, and adjust the clamp in order that the pads are centrally disposed at each side, tighten the clamp by turning the handle clockwise until a water tight seal is ensured.

NOTE

The clamp handle must be clear of the angle plates welded to the underside of the floor plate.


25 To replace the floor plate, engage the left edge of the plate under the retaining lip on the edge of the hatch well, lower the plate, and engage the catches. Ensure that the catch handles lie in the recesses provided.



434/116

- | | | | |
|---|----------------------|---|--------------------|
| 1 | Cruciform clamp | 3 | Locking handle |
| 2 | Power pack partition | 4 | Escape hatch cover |


Fig 1 Escape hatch



430/2006

- | | | | |
|---|--------------------------------|----|--|
| 1 | Stowage locker drain plug | 7 | Gearbox drain access plug |
| 2 | Locker plug | 8 | Drivers compartment drain plug |
| 3 | Load compartment drain plug | 9 | Steering unit drain access plate |
| 4 | Stowage compartment drain plug | 10 | Engine oil drain access plug |
| 5 | Fuel drain valve access plate | 11 | Steering unit oil tank and coolant drain access plug |
| 6 | Escape hatch | | |

Fig 2 Hull bottom plate




430/20099

1 Cupola door catches

2 Locking catch

Fig 3 Cupola and driver's hatch



434/005a

1 Commanders hatch

2 Crane operators hatch

Fig 4 Crane operators hatch

CHAPTER 1-3
STOWAGE AND TOOLS
CONTENTS

Para

- 1 Introduction
- 2 External stowage
Internal Stowage
- 3 Drivers and commanders SA 80 stowage
- 4 Tools


Fig	Page
1 External stowage areas.....	1
2 SA 80 Rifle Stowage.....	2

INTRODUCTION

1 This chapter details the location of stowage on the Carrier Maintenance Full Tracked FV434, which are not classed as fittings.

EXTERNAL STOWAGE

2 The external stowage areas are shown in Fig 1:




430/20007

- | | |
|------------------------------------|----------------------------|
| 1 Bin rear roof compartment LH | 5 Stowage lockers |
| 2 Bin rear roof compartment Centre | 6 Rear stowage compartment |
| 3 Bin RH roof compartment | 7 Stowage brackets |
| 4 Bin rear roof compartment | |

Fig 1 External stowage areas

INTERNAL STOWAGE**Drivers and commanders SA 80 stowage**

3 Fig 2 details the location of the stowage brackets for the drivers and commanders SA80 stowage and the stowage brackets for the boiling vessel (B.V.)



430/20155

1 SA80 Stowage bracket

2 Boiling vessel bracket

Fig 2 SA 80 Rifle Stowage

TOOLS

4 The tools associated with this vehicle are detailed in AESP 2350-T-250-741.

CHAPTER 2-0
VEHICLE SYSTEMS – LIST OF CHAPTERS
CONTENTS

Para

- 1 List of chapters

LIST OF CHAPTERS

- 1 This chapter is further sub-divided as follows:

Chap

- 2-1 Fire fighting system
- 2-2 Hull and fittings
- 2-3 Powerpack
- 2-4 Final drive, suspension and tracks
- 2-5 Ventilation control system
- 2-6 Electrical system
- 2-7 Vehicle operation
- 2-8 Failure diagnosis

**CHAPTER 2-1
FIRE FIGHTING SYSTEMS**

CONTENTS

Para		
1	Fire fighting equipment	
6	Operation of a portable extinguisher BCF (WARNING)	
10	Operation of a portable extinguisher 2 kg dry powder (WARNING)	
11	Operation of the fixed fire extinguisher (WARNING)	
13	Fire alarm system	
17	Testing the circuit	
22	Action in the event of fire (WARNINGS)	
24	External fires, driver's and personnel compartment fires	
25	Power pack compartment fires	
	Maintenance	
27	Checking a portable fire extinguisher	
31	Servicing the fixed fire extinguisher system	
Fig		Page
1	Driver's compartment.....	2
2	Rear of vehicle.....	2
3	Front of vehicle.....	3
4	BCF type portable fire extinguisher.....	4
5	Portable 2 kg dry powder fire extinguisher	5
6	Fixed fire extinguisher cylinders.....	6
7	Fire extinguisher control cover flap R/H	7
8	Fire extinguisher control cover flap L/H	7
9	Distribution panel No. 6, Mk 1.....	9
10	Crew compartment left hand side.....	11/12

FIRE FIGHTING EQUIPMENT

1 Three internally fitted BCF and three externally mounted dry powder portable fire extinguishers and a fixed BCF system are provided to combat vehicle fires.

2 The portable fire extinguishers are suitable for combating all types of fire and operating instructions are marked on each extinguisher.

3 The portable extinguishers are located as follows:

3.1 BCF Type

3.1.1 One (Fig 1(3)) in the driver's compartment mounted on a bracket on the power pack compartment plate.

3.1.2 Two 2 kg portable BCF, (Fig 5), in the crew compartment, one mounted on the ventilation filter housing and the other on the power pack compartment rear plate above the fire warning light.


3.2 Dry Powder

3.2.1 One (Fig 2 (1)) on the vehicle rear plate mounted above the power tools socket.

3.2.2 Two (Fig 3 (1)) on the front sloping plate, one above each of the smoke dischargers.

4 Operating instructions are clearly marked on each extinguisher (see Figs 4 and 5).


5 The two fixed BCF cylinders (Fig 6) are provided to combat fires in the power pack compartment. They are mounted on a bracket on the rear plate of the power pack compartment.



432/20156

- | | | | |
|---|---|---|---------------------------|
| 1 | Fixed fire extinguisher remote controls | 3 | Fire extinguisher bracket |
| 2 | Fire warning light | | |


Fig 1 Driver's compartment



430/20008

- | | |
|---|---------------------------------------|
| 1 | Portable fire extinguisher in bracket |
|---|---------------------------------------|

Fig 2 Rear of vehicle



430/20157

1 Location of front portable fire extinguishers

Fig 3 Front of vehicle

Operation of a portable extinguisher BCF

WARNINGS

(1) **PERSONNEL SAFETY.** IN THE EVENT OF A FIRE ENSURE ALL PERSONNEL HAVE BEEN EVACUATED FROM THE VEHICLE AND THAT ALL NON-ESSENTIAL PERSONNEL HAVE BEEN EVACUATED TO A SAFE AREA.


(2) **ASPHYXIATION HAZARD.** THIS EQUIPMENT CONTAINS A HECTOFLUOROPROPANE (FM 200) FIRE SUPPRESSED SYSTEM. IF FM 200 VAPOUR IS BREATHED, IT CAN CAUSE SUFFOCATION. ONLY TRAINED PERSONNEL UNDER SUPERVISION ARE ALLOWED TO WORK ON THE SYSTEM. ANYONE WHO HAS BREATHED FM 200 VAPOUR IS TO RECEIVE MEDICAL ATTENTION.

(3) **ASPHYXIATION HAZARD.** THE VAPOURS OF ALL FIRE EXTINGUISHERS DISPLACE AIR AND CAN CAUSE ASPHYXIA IN CONFINED SPACES. OPEN ALL HATCHES AND ALLOW TIME FOR FUMES TO DISPERSE BEFORE PERSONNEL RE-ENTER THE VEHICLE.

CAUTION

SMOKE SOURCE. Before operating a fire extinguisher, consideration should be given to the possible cause of smoke. Allowance should be made for smoke from surplus oil, new engine paintwork, new insulation on the exhaust system and any other normal vapour.

- 6 Unclip and remove the extinguisher from its bracket; take up a suitable position as close to the fire as is safely, possible.
- 7 Discharge the extinguisher (as per operating instructions).
- 8 Direct the spray cone at the seat of the nearest flames first, sweeping from side to side, progressing the spray over the fire area but leaving no flame behind it.
- 9 During operation, the extinguisher must be held downward with a tilt of not more than 45 deg. The rate of discharge cannot be controlled; once the discharge starts, the extinguishers will empty completely. When discharged, the container should be discarded and a replacement obtained as soon as possible.



432/026

- | | | | |
|---|------------------------------|---|---------------------------------|
| 1 | Test indicator | 3 | Striker knob and test indicator |
| 2 | Discharge nozzle and striker | | |


Fig 4 BCF type portable fire extinguisher

Operation of portable extinguisher, 2 kg dry powder

WARNINGS

- (1) **PERSONNEL SAFETY. IN THE EVENT OF A FIRE, ENSURE ALL PERSONNEL HAVE BEEN EVACUATED FROM THE VEHICLE AND THAT ALL NON-ESSENTIAL PERSONNEL HAVE BEEN EVACUATED TO A SAFE AREA.**
 - (2) **ASPHYXIATION HAZARD. DRY POWDER EXTINGUISHERS ARE NON-TOXIC. HOWEVER, THIS TYPE OF EXTINGUISHER IS NOT TO BE USED IN A CONFINED SPACE UNLESS IN AN EXTREME EMERGENCY.**
 - (3) **ASPHYXIATION HAZARD. THE VAPOURS OF ALL FIRE EXTINGUISHERS DISPLACE AIR AND CAN CAUSE ASPHYXIA IN CONFINED SPACES. OPEN ALL HATCHES AND ALLOW TIME FOR FUMES TO DISPERSE BEFORE PERSONNEL RE-ENTER THE VEHICLE.**
- 10 To use the 2 kg dry powder portable fire extinguisher, proceed as follows:
 - 10.1 Hold the extinguisher (see Fig 5) upright.
 - 10.2 Remove the cap from the discharge nozzle (7), and remove the ring pull pin (1) from the handle assembly.
 - 10.3 From a position as near the fire as possible, direct the nozzle at the base of the nearest flames and squeeze the operating handle (2) to commence the discharge.

- 10.4 Release the operating handle to halt the discharge.
- 10.5 After use, check the gauge indication and replace the extinguisher if necessary.



432/103

- | | | | |
|---|------------------------|---|------------------------|
| 1 | Ring pull pin | 5 | Operating instructions |
| 2 | Operating handle | 6 | Cylinder |
| 3 | Indicator gauge | 7 | Discharge nozzle |
| 4 | Inspection record card | | |

Fig 5 Portable 2 kg dry powder fire extinguisher

NOTE

There could be three or more variants of portable fire extinguisher currently in service. Before using the vehicle the User should ensure that they determine the type of extinguisher fitted to the vehicle. They should make themselves familiar with the operating instructions, which are clearly marked on each fire extinguisher and read the appropriate local Standing Operating Procedures (SOP;s)

Operation of the fixed fire extinguisher

WARNINGS

(1) PERSONNEL SAFETY. IN THE EVENT OF A FIRE ENSURE ALL PERSONNEL HAVE BEEN EVACUATED FROM THE VEHICLE AND THAT ALL NON-ESSENTIAL PERSONNEL HAVE BEEN EVACUATED TO A SAFE AREA.

(2) ASPHYXIATION HAZARD. THIS EQUIPMENT CONTAINS A HECTOFLUOROPROPANE (FM 200) FIRE SUPPRESSED SYSTEM. IF FM 200 VAPOUR IS BREATHED, IT CAN CAUSE SUFFOCATION. ONLY TRAINED PERSONNEL UNDER SUPERVISION ARE ALLOWED TO WORK ON THE SYSTEM. ANYONE WHO HAS BREATHED FM 200 VAPOUR IS TO RECEIVE MEDICAL ATTENTION.

(3) ASPHYXIATION HAZARD. THE VAPOURS OF ALL FIRE EXTINGUISHERS DISPLACE AIR AND CAN CAUSE ASPHYXIA IN CONFINED SPACES. OPEN ALL HATCHES AND ALLOW TIME FOR FUMES TO DISPERSE BEFORE PERSONNEL RE-ENTER THE VEHICLE.

- 11 Switch off the engine and battery master switches.

12 An extinguisher control is operated as detailed below.


12.1 Driver's compartment. Turn one of the control handles (Fig 1(1)), located on the roof plate to the left of the hatch, a quarter turn anticlockwise and pull out sharply.

12.2 Personnel compartment. Pull the finger bar (Fig 6(5)) of one of the discharge heads. The finger bars are painted red.

12.3 Outside the vehicle. Turn one of the handles, located beneath the rubber flaps (Fig 7(1)) and Fig 8(1)) a quarter turn anticlockwise and pull sharply.

NOTE


The rate of discharge from a cylinder cannot be controlled. Once the seal has been broken, the cylinder will discharge completely. If the fire persists after one cylinder has been discharged, operate the control for the other cylinder. A replacement cylinder should be installed as soon as possible.



430/20158

- | | | | |
|---|--------------------------|---|----------------|
| 1 | Securing plate | 4 | Cylinders |
| 2 | Through bolt nuts | 5 | Finger bars |
| 3 | Pressure indicator gauge | 6 | Discharge head |


Fig 6 Fixed fire extinguisher cylinders



430/20159

- 1 Fixed fire extinguisher control cover flap

Fig 7 Fire extinguisher control cover flap R/H



434/011a

- 1 Fixed fire extinguisher control cover flap

Fig 8 Fire extinguisher control cover flap L/H

FIRE ALARM SYSTEM

13 The system is operated electrically and is designed to give visible and audible warnings if the system senses any overheating or fire in the power pack compartment. It is resetting and will not signal a warning if a short circuit occurs or if a fault develops in the power supply or control unit. It is, therefore, essential that the system be tested daily.

14 Incorporated in the circuit is a firewire sensing element loop, a control box with a circuit test switch, a warning horn, a flasher unit, and two warning lights. The warning light's which have red lenses are located one (Fig 1(2)) in front of the driver's position, the other (Fig 10(1)) in the crew compartment, mounted next to the fixed fire equipment. The warning light in the personnel compartment is attached to a box in which a flasher unit is housed. When energized, the flasher unit causes the warning lights to flash.

15 An audible warning is given by the sounding of a horn, located below the driver's switchboard and by a buzz, which can be heard in all connected headphones.

16 If the automotive battery switch is off, the warning lights will not flash in the event of a fire or overheating or if the test switch is operated, the battery switch does not affect the audible warnings.

Testing the circuit

17 Ensure that the automotive battery switch (Fig 9(2)) 'ON'.

18 Connect headphones to the appropriate control boxes.

19 Operate the test switch on the firewire control box (mounted below the distribution box) and check that:

19.1 The warning horn sounds.

19.2 A warning buzz is heard in all connected headphones.

19.3 Both warning lights flash.

20 The test switch will not operate the warning units if:

20.1 There is no supply to the control box.

20.2 A short circuit exists in the sensing element loop or connecting circuit.


20.3 An open circuit exists in the loop or its connections.

20.4 The control box is defective.

21 If the warning units continue to function after releasing the test switch, it indicates that there is a low resistance leakage to earth due to contamination of the element connectors or termination fittings. To stop the warning signals, the control circuit must be temporarily interrupted at the distribution panel fitted at the right of the driver's compartment. The procedure for this is as follows:

21.1 Distribution panel No. 6, Mk 1 - Release circuit breaker compartment cover (Fig 9(1)), pull the button circuit breaker 'J' to open the circuit breaker. Close the circuit breaker by pressing the button.

21.2 Report the fault immediately so that it may be rectified as soon as possible.



432/038

- 1 Circuit breaker compartment cover
- 2 Battery master switch

Fig 9 Distribution panel No. 6, Mk 1

ACTION IN THE EVENT OF FIRE

22 In all cases of fire:

22.1 Stop the vehicle.

22.2 Stop the engine.

22.3 Turn both battery switches to 'OFF'.

23 The senior person present must take charge of the fire fighting operation and direct it according to the nature of the fire.

External fires, driver's, and crew compartment fires

24 Use the portable extinguishers.

Power pack compartment fires

25 If the warning device operates or flames are seen, discharge one cylinder. If after the first cylinder has discharged the fire persists, discharge the second cylinder.

26 If no warning is given but smoke is seen, stop the vehicle, stop the engine, turn both battery switches to 'OFF' and investigate carefully. If investigation is impracticable or if smoke persists or increases, discharge one or, if necessary, both cylinders.

MAINTENANCE**Checking a portable fire extinguisher**

27 Remove the extinguisher from its bracket and examine for damage.

28 Check the striker knob on the internally mounted portable extinguishers, if it can be turned by finger and thumb, or has been pushed in, the extinguisher should be discarded and a replacement obtained.

NOTE

On earlier types of extinguisher, apply thumb pressure to white spot on domed top. Renew extinguisher if spot remains pressed in. Later types may have a gauge fitted.

29 Check that the discharge nozzle is clear.

NOTE

The extinguishers are sealed and cannot be dismantled for further examination.

30 Check that each externally mounted portable extinguisher is fully charged. Check dependant on type of extinguisher fitted.

Servicing the fixed fire extinguisher system


31 Check that each cylinder is secure in its mounting.

32 Check that each cylinder is fully charged by checking the gauge is indicating in the green range. If the indicator is outside of the green range the cylinder must be changed.

NOTE

Crew must not attempt to remove a discharged or partially discharged cylinder, but at the first opportunity, report the condition of the cylinder to REME. The vehicle shall be VOR (Vehicle off the road) until the fault has been rectified.

- 33 Check that the cable connections to the remote control handles are in order.
- 34 Test the alarm system see Para 17 to 21.



430/20160

- 1 Fire warning light

Fig 10 Crew compartment left hand

CHAPTER 2-2
HULL AND FITTINGS
CONTENTS

Para	
	Introduction
1	General
	Driver's and commander's compartment
2	Driver's hatch
3	Driver's periscope
	Periscope/windscreen washer
6	Filling the fluid container
7	Operating the washer
9	Cleaning a nozzle
10	Pump unit
11	Removing and replacing the driver's periscope (CAUTION)
12	Driver's seat
15	Seat adjustment
16	Fitting the harness
17	Releasing the harness
18	Seat maintenance
20	Driver's controls and instruments
21	Steering/brake levers
22	Parking controls
23	Accelerator pedal
24	Engine fuel stop control
25	Engine speed hand control
26	Gear range selector lever
27	Engine/transverse dis-connector handle
28	Driver's periscope screen washer control handle
29	Dipswitch
30	Horn push button
31	Instrument panel
32	Driver's switchboard
33	Fire alarm horn
34	Firewire control box
35	Fire alarm lighting light
36	Distribution link box
37	Distribution panel No. 6 Mk 1
38	Power pack access plate (engine covers)
39	Removing and replacing the plate (CAUTION)
40	Commander's cupola hatch
41	Cupola
45	Removing and replacing the commander's periscopes (CAUTION)
46	Commander's seat
52	Maintenance
	Commander's instruments and controls
53	Vacuum/pressure gauge, air conditioning system
54	Test button, ventilation system
55	Ventilation fan, speed control
56	Smoke discharger switches
57	Radio distribution box
58	Communication equipment
	Crew Compartment
59	Crew seats
63	Maintenance

CONTENTS (continued)

Para

64	Operator's hatch
65	Escape hatch
	Crew compartment controls
69	Fire alarm warning light
70	Auxiliary junction box
73	Crane pump engagement lever
74	Crane operator's engine speed control
75	Crane operator's engine switchboard
	Load carrying compartment
76	Crane operators platform
80	Catwalk
	Load carrying compartment controls and instruments
81	Crane control lever
82	Hydraulic suspension lock control
	External equipment
83	Mounting steps
86	Workbench
89	Tow bar
92	Rear stowage compartment door
95	High visibility marker boards
97	Power pack access
98	Air inlet and outlet louvres
101	Steering unit access cover (WARNING)
102	Smoke grenade dischargers
103	To load (WARNINGS)
104	To fire
105	Misfire
106	To unload (WARNINGS)
108	After firing
109	Fuel system (WARNINGS)
112	Fuel tank
113	Filling the fuel tank
114	Draining the fuel tank
	Maintenance
116	Checking and topping up the governor oil level
	Maintenance
117	Draining the vehicle hull (WARNING)
118	Hull details lubrication
119	Mount, gun, 7.62 mm, No. 3 Mk 1 (CAUTION)
124	Mount, gun, 7.62 mm, No. 3 Mk 1 for GPMG L7
131	Mounting the GPMG
133	Removing the GPMG
134	Securing the GPMG for travelling
135	Positioning the spent case bin
136	Removing the spent case bin
137	Servicing and maintenance

Table

Page

1	Washer fluid mixture ratios	5
---	-----------------------------------	---

(continued)

CONTENTS (continued)

Fig		Page
1	Hull external fittings (Mk 1 vehicle).....	4
2	Cupola and driver's hatch.....	7
3	Driver's seat.....	9
4	Radio batteries.....	10
5	Driver's compartment.....	11
6	Driver's controls and instruments.....	12
7	Instrument panel.....	13
8	Driver's switchboard.....	13
9	Distribution panel No. 6 Mk 1.....	15
10	Engine/transverse dis-connector control handle.....	16
11	Cupola and driver hatch (closed).....	18
12	Commander's seat.....	19
13	Ventilation fan controls.....	20
14	Radio distribution box.....	21
15	Schematic layout of communication equipment.....	23
16	Crew compartment, left side.....	24
17	Crew compartment, right side.....	25
18	Crane operation hatch.....	26
19	Escape hatch.....	27
20	Auxiliary control box.....	28
21	Crane pump engagement lever.....	29
22	Crane operator's switchboard and speed control.....	29
23	Crane operators platform.....	30
24	Crane controls.....	31
25	Front of vehicle.....	33
26	Rear of vehicle.....	34
27	Power pack covers.....	35
28	Fuel system.....	38
29	Load compartment, front right corner.....	39
30	Fuel tank drain valve.....	40
31	Hull drain points.....	41
32	Mount, gun 7.62mm No 3 Mk 1.....	43/44

INTRODUCTION

General


1 The hull is constructed of welded steel and armour plates, and is divided into four compartments; the power pack, the driver and commander, the crew, and load carrying.

1.1 Driver's and commander's compartment. The compartment is located at the front of the RH side of the hull, covered by an overhead armoured glacis plate. The glacis plate contains a rectangular shaped hole, which provides normal access for the driver. The access hole is closed by an armoured hatch. The hatch is fitted with a wide angled periscope (Fig 1(4)). The driver's seat can be adjusted to facilitate varying driving positions and to permit emergency evacuation though he rear of the compartment. The commander is located directly behind the driver, covered by an overhead armoured roof plate. The roof plate contains a circular shaped hole, which provided normal access for the commander. The access hole is closed by an armoured hatch mounted on the cupola (Fig 1(3)). The cupola has a 360 deg rotation, with three periscopes (2), both outer periscopes fixed. Centre AFV No. 32 Mk 1 periscope can be pivoted axially in vertical plane is fitted with three periscopes. A mount (1) for a (GMPG) general-purpose machine gun is also provided. The commander's seat can be adjusted to facilitate varying positions and to permit emergency evacuation though the rear of the compartment.

1.2 **Crew compartment.** The compartment is located immediately behind the commander and extends the full width of the hull, covered by an armoured roof plate. The roof plate contains a rectangular shaped hole, which provides normal access to the compartment. The access hole is closed by an armoured hatch. The compartment provides seating for two crew (crane operator and fourth crewman). Additionally an escape hatch is provided in the hull bottom plate as an alternative means of exit should the roof door be obstructed.

1.3 **Load carrying compartment.** The compartment is on the top of the vehicle between the crew compartment and the rear of the vehicle.

1.4 **Power pack compartment.** The power pack compartment is located at the front LH side of the hull, covered by overhead armoured glaucis and roof plates. Access covers (Fig 1(6)), air intake and outlet louvres are located in the roof plates. The compartment houses the power pack.



430/20161

- | | | | |
|---|------------------------|---|----------------------------|
| 1 | GPMG Mount | 5 | RH Smoke discharger |
| 2 | Commander's periscopes | 6 | Power pack covers |
| 3 | Commander's Cupola | 7 | Steering unit access cover |
| 4 | Driver's periscope | 8 | LH Smoke discharger |

Fig 1 Hull external fittings (Mk 1 vehicle)

DRIVERS AND COMMANDER'S COMPARTMENT

Driver's Hatch

2 The door of the driver's hatch is spring assisted in opening and is locked when closed, by a locking catch (Fig 2(12)), which can be operated only from inside the vehicle. The door carries a wide-angle periscope (Fig 2(13)) for closed down driving. A spring-loaded catch retains the door in the open position.

Driver's periscope

- 3 The drivers hatch carries a wide-angle periscope (Fig 2(13)) for closed down driving.
- 4 The periscope wiper blades can be operated manually by the wiper manual control handle (Fig 2(16)), or electrically by a motor (20) attached to the door. For the manual operation move the wiper manual control handle back and forth as necessary to obtain a clear field of view. For the motor operation, with the battery and engine switches ON, move the wiper manual control parking handle to the left away from the parked position, then operate the wiper motor switch.

NOTE

In the parked position, the wiper motor switch is locked in the OFF position.

- 5 The periscope washer is operated manually by a screen washer control handle (16) in the head of the container, which is located on the left in front of the driver. The container can be filled through a hole in the container head after removing a rubber bung.

Periscope/windscreen washer

Filling the fluid container

- 6 Remove the rubber filler bung from the pump unit and pour in washer fluid (mixed dependant upon temperature, in compliance with Table 1) until the tank is filled to the level of the filler opening. Ensure that dirt, oil or grease does not enter the tank.

TABLE 1 WASHER FLUID MIXTURE RATIOS

Freezing point of mix (approx) Deg C (1)	MOD Screen wash (2)	Parts water (3)	Parts AL11 (4)
-5	1	8	1
-10	1	7.5	1.5
-12.5	1	6.5	2.5
-15	1	6	3
-17.5	1	3	6

NOTE

- (1) Soft or distilled water must be used whenever possible. If an emergency arises and water from another source is used, it is essential that it is perfectly clean.
- (2) If the pump fails a new container (reservoir) and pump, are to be fitted in accordance with AESP 2350-T-250-821 Mod 1/60.

Operating the washer

- 7 Pull the handle (Fig 2(16)) steadily, hold it a moment, and then release it. The return action is spring operated, therefore the handle MUST NOT be pushed back, or damage may be caused.

NOTE

If the handle does not return, there is an obstruction in the system, possibly due to dirt at the nozzle. To clean the nozzle, refer to Para 9.

- 8 While the spray is operating switch 'ON' the wiper motor; switch 'OFF' when the spray ceases.

Cleaning the nozzle

- 9 The procedure for cleaning the nozzle is as follows:
 - 9.1 Remove the nozzle and the nozzle-sealing washer from the jet unit.
 - 9.2 Blow air through the nozzle in the reverse direction to the fluid flow until the nozzle is cleared.
 - 9.3 Operate the control handle two or three times to flush out the system.
 - 9.4 Replace the nozzle and sealing washer then check efficient operation.

Pump unit

- 10 Should the pump unit become clogged by dirt or a sticking valve, report to REME.


Removing and replacing the driver's periscope

- 11 The procedure for removing and replacing the driver's periscope, is as follows:
 - 11.1 Slacken the knurled nuts (Fig 2(19)) at the bottom of the supporting lugs.
 - 11.2 Swing the lower part of the periscope forward to clear the lugs, and then lower the periscope from the mounting.
 - 11.3 Clean the inside of the periscope aperture and wipe with a lightly oiled clean cloth.
 - 11.4 Any mud or dirt accumulated on the periscope glass surfaces must be washed off with clean water and the surfaces dried with a clean cotton rag. On no account should mud or dirt be removed in a dry condition.

CAUTION

EQUIPMENT DAMAGE. The glass surfaces must be kept perfectly clean they must not be touched directly with the fingers.

- 11.5 Replace the periscope in the reverse sequence, taking care not to damage the wiper blades.



430/20117

- | | | | |
|----|---------------------------------|----|------------------------------|
| 1 | Clamp handle | 12 | Rotatable catch |
| 2 | Cupola door catches | 13 | Drivers periscope |
| 3 | Periscope casing locking catch | 14 | Brow pad |
| 4 | Brow pads | 15 | Wiper / IR switch |
| 5 | Knurled screws | 16 | Screen washer control handle |
| 6 | Radio batteries flame trap | 17 | Filter unit |
| 7 | Automotive batteries flame trap | 18 | Washer container head |
| 8 | Smoke discharger switches | 19 | Knurled nut |
| 9 | Distribution panel | 20 | Periscope wiper motor |
| 10 | Battery master switch | 21 | Dummy socket |
| 11 | Instrument panel | | |

Fig 2 Cupola and driver's hatch

Driver's seat

12 The driver's seat (Fig 3) is designed for opened up or closed down driving and can be tilted forward to give access to the batteries underneath it. Hinged at the back of the frame is the commander's footrest (5).

13 The backrest has two locations and can also be tilted or lowered completely to allow access from the rear.

14 A safety harness is fitted to the backrest and anchored to the roof and when in use restrains the driver from uncontrollable movement while travelling.

Seat adjustment

15 Adjust the seat as follows:

15.1 To adjust the seat for height, ease the weight of the body from the seat and push forward the height adjusting lever (Fig 3(4)) on the right, press down the seat or allow it to rise until the desired position is reached, then release the lever. Six positions are obtainable.

15.2 To move the seat backward or forward, depress the longitudinal adjustment bar (2) located along the bottom front of the seat and slide the seat to the required position. Release the bar and ensure that the catches re-engage. The seat can be slid rearwards until it is completely clear of the slides.

15.3 To locate the backrest in either position, lift it and move it forward or backward.

15.4 To adjust the tilt of the backrest, press down the backrest-adjusting lever (7) on the right of the backrest, tilt the backrest to one of five positions, and then release the lever.

15.5 To lower the backrest, press the lever on the right of the backrest and lower the backrest to the horizontal position.

15.6 To obtain access to the radio batteries, remove the bolts, one either side, securing the supporting cross-member then tilt the seat upwards and forwards (Fig 4(1)).

NOTE

The vehicle may be fitted with maintenance free batteries and the individual battery cells cannot be refilled.

Fitting the harness

16 The procedure for fitting the harness (Fig 3(1)) is as follows:

16.1 Check harness for serviceability (Para 21 and 22 refers), if found unserviceable, report.

16.2 Move the two parts of the harness to each side clear of the seat.

16.3 Sit in the seat.

16.4 Place the arms under the shoulder straps and arrange the straps in front of the body.

16.5 Draw together the two parts of the quick-release buckle and engage them, then press the handle so that it lies flush with the rest of the buckle.


Releasing the harness

17 Lift the quick-release buckle handle marked 'LIFT'. Slip the shoulder straps off the shoulders.

Seat Maintenance

18 User maintenance to the driver's seat is restricted to checking the security of the seat mounting fixtures, ensuring all sliding surfaces and pivot points are lightly oiled and that all catches, locking levers and operating mechanisms operate correctly.

19 User maintenance for the safety harness is restricted to checking the security of the mounting screws and the belts for chaffing and freedom of movement. Check the operation of the quick release buckle mechanism.



- | | | | |
|---|-----------------------------|---|----------------------------------|
| 1 | Harness | 5 | Commander's footrest |
| 2 | Longitudinal adjustment bar | 6 | Throw-over link positioning seat |
| 3 | Torsion bar | 7 | Backrest adjusting lever |
| 4 | Height adjusting lever | | |


Fig 3 Driver's seat

Driver's controls and instruments

20 Drivers controls, instruments and layout of the drivers compartment are illustrated in figures 5 and 6.

Steering/brake levers

21 The steering/brake levers (Fig 5(3)) are mounted to the hull floor in front of the driver, a mechanical linkage connects the levers to the steering unit brake mechanism. The levers are used to steer and brake the vehicle.



430/20087

- | | | | |
|---|--------------------|----|------------------------------|
| 1 | Seat frame | 7 | Container housing frame |
| 2 | Negative terminal | 8 | Container |
| 3 | Vent tube assembly | 9 | Access plate, gearbox filter |
| 4 | Rubber cover | 10 | Footrest bracket |
| 5 | Battery clamp bolt | 11 | Seat bracket |
| 6 | Battery clamp bar | 12 | Inter-connector |


Fig 4 Radio batteries

Parking control

22 The parking control button protrudes through a screwed cap (Fig 6(14)) on the upper end of each steering/brake lever. It is a 'spring loaded' plunger, which is applied; when the brake/steering levers are fully applied, the buttons are depressed to locked into position. To release the plunger locks pull backwards on the levers and press the buttons. This will release the levers for normal operation.

Accelerator pedal

23 The accelerator pedal (Fig 5(6)) is located by the driver's right foot and is mechanically linked to the power pack to control engine speed.



430/20162

- | | | | |
|---|---------------------------------------|----|---------------------------------------|
| 1 | Power pack access plate upper section | 6 | Accelerator pedal |
| 2 | Sight wiper switch | 7 | Engine fuel stop control |
| 3 | Steering/brake levers | 8 | Engine speed hand control |
| 4 | Driver's turn light switchboard | 9 | Gear range selector lever |
| 5 | Instrument panel | 10 | Power pack access plate lower section |

Fig 5 Driver's compartment

Engine fuel stop control

24 The engine fuel stop control (Fig 5(7)) is the pedal located by the driver's left foot. It is mechanically linked to the engine, depressing the control pedal stops the engine by cutting its supply of fuel.

Engine speed hand control


25 The engine speed hand control (8) is mounted at the front of the power pack compartment sill. The control permits independent control of engine speed when the vehicle is stationary to charge automotive, ventilation and radio batteries.

Gear range selector lever

26 The gear range selector lever (9) is mounted to the left of the driver on the power pack compartment sill. The gear range selector lever is mechanically linked to the vehicle gearbox and can be shifted to pre select a required gear range. The gear ranges, which can be selected, are 1-2, 3-4, 3-5, 3-6, neutral and reverse. To engage the select lever in the reverse slot it is necessary first to pull the reverse stop knob out.

Engine/transverse gearbox dis-connector access cover

27 Engine/transverse gearbox dis-connector control handle (Fig 10(4)) is located under the hinged cover (1) at the rear end of the power pack sill. The dis-connector is used to facilitate engine starting whilst either cold starting or being slave started.



430/20163

1	Fire warning light	8	Distribution link box
2	Interior light	9	Distribution link box warning light
3	Instrument panel	10	Driver's lighting switchboard
4	Distribution panel	11	Steering/brake lever
5	Firewire control box test switch	12	Horn push
6	Firewire control box	13	Parking control button
7	Automotive batteries		

Fig 6 Driver's controls and instruments

Driver's periscope screen washer control handle

28 The washer unit is mounted on the sloping roof plate in front of the driver (see Para 7 for operation).

Dipswitch


29 The dipswitch is the foot-operated switch on the floor adjacent to the driver's left foot. With the headlights switched on, operation of the switch changes the light beams of the headlight from main to dip or vice versa. A warning light on the turn-light switch glows when the main beams are on.

Horn push button

30 The horn push (Fig 6(12)) is located to the right of the driver's switchboard. It is a push type switch controlling the traffic horn.

Instrument panel

31 The instrument panel (Fig 6(3)) is mounted to the right of the driver's switchboard and houses instruments related to the power pack and vehicle speed illustrated in Fig 7.




432/085

- | | | | |
|---|---------------------------|----|-------------------------------------|
| 1 | Tachometer | 6 | Panel lights switch |
| 2 | Panel light | 7 | Safe Working temperature indicator |
| 3 | Coolant temperature gauge | 8 | Gearbox oil temperature gauge |
| 4 | Fuel gauge | 9 | Fuse |
| 5 | Ammeter | 10 | Speedometer trip reading reset knob |
| | | 11 | Speedometer |

Fig 7 Instrument panel

Driver's switchboard

32 The driver's switchboard (Fig 8) is located in front of the driver; it mounts the turn light switch (1), engine switch (6) and external lighting (4) switchboards.



432/456

- | | | | |
|---|--------------------------------|---|--------------------------|
| 1 | Turn light switch | 5 | Starter switch |
| 2 | Main indicator (GEN) | 6 | Engine switch |
| 3 | Low oil pressure warning light | 7 | Main beam warning light |
| 4 | External lighting switchboard | 8 | Turn light warning light |

Fig 8 Driver's switchboard

Fire alarm horn

33 The fire alarm horn is located on the front sloping plate below the driver's switchboard and marked FIRE ALARM.

Firewire control box

34 The firewire control box (Fig 6(6)) is mounted on the vehicle RH side plate adjacent to the automotive batteries. The control box houses the fire alarm system test switch (5).

Fire alarm warning light


35 The fire warning light (1), is fitted with a red lens, is located in front of the driver.

Distribution link box

36 The distribution link box (8) is located immediately below the instrument panel. A small press to test warning light (9) is fitted to the left side of the link box. Under normal conditions, with the alternators charging, the light is dim, if the radio batteries positive line is earthed, the light is bright. If the radio battery connections are reversed, the light is bright before the engine is started, if the engine is started in this condition the lamp will glow excessively and burn out. Internal damage will also be caused to the charging system.

Distribution panel No. 6 Mk 1

37 The distribution panel No. 6 Mk 1 (Fig 9) is mounted on the roof plate to the right of the driver. The battery master switch (11) on this panel controls both the automotive and the ventilation batteries and the fuses were replaced by Circuit Breakers (CBs).



432/342

- | | | | |
|---|--------------------------|----|-----------------------|
| 1 | Cover | 7 | NBC ON |
| 2 | Nut | 8 | External light switch |
| 3 | Metal case | 9 | Battery selector |
| 4 | Anti-vibration mounting | 10 | Circuit breaker cover |
| 5 | Circuit breaker (11 off) | 11 | Battery master switch |
| 6 | CBR ON | | |

Fig 9 Distribution panel No. 6, Mk 1

Power pack access plate (engine covers)

38 Access to the right side of the power pack is provided by a removable plate forming the rear part of the longitudinal partition. The plate is made in two sections secured by 18 turn catches, nine on the upper section (Fig 5(1)) and nine on the lower (10). The turn catches (Fig 10(2)) are fixed to hexagon heads on the outer side of the plate; each head has a saw-cut to indicate the position of the catch. The seal between the sections is made by four clamp plates attached to the lower section.

Removing and replacing the plate

39 The procedure for removing and replacing the plate is as follows:


39.1 Ensure that the commander's cupola is positioned so that the periscope handles are not in the way when removing the access plate. Lower the driver's seat and backrest, remove the commander's seat backrest.

39.2 Release the four clamp plates sealing the joint between the two sections, turn the catches securing the upper section and lift the section away. Turn the catches securing the lower section and lift the lower section away.

CAUTION

EQUIPMENT DAMAGE. Report immediately any signs of distortion or defects, which might impair the air seal. This is essential to prevent overheating power pack components.

39.3 Examine the seal and sealing surfaces and to refit the plate, proceed in the reverse sequence to that for removing.



432/048

- | | | | |
|---|------------|---|------------------------------|
| 1 | Cover | 4 | Dis-connector control handle |
| 2 | Turn catch | 5 | Power pack partition plate |
| 3 | Catch | | |

Fig 10 Engine/transverse gearbox dis-connector control handle

Commanders cupola hatch

40 The commanders hatch in the top of the cupola (Fig 1(3)) when closed is held by two door catches (Fig 11(2)). The catches can be operated only from inside the vehicle. A stop bracket and spring catch retains the door in the open position.

Cupola

41 The cupola (Fig 11) is rotatable through 360 deg to allow all round vision for the commander and full use of the Machine Gun (MG).

42 Three periscopes are mounted side by side on the cupola ring with the General Purpose Machine Gun (GPMG) pintle-mounting bracket welded to the guard over the periscopes. The outer periscopes have fixed positions but the middle periscope is capable of limited movement in the vertical plane.

43 A window is mounted on the periscope guard to cover the object glass of the left periscope. The window has a wiper operated by a flexible cable and torsion spring acting on the spindle of the wiper arm. To operate the wiper pull down the handle of the flexible cable then release it. The wiper arm returns under the action of the torsion spring.

44 The hinged door in the top of the cupola when closed is held by two rotatable catches (2). The catches can be operated only from inside the vehicle. A stop bracket and spring catch retains the door in the open position. The cupola can be locked against rotation by three clamps disposed equi-distant around the cupola ring. By turning down the clamp handles (1) from horizontal to vertical, the cupola is held from further rotation to retain a field of view.

Removing and replacing the commander's periscope

45 The procedure for removing and replacing the commander's periscope, is as follows:

45.1 Unscrew the knurled screw (Fig 11(5)) in the supporting strap under the periscope. Support the periscope, swing the strap inwards and lower the periscope.

45.2 Clean the inside of the periscope aperture and wipe with a lightly oiled clean cloth.


45.3 Any mud or dirt accumulated on the periscope glass surfaces must be washed off with clean water and the surfaces dried with a clean cotton rag. On no account should mud or dirt be removed in a dry condition.

CAUTION

EQUIPMENT DAMAGE. The glass surfaces must be kept perfectly clean; they must not be touched directly with the fingers.

45.4 Replace the periscope in the reverse sequence, taking care not to damage the wiper blades.

45.5 Repeat the operations for the other two periscopes.



430/20117

1	Clamp handles	12	Locking catch
2	Cupola door catches	13	Driver's periscope
3	Periscope casing locking catch	14	Brow pad
4	Brow pad	15	Wiper switch
5	Knurled screws	16	Screen washer control handle
6	Radio battery flame trap	17	Filter unit
7	Automotive battery flame trap	18	Wiper manual control handle
8	Smoke discharger switches	19	Knurled nut
9	Accessories control box	20	Wiper motor
10	Battery Master Switch	21	Dummy socket
11	Instrument panel		

Fig 11 Cupola and driver's hatch (closed)

Commander's seat

46 The seat (Fig 12) is attached to the vehicle side plate below the cupola. It is adjustable for height and can be stowed to allow free passage to and from the driver's compartment.


47 To adjust the seat for height, slacken the hand wheel (4) on the seat support (3) lift or lower the seat to the required position, then retighten the hand wheel.

48 The seat and backrest (1) can be moved to facilitate access to the driver's compartment from the personnel compartment. To move the seat, lift the backrest and lower it backwards, then lift the seat at the side opposite the hinge (2).

49 A safety harness anchored to suitable points on the hull and seat bracket is provided to minimize the risks of injury to the commander.

Maintenance

52 User maintenance to the commander's seat is restricted to checking the security of the seat mounting fixtures. Ensuring all sliding surfaces and pivot points are lightly oiled and that all catches, locking levers and operating mechanisms operate correctly



432/046

- 1 Backrest
- 2 Support hinge
- 3 Seat support
- 4 Hand wheel

- 5 Support slide
- 6 Footrest support
- 7 Backrest hinge

Fig 12 Commander's seat

Commander's instruments and controls

Vacuum/pressure gauge, air conditioning system

53 The vacuum/pressure gauge, air conditioning system (Fig 13(2)) is mounted below the commander's cupola. The gauge reads the internal air pressure when the environmental control system is operating.

Test button, ventilation system


54 The test button, for the ventilation system (3) is mounted below the vacuum/pressure gauge. When the button is pressed, the vacuum gauge will give an indication of the amount of dust in the environmental control system filters.

Ventilation fan, speed control

55 The ventilation system fan, speed control (7) is mounted at the side of the right hand side crew seat.

Smoke discharger switches

56 The smoke discharger switches (Fig 11(8)) are located to the rear of the driver's hatch. They are of the push button type and fire respectively the right and left smoke dischargers.





434/024

- | | | | | | |
|---|-------------------------|---|------------------------|---|-------------------|
| 1 | Vent tube to atmosphere | 4 | Commander's cupola | 6 | Water trap |
| 2 | Vacuum/pressure gauge | 5 | Tube to filter housing | 7 | Fan speed control |
| 3 | Test button | | | | |

Fig 13 Ventilation fan controls

Radio distribution box

57 The radio distribution box (Fig 14) is secured to a bracket (1) which in turn is mounted to the hull wall to the left of the commander. The mounting bracket also locates the Vehicle User Data Terminal (VUDT) (2) which is mounted in front of the radio distribution box and partially obscuring the radio distribution box controls. The box contains a radio battery switch (2), external charging switch (4) and generator warning light (3).



- 1 Mounting bracket
- 2 VUDT
- 3 Radio battery switch
- 4 Generator warning light

- 5 External charging switch
- 6 Fuse cover
- 7 Terminal cover

430/20164

Fig 14 Radio distribution box

COMMUNICATION EQUIPMENT

58 Figure 16 is a schematic diagram of the communication equipment installed in the vehicle, it details the equipment fitted in the commander's and driver's stations, crew compartment and loading bay, and is included for reference only. Full details of the operation of the equipment is detailed in the relevant Interactive Electronic Technical Publication (IETP) (TBA) Bowman radio publications.

NOTE

This illustration represents a full communications fit, for certain roles some of the equipment may have been removed.

CREW COMPARTMENT

Crew seats

59 The crew seats are located in the crew compartment to the rear of the commander. The crane operator's seat is located on the right side of the vehicle and the 4th crewman's seat on the left hand side of the vehicle.

60 The crew seats are hinged (Fig 16 and 17) with separate back and head rests are provided at each end of the transverse crew compartment. A chain and hook is attached to each seat assembly for the retention of the seats in the folded position.

61 Stowage is provided to the underside of the seat trays to accommodate a first aid kit and vehicle literature.

62 Safety harnesses anchored to suitable points on the hull and seat brackets are provided to minimize the risks of injury to the crew members.

Maintenance

63 User maintenance for the personnel seats is restricted to checking the security of the seat mounting fixtures, ensuring the locking catch mechanisms operate to retain the seats in the vertical and horizontal positions, and all hinges and locking catches are lightly oiled.

10

REDACTED






Fig 15 Schematic layout of communication equipment



430/20165

- | | | | |
|---|------------------------------------|----|------------------------------------|
| 1 | Portable fire extinguisher bracket | 7 | Backrest |
| 2 | HFPA | 8 | Harness |
| 3 | Air conditioning filter housing | 9 | Portable fire extinguisher bracket |
| 4 | Fixed fire extinguisher cylinders | 10 | Headrest |
| 5 | Crane pump engagement lever | 11 | Fan motor |
| 6 | Seat | | |

Fig 16 Crew compartment, left side




430/20166

- | | | | |
|---|-----------------------------|----|---------------------------------|
| 1 | Fan speed control | 7 | Reservoir filler cap |
| 2 | Head rest | 8 | Backrest |
| 3 | Roof light | 9 | Reservoir |
| 4 | Crane operators switchboard | 10 | Slewing rack lubricating nipple |
| 5 | Reservoir vent | 11 | King post lubricating nipple |
| 6 | Auxiliary junction box | | |

Fig 17 Crew compartment, right side

Operator's hatch

64 The operators hatch (Fig 18(1)) is located at the rear of the cupola. The door is spring assisted when opening or closing and is locked by two rotatable catches operated from inside or outside the vehicle. A spring loaded catch on the air outlet louvre, which can be released by a handle on the catch, retains the door in the open position. The underside of the door is padded. A hasp is provided on the door and a staple on the vehicle roof to allow the door to be padlocked.



434/005a

1 Commanders hatch

2 Crane operators hatch

Fig 18 Crane operators hatch

Escape hatch

65 An escape hatch (Fig 19) is provided in the hull bottom plate below the crew compartment as an alternative means of exit should the roof door be obstructed. The hatch cover (2) is secured to the hull bottom plate by a cruciform clamp (1) and the hatch well is covered by a removable floor plate.


66 To open the hatch grasp the floor plate catch handles and rotate them a quarter turn, then lift the floor plate clear. Unscrew the clamp by turning the handle (3) anti-clockwise until the cruciform clamp can be turned and the hatch cover removed.

67 When replacing the hatch cover, check that the seals and sealing faces are clean, in good order, then position the cover over the hatchway, and adjust the clamp in order that the pads are centrally disposed at each side, tighten the clamp by turning the handle clockwise until a water tight seal is ensured.

NOTE

The clamp handle must be clear of the angle plates welded to the underside of the floor plate.

68 To replace the floor plate, engage the left edge of the plate under the retaining lip on the edge of the hatch well, lower the plate, and engage the catches. Ensure that the catch handles lie in the recesses provided.



434/016

- | | | | |
|---|----------------------|---|--------------------|
| 1 | Cruciform clamp | 3 | Locking handle |
| 2 | Power pack partition | 4 | Escape hatch cover |

Fig 19 Escape hatch

Crew compartment controls

Fire alarm warning light


69 The fire alarm warning light is centrally mounted at the top front of the personnel compartment.

Auxiliary junction box

70 The auxiliary junction box (Fig 19) is located on the rear of the vertical member forward of the ventilating fan. Four interior lights are provided which are controlled by switch No. 2 (Fig 19(7)) on the auxiliary junction box; each light incorporates its own switch and dimmer resistance.

71 Under normal conditions put switch No. 2 on the auxiliary junction box to 'ON' then switch 'ON' the individual lights as required.

72 Under blackout conditions put switch No. 2 to 'OFF' then set the individual light switches to provide the minimum amount of light for the task in hand.



432/091

- | | | | |
|---|---------|---|--|
| 1 | Fuse F5 | 5 | Fuse F1 |
| 2 | Fuse F4 | 6 | Switch No. 1 (spotlight and inspection
light sockets at crane position) |
| 3 | Fuse F3 | 7 | Switch No. 2 (Interior lights) |
| 4 | Fuse F2 | | |

Fig 20 Auxiliary junction box

Crane pump engagement lever


73 The lever (Fig 21(2)) is mounted on the pump drive gear housing, which is bolted to the transverse gearbox. The lever extends through the power pack rear partition into the operator's compartment. For operation of the lever, refer to Chap 3-1.

Crane operator's engine speed control

74 The control quadrant (Fig 22(4)) is mounted on the roof plate adjacent to the crane operator's seat. For operation of the control, refer to Chap 3-1.

Crane operator's engine switchboard


75 The crane operator's engine switchboard (Fig 22(1)) is mounted adjacent to the crane operator's engine speed control. For operation of the switchboard, refer to Chap 3-1.



434/055

- | | | | |
|---|---------------------------|---|-------------------------------|
| 1 | Power pack rear partition | 4 | Filler/level plug |
| 2 | Engagement lever | 5 | Drive engagement gear housing |
| 3 | Hydraulic pump | | |

Fig 21 Crane pump engagement lever



30/20167

- | | | | |
|---|-----------------------|---|-----------------------------------|
| 1 | Auxiliary switchboard | 4 | Quadrant |
| 2 | Wingnut | 5 | Linkage to governor control lever |
| 3 | Handle | 6 | Bulkhead |

Fig 22 Crane operator's switchboard and speed control


LOAD CARRYING COMPARTMENT**Crane operators platform**

76 The platform (Fig 23(3)) for the crane operator is mounted on the bulkhead below the hatch. To allow the platform to be stowed, it is hinged to the bulkhead.

77 The platform is a chequer plate supported at the front by two box channelled struts (6). The platform is linked to the struts by two pins (8), one each side of the platform, which engage slots (9) in the struts. The platform is held in the stowed position by a spring loaded catch (4).

78 To erect the platform, release the catch then raise the platform to the horizontal and manoeuvre the struts for the platform pins to drop into engagement with the slot end to secure the platform in position.

79 To lower the platform, lift the platform to disengage the pins from the slot ends, then lower the platform and engage the stowage catch.



434/015

1	Hinge pin	6	Strut
2	Bulkhead	7	Hinge bracket
3	Chequer floor plate	8	Pin
4	Catch	9	Slot
5	Escape hatch floor plate		

Fig 23 Crane operators platform

Cat-walk

80 Along each side of the load, carrying compartment is a hinge platform of two sections. The platform surface is chequer plate and the sections can be raised, and secured, by means of drop-end pins, when not in use. The drop-end pins are tethered by chains linked to the hinge brackets.


Load carrying compartment controls and instruments

Crane controls levers

81 The crane controls levers (Fig 24) are incorporated in the control valve unit mounted on the roof plate at the base of the crane. For operation of levers, refer to Chap 3.1.

Hydraulic suspension lock control

82 The hydraulic suspension lock control (Fig 24(4)) is mounted on the rear of the crane valve unit. The locking of the front and rear suspension units stabilizes the vehicle when lifting loads. A pressure gauge (5) is used to indicate suspension lockout. For operation of the control, refer to Chap 3.1.



434/014

- | | | | |
|---|-----------------|---|-------------------------------|
| 1 | Slewing lever | 5 | Lockout pressure gauge |
| 2 | Outer ram lever | 6 | Operators door locking handle |
| 3 | Inner ram lever | 7 | Operators door padlock hasp |
| 4 | Lockout lever | 8 | Light sockets |

Fig 24 Crane controls

EXTERNAL EQUIPMENT

Mounting steps

83 Steps are provided, one for driver and crewmembers to mount the vehicle, and two for use when maintenance tasks require crew to climb upon the roof of the vehicle.

84 The driver's step is attached to the right forward track guard and is permanently in position. The crew step (Fig 25(2)) at the front left of the vehicle is hinged to allow it to be stowed. To position the step for use, slide it upward to the limit of the hinge pinholes and swing it forward and downward. To stow the step, swing it upward to contact the front sloping plate and allow it to slide into the locked position.

85 The crew step (Fig 26(8)) at the rear is hinge mounted on the workbench. To position it for use, release the hook catch then lower the step and draw it rearward. Hook the strap, welded across the step frame, onto the lipped edge of the hinge bracket. To stow the step, lift the frame clear of the lipped edge, swing it to the stowed position, and engage the hook catch.

Workbench

86 The workbench is located at the rear of the vehicle, it is hinged to channel sectioned brackets welded to the bottom of the rear lockers. The bench is supported at the rear corners by two chains (4), which are hitched to hooks welded to the top of the locker rear plate. When stowed the bench lies flat against the rear lockers and is retained by a hasp and a captive drop end pin.

87 Hinged to the underside of the workbench is a vice mounting bracket (9), a captive pip pin is used to secure it in either the working or stowed position.

88 Two tapped bosses and an electrical socket are provided on the rear plate of the locker above the bench to mount and connect a fluorescent light.

Tow bar

89 The tow bar (12) comprises a prefabricated beam with a towing hook bolted to the centre. The hook is rotatable in the vertical plane, but is normally held in the upright position by a forked catch incorporated in the base of the mounting bracket. The hook closing plate is locked in the closed condition by a spring-loaded sprag.

90 The forked catch must only be released for the hook to rotate when towing trailers with fixed eyes.


91 The tow bar is attached for towing, to the two towing eye brackets welded to the vehicle rear plate, one either side of the rear stowage compartment door. The two locking pins, which are tethered by chains to the towing brackets, are inserted into the brackets from the lower side and rotated to rest the handles upon lipped brackets.

Rear stowage compartment door

92 The enclosed stowage compartment to the rear of the fuel tank is provided with a hinged access door (Fig 22(10)) in the hull rear plate. A hasp is welded to the door to provide means of padlocking.

93 The door is secured in the closed position by two locking catches. To seal the door for wading purposes four turn catches are positioned around the door on the hull rear plate, they can be tightened by means of a spanner.

94 When opened, the door hinge straps abut the hull rear plate and supports the door horizontally.



430/20168

- 1 Smoke dischargers
- 2 Foot step


- 3 Tow eyes
- 4 Turn lights

Fig 25 Front of vehicle

High visibility marker boards

95 High visibility boards (Fig 26(16)) are retained in holders (15), which are mounted to each rear stowage bin. The marker boards are reversible; they are painted on the reverse side with the appropriate colour and are then rotated to show the red/yellow side when travelling on public roads.

96 To reverse the high visibility marker boards depress the thumb catch and slide the holder. Fitting is the reverse, with the catch being depressed to avoid damage to board surface. When the chevrons are visible then ensure that the marker boards (16) are fitted as shown in Figure 26.



430/20009

1	Catwalk	9	Vice mounting bracket
2	Fire extinguisher bracket	10	Rear stowage door
3	Jerrican stowage bracket	11	Earthing terminal
4	Bench support chains	12	Trailer socket
5	Locker door clamp	13	Towbar
6	Rear stowage compartment door	14	Holder
7	Work bench	15	Marker board
8	Bench step	16	Registration plate light

Fig 26 Rear of vehicle

POWER PACK ACCESS


97 Access to the power pack is either from inside the driver's compartment (Para 42) or via the air inlet and outlet louvres (Fig 1(6)). Access to the steer unit is via the steering unit access cover (Fig 1(7)) situated on the hull front plate.

Air inlet and outlet louvres

98 The louvres (Fig 27(3)) and (7)) are hinged together by torsion bars and secured in the closed position by thirteen turn catches (9) and two clamp plates (6).

99 The weight of the doors is counterbalanced by the torsion bars and only one louvre can be opened at a time.

100 To open a louvre, release the two clamp plates, then slacken the locknuts, and rotate the turn catches a quarter turn. Raise the louvre until over centre then insert the locking pin (10) housed in the bracket through the two holes (8) in the left hinge as they come into alignment.



434/023

- | | | | |
|---|----------------------|----|-----------------------------|
| 1 | Turncatch (open) | 7 | Operator's door stop |
| 2 | Torsion bar tube | 8 | Operator's door catch |
| 3 | Inlet louvre | 9 | Outlet louvre |
| 4 | Coolant filler cover | 10 | Turncatch (closed) |
| 5 | Driver's hatch stop | 11 | Locking pin stowage bracket |
| 6 | Clamp plates | 12 | Locking pin holes |

Fig 27 Power pack covers

Steering unit access cover

WARNING

HEAVY WEIGHT. USE EXTREME CAUTION AND ENSURE THAT THE CURRENT REGULATIONS GOVERNING THE LIFTING AND LOWERING OF HEAVY WEIGHTS ARE OBSERVED WHENEVER A STEERING UNIT ACCESS COVER IS OPENED OR CLOSED.

101 The power pack access cover (Fig 1(6)) is secured by six turncatches, which are released when the locknuts are slackened and the turncatches rotated a quarter turn. Stops welded to the plate, limit the movement of each catch. Two handles are provided for lifting the cover, which hinges at the bottom.

SMOKE GRENADE DISCHARGERS

102 The two triple barrelled dischargers (Fig 24(1)) can be fired independently or both fired together by means of two push buttons (Fig 11(8)) adjacent to the commander.

To load**WARNINGS**

(1) **PERSONNEL DANGER. FATAL OR SERIOUS INJURY CAN OCCUR IF A SMOKE GRENADE DISCHARGES DURING THE LOADING PROCEDURE. ENSURE THE SMOKE DISCHARGER SWITCH IS IN THE OFF POSITION AND THAT ALL NON-ESSENTIAL PERSONNEL ARE CLEAR OF THE AREA TO A DISTANCE OF 200 METRES.**

(2) **SAFETY HAZARD. RADIO TRANSMISSION, DURING THE LOADING PROCEDURE, CAN CAUSE SMOKE GRENADES TO DISCHARGE. ENSURE NO TRANSMISSION TAKES PLACE DURING THE LOADING PROCEDURE.**

(3) **PERSONAL INJURY. KEEP OUT OF THE LINE OF FIRE OF DISCHARGER BARRELS WHEN LOADING OR UNLOADING SMOKE GRENADES.**

103 Insert the grenade in the barrel, clip end first, then press home to ensure correct engagement of the firing pin and clip.

To fire

104 Press the appropriate button on the firing button box.

Misfire

105 In the event of a misfire in any barrel, wait 5 minutes then without placing any body part in front unload and throw the grenade clear of the vehicle, or dispose of in accordance with Unit Standing Orders.

To unload**WARNINGS**

(1) **PERSONNEL DANGER. FATAL OR SERIOUS INJURY CAN OCCUR IF A SMOKE GRENADE DISCHARGES DURING THE UNLOADING PROCEDURE. ENSURE THE ARMING SWITCH IS IN THE OFF POSITION AND THAT ALL NON-ESSENTIAL PERSONNEL ARE CLEAR OF THE AREA TO A DISTANCE OF 200 METRES.**

(2) **SAFETY HAZARD. RADIO TRANSMISSION, DURING THE UNLOADING PROCEDURE, CAN CAUSE SMOKE GRENADES TO DISCHARGE. ENSURE NO TRANSMISSION TAKES PLACE DURING THE UNLOADING PROCEDURE.**

(3) **PERSONAL INJURY. KEEP OUT OF THE LINE OF FIRE OF DISCHARGER BARRELS WHEN LOADING OR UNLOADING SMOKE GRENADES.**

106 Withdraw the grenade from the barrel and place it in a storage canister.

107 Replace the discharger cover.

After firing

108 Remove the aluminium sealing plate left in the barrel after firing the grenade and dry clean the barrel.

FUEL SYSTEM

WARNINGS

- (1) **FIRE HAZARD. A RISK OF FIRE AND/OR EXPLOSION EXISTS WHEN FUEL IS BEING TRANSFERRED FROM ONE CONTAINER TO ANOTHER AT A POINT IN CLOSE PROXIMITY TO A RADAR SET. DO NOT TRANSFER FUEL WHEN A RADAR SET IS IN OPERATION AT A DISTANCE OF LESS THAN 30 M (100FT).**
- (2) **FIRE HAZARD. A RISK OF FIRE AND/OR EXPLOSION EXISTS WHEN FUEL IS BEING TRANSFERRED FROM ONE CONTAINER TO ANOTHER AT A POINT IN CLOSE PROXIMITY TO HF RADIO TRANSMISSION. REFUELING SHOULD NOT TAKE PLACE WHILST TRANSMITTING OR IF IN CLOSE PROXIMITY TO ANOTHER VEHICLE, WHICH IS TRANSMITTING.**
- (3) **PERSONAL INJURY. THE NO SMOKING OR NAKED LIGHT REGULATIONS MUST BE FOLLOWED WHENEVER FUEL IS BEING TRANSFERRED OR WHEN ANY PART OF THE FUEL SYSTEM IS OPEN.**

109 The fuel system is shown diagrammatically in Fig 27.

110 The fuel is drawn from its tank by an electrically operated pressurizing pump which, when started by operating the engine switch, delivers the fuel to the fuel injection pump through a replaceable element type filter mounted on the power pack frame. Leak-off fuel from the injectors, injection pump and filter relief valve is returned direct to the tank.

111 The fuel tank is positioned under the load carrying compartment floor plate, immediately behind the bulkhead and forward of the rear stowage compartment. It is secured in position by eight straps made of galvanized cable with hexagonal fittings.

Fuel tank

112 Fuel is carried in a tank located under the load compartment immediately behind the crew compartment bulkhead. The filler tube (Fig 28(5)) is on the right of the tank and extends upward through the load compartment floor almost to the top of the bulkhead to which it is attached. It is closed by a hinged cover under which is the filler cap (3). A drain valve is fitted centrally in the bottom of the tank, which is accessible after removing an access plate, from the hull bottom plate. A vent tube, (4) extends from the tank and runs parallel to the filler tube.

Filling the fuel tank


113 The procedure for filling the fuel tanks is as follows:

- 113.1 With the vehicle standing on level ground and earthed, open the hinged cover (Fig (3) on the tank filler tube (5).
- 113.2 Unscrew and lift out the filler caps.
- 113.3 Fill both tanks to capacity, checking progress by the fuel gauge reading.
- 113.4 Replace and secure the filler cap. Close and secure the hinged cover.

Draining the fuel tank

114 The tank is drained through a valve located in the bottom of the fuel tank. Access to the valve unit is through a hole in the hull bottom plate, after removing a circular plate (Fig 30(5)). The drain valve assembly has two plugs, one used to regulate the flow of fuel, the other to give access to the valve. Have suitably sized receptacles ready to collect the draining fuel and proceed as follows:

- 114.1 Earth the vehicle.



- 1 Injection pump leak-off
- 2 Fuel feed line
- 3 Injection pump feed
- 4 Relief valve
- 5 Fuel filter
- 6 Tank vent pipe
- 7 Fuel feed connection
- 8 Injection pump leak-off connection
- 9 Injector leak-off connection
- 10 Flexible pipes
- 11 Heater connection valve
- 12 Fuel tank filter
- 13 Fuel pump
- 14 Fuel injection pump
- 15 Injector leak-off
- 16 Flexible pipes
- 17 Injector leak-off connection
- 18 Injection pump leak-off connection
- 19 Fuel filter feed connection

Fig 28 Fuel system diagram

114.2 Unscrew the regulating plug (Fig 29(1)), i.e., the one with the larger head. This must be done slowly as fuel may gush out when the plug is removed if the valve is not seating correctly.


114.3 Remove the drain valve access plug (2).

114.4 Position a receptacle to collect drained fuel, then screw the regulating plug into the access plug hole until fuel starts to drain. Screwing the regulating plug in further increases the flow, unscrewing it decreases and stops the flow.

114.5 When all the fuel has drained, check that the valve operates freely in its guide and seats correctly.

114.6 Replace the plugs in their original positions, checking the washers for serviceability and correct fitting.


114.7 Replace the access plate and stow the earth spike.



434/019

- | | | | |
|---|-------------------|----|---------------------|
| 1 | Operators hatch | 6 | Dust cap |
| 2 | Air inlet cowl | 7 | Accumulator |
| 3 | Fuel filler cover | 8 | Hull drain plug |
| 4 | Fuel tank vent | 9 | Bulkhead light |
| 5 | Fuel filler tube | 10 | Ventilation ducting |

Fig 29 Load compartment, front right corner



434/020

- 1 Regulating plug
- 2 Drain valve access plug
- 3 Valve spring
- 4 Valve

- (a) Plugs in normal position
- (b) Regulating plug in draining position

Fig 30 Fuel tank drain valve

Maintenance**Checking and topping up the governor oil level**

116 The procedure for checking and topping up the governor oil level, is as follows:

- 116.1 Remove the power pack access plate (Para 59 to 63).
- 116.3 Clean the area surrounding the dipstick.
- 116.3 Withdraw the dipstick.
- 116.4 The level should be up to the full mark on the dipstick. If necessary, top up through the filter/dipstick hole.
- 116.5 Replace the dipstick. Refit the power pack access plate (Para 63).


MAINTENANCE**Draining the vehicle hull****WARNING**

ENVIRONMENTAL HAZARD. DO NOT DRAIN THE FLUID CONTENTS OF THE HULL ONTO THE GROUND. SUITABLE CONTAINERS SHOULD BE USED TO COLLECT THE DRAINED FLUIDS

117 The vehicle hull can be drained by removing the four plugs (Fig 31(1), (3), (4) and (6)) in the hull bottom plate. The bosses into which the plugs screw may be flush with the bottom plate or, if proud, drilled radially flush with the bottom plate to allow drainage. Before replacing the plugs, check that the radial holes, if present, are clear and the plugs are serviceable.

Hull details lubrication

118 Using an oil can sparingly, lubricate the hinges, catches and movable parts of the driver's hatch and seat, commander's cupola and seat, personnel seats, mortar hatch, rear door, track guard hinges, flotation screen struts and other working parts.



430/2006

- | | | | |
|---|--------------------------------|----|--|
| 1 | Stowage locker drain plug | 7 | Gearbox drain access plug |
| 2 | Locker plug | 8 | Driver's compartment drain plug |
| 3 | Load compartment drain plug | 9 | Steering unit drain access plate |
| 4 | Stowage compartment drain plug | 10 | Engine oil drain access plug |
| 5 | Fuel drain valve access plate | 11 | Steering unit oil tank and coolant drain access plug |
| 6 | Escape hatch | | |

Fig 31 Hull drain points

MOUNT, GUN, 7.62 mm, No 3 Mk 1

119 The FV430 Series is fitted for use with General Purpose Machine Gun 7.62 mm L7 (GPMG) using machine gun mount No 3 Mk 1.

120

121 To install the mount, withdraw the pintle-securing pin from the socket, insert the mount and replace the pin. Secure the travelling strut (Fig 32(11)).

CAUTION

EQUIPMENT DAMAGE. To prevent damage to the engine fans, ensure the spent case bin is emptied at the specified intervals

122 During firing operations, it is essential that the spent case bin be emptied before they are completely full and overflowing. Empty cartridge cases and links, which overflow, are liable to enter the engine air louvres and cause damage to the engine fans.

123 The No 3 mount bin should be emptied every 150-200 rounds (3/4-1 belt).

Mount, gun, 7.62 mm, No. 3 Mk 1 for GPMG L7

124 The mount consists of a saddle (Fig 31(16)) welded to a pintle, which fits into the socket on the cupola and a gun cradle (10) suspended between the saddle horns by two pivot pins (5), which are secured by circlips.

125 Welded to the left side of the cradle are clamp brackets which secure the rough alignment sights (2) and (14). The sights can be adjusted then locked in position by tightening the setscrews. Mounted on the rear of the saddle is a spent case bin (9) that is hung on two bosses (6) with the lower part resting against a rubber pad (15) bonded to the rear of the saddle.

126 The GPMG is secured to the cradle by two pins (4) and (12) which are locked in position by two catch plates (3). The rear pin projects to the left forming a handle grip.

127 An ejection chute (7) is bolted to the right side of the cradle to receive and deflect the belt links into the spent case bin, and a deflector plate (8) is bolted underneath the cradle for the cartridge cases.

128 The ammunition box carrier (1) is bolted to the left side of the cradle. The ammunition box is held in position by a lug at the top and a spring catch (17) at the bottom of the carrier.

129 The travelling strut (11) is secured by a pivot pin in a bracket welded to the cupola periscope guard. For travelling, the cradle is secured by engaging the strut in the spring clip (13) at the rear of the cradle.

130 A weatherproof cover fastened by press-studs is provided to encase the gun mount.

Mounting the GPMG

131 Remove the two securing pins and place the GPMG with the ejection opening cover opened, in the cradle and slide the MG along until the holes are aligned. Insert the securing pins and engage the catch plates.

132 When not in use, position the gun to ensure it does not obstruct the opening of the driver's hatch.

Removing the GPMG

133 Release the catch plates and withdraw the securing pins. Remove the GPMG, then replace and secure the pins.

Securing the GPMG for travelling

134 Engage the stirrup shaped end of the support in the spring clip at the rear of the cradle.

Positioning the spent case bin


135 Depress the GPMG and position the bin with the keyhole shaped slots over the bosses (Fig 32(6)), then lower the bin until it is suspended on the bosses and resting against the rubber pad on the saddle.

Removing the spent case bin

136 Depress the GPMG, then lift and withdraw the bin from the mount.

Servicing and maintenance

137 Inspect the mount visually to ensure the components are correctly assembled and secure. Lightly lubricate all movable parts and grease the pintle and pintle socket.



432/131

- | | | | |
|---|----------------------------|----|-------------------|
| 1 | Ammunition carrier | 10 | Cradle |
| 2 | Fore sight | 11 | Travelling strut |
| 3 | Catch plate | 12 | Rear mounting pin |
| 4 | Front mounting pin | 13 | Spring clip |
| 5 | Cradle pivot pins | 14 | Rear sight |
| 6 | Bosses | 15 | Rubber pad |
| 7 | Belt link ejection tube | 16 | Saddle |
| 8 | Spent case deflector plate | 17 | Spring catch |
| 9 | Spent case bin | | |

Fig 32 Mount, gun 7.62mm No 3 Mk 1

CHAPTER 2-3
POWER PACK
CONTENTS

Para

- 1 Introduction
- 4 Engine
 - 5 Accelerator control linkage
 - 6 Crankshaft seals lubrication
 - 7 Checking and topping up the engine oil (WARNING)
 - 8 Changing the engine oil (WARNING)
 - 9 Renewing the oil filter elements
 - 10 Cleaning the engine oil tank breather
- 11 Fuel filter
 - Maintenance
- 12 Cleaning the fuel filter
- 13 Cooling system
 - 18 Checking and topping up the cooling system (WARNINGS)(CAUTION)
 - 19 Draining, flushing, and refilling the cooling system
- 20 Hydraulic fan drive system
 - 22 Checking the hydraulic fan drive tank oil level
 - 23 Draining and refilling the hydraulic system (CAUTION)
 - 24 Cleaning the hydraulic fan drive magnetic filters (CAUTION)
- 25 Air cleaner
 - 30 Changing the air cleaner elements
- Transmission
 - 32 Gearbox
 - 33 Transfer gearbox
 - 34 Checking the gearbox oil level and topping up
 - 36 Changing the gearbox oil (power pack removed)
 - 37 Changing the gearbox oil filter element
 - 38 Changing the gearbox oil (power pack fitted)
 - 39 Gearbox coupling lubrication


Fig

Page

1	Power pack, front right.....	2
2	Power pack, rear left.....	3
3	Steering and accelerator linkage lubricators	5
4	Coolant pump and crankshaft seal's lubrication	6
5	Power pack, access plate removed.....	6
6	Hull bottom plate.....	7
7	Engine oil filter	8
8	Hydraulic fans	9
9	Fuel filter	10
10	Cooling system	11
11	Power pack covers	13
12	Power pack, front right.....	14
13	Magnetic filter	16
14	Air cleaners and radiators.....	17
15	Driver's compartment.....	19
16	Gearbox oil filter.....	20
17	Radio batteries (Maintenance free)	21
18	Gearbox coupling.....	22

INTRODUCTION

1 The power pack (Fig 1) is a complete unit containing all the assemblies required to supply power, both electrical and mechanical, to the vehicle with a gearbox incorporated to give mechanical variation in torque and direction.




432/069

1	Heat exchanger	10	Gearbox coupling
2	Fan controller	11	Engine oil tank
3	Radiator	12	Filler connection
4	Air cleaner	13	Gearbox filter cover
5	Power pack junction panel	14	Gearbox drain plug
6	Injection pump governor	15	Gearbox
7	Coolant pump	16	Gearbox oil filler
8	Exhaust pipe	17	Fuel filter
9	Coolant drain cock	18	Fan motor

Fig 1 Power pack, front right

2 The connections for the electrical circuits, fuel and fire warning system are made at the front of the power pack on the power pack junction (PPJ) (Fig 1 (5)).

3 The power pack is a self-contained unit, which can be removed from, or installed in, the vehicle as a single assembly. It comprises an engine, with its attendant oil tank (11), heat exchanger (1), radiator (3), hydraulic fan assembly and air cleaner (4) with a semi automatic gearbox (GM-Allison TX200-4A) (15) having six forward gears and one reverse gear and a transfer gearbox (Fig 2 (5)).



432/066

1	Magnetic filters	8	Blower
2	Oil filters	9	Drain plug, oil tank
3	Fuel filters	10	Hydraulic fans oil tank
4	Hydraulic fan pump	11	Dust discharge orifice
5	Transverse gearbox	12	Air cleaner, first stage
6	Tacho-generator	13	Air cleaner, second stage
7	Starter motor securing strap		

Fig 2 Power pack, rear left

ENGINE


4 The vehicle is powered by a K60 Mk 4F or Mk 6F engine of Rolls Royce design. The engine is a six cylinder, vertically opposed, two-stroke diesel (compression ignition).

Accelerator control linkage

5 The accelerator cross-shaft bearings are lubricated through the two rear nipples (Fig 3(7)) in a row of five located adjacent to the right steering/brake lever. Lubricate the pivoting parts of the linkage using an oilcan.

Crankshaft seals lubrication


6 This lubrication can only be undertaken when the power pack is removed from the vehicle. Two grease nipples (Fig 4(2)) are fitted on the left side, front of the engine adjacent to the coolant pump. Lubricate by giving one full pumping stroke of the grease gun.



432/061

- | | | | |
|---|-------------------|----|-------------------------------------|
| 1 | Accelerator pedal | 7 | Accelerator cross-shaft lubricators |
| 2 | Quadrant | 8 | Steering linkage lubricators |
| 3 | Toothed washer | 9 | Steering lever return spring |
| 4 | Knurled nut | 10 | Steering/brake levers |
| 5 | Spring | 11 | Fuel stop control pedal |
| 6 | Guard | | |


Fig 3 Steering and accelerator linkage lubricators



432/060

- | | | | |
|---|-------------------------|---|--|
| 1 | Coolant pump vent pipe | 3 | Coolant pump nipple (not fitted to later vehicles) |
| 2 | Crankshaft seal nipples | 4 | Exhaust |

Fig 4 Coolant pump and crankshaft seal's lubrication



432/056

- | | | | |
|---|-----------------------|---|------------------------|
| 1 | Engine oil filler cap | 2 | Gearbox oil filler cap |
|---|-----------------------|---|------------------------|

Fig 5 Power pack, access plate removed

Checking and topping up the engine oil

WARNING

VEHICLE MOVEMENT. THE DRIVER SHOULD NOT LEAVE THE VEHICLE WHEN THE ENGINE IS RUNNING UNLESS THEIR OWN SAFETY IS ENDANGERED

- 7 The procedure for checking and topping up the engine oil is as follows:
 - 7.1 Stand the vehicle on level ground.
 - 7.2 Release the spring catch under the filler cap (Fig 5(1)) and raise the cover.
 - 7.3 Withdraw the dipstick, wipe it, re-insert it ensuring that it goes down fully, then withdraw it again and check for a presence of oil. Replace the dipstick and close the filler cap.
 - 7.4 Start the engine (Chap 2-7 refers) and run it until the coolant temperature is between 90.5 deg C and 93.3 deg C (195 deg F and 200 deg F).
 - 7.5 With the engine idling, re-check the oil level and top up to the full mark on the dipstick if necessary.

Changing the engine oil

WARNING


PERSONAL INJURY. CARE MUST BE TAKEN WHEN DRAINING OILS FROM POWER PACK. THE ENGINE OIL COULD BE HOT AND A DANGER OF SCALDING IS POSSIBLE.

- 8 The procedure for changing the engine oil is as follows:
 - 8.1 This servicing should be carried out when the engine has been started and the engine has run for approximately 5 minutes or movement begins to register on the engine coolant gauge.
 - 8.2 Stand the vehicle on level ground and switch off engine.
 - 8.3 Remove the access plug (Fig 6(6)) from the hull bottom plate.
 - 8.4 Remove the drain plug from the oil tank and allow the oil to drain into a clean suitably sized receptacle. Check the drain plug and washer for serviceability then replace and tighten securely.
 - 8.5 Replenish with fresh oil to the 'full' mark on the dipstick.
 - 8.6 Check and top up the oil Para 7 refers. Stop the engine and replace the access plug in the hull bottom plate.

Renewing the oil filter elements

- 9 This procedure can only be undertaken when the power pack is removed from the vehicle. The procedure for renewing the oil filter elements is as follows:
 - 9.1 Remove nut retainer (Fig 7(16)) and slacken one centre bolt cap nut (1) in the filter head while supporting the filter bowl (4). Lower the bowl carefully so as not to spill the oil.
 - 9.2 Pour the oil into a suitable container for disposal. Withdraw the element (5), the seal (7), the spring (8) and the washers (9 and 10). Dispose of the element in accordance with local regulations.
 - 9.3 Clean all the components thoroughly and inspect for serviceability. Renew the components as necessary.


- 9.4 Fit onto the centre bolt (6) the rubber washer (10) the copper washer (9) the spring (8) and the cork seal (7).
- 9.5 Fit the new element (5) with the radial outlet holes uppermost.
- 9.6 Fill the bowl with clean oil of the correct grade (AESP 2350-T-250-601 refers). Fit the bowl to the head, ensuring it seats correctly. Replace the cap nut (1) and washer (2).
- 9.7 Repeat for the other bowl.



430/2005

- | | | | |
|---|--------------------------------|----|--|
| 1 | Stowage locker drain plug | 7 | Gearbox drain access plug |
| 2 | Locker plug | 8 | Drivers compartment drain plug |
| 3 | Load compartment drain plug | 9 | Steering unit drain access plate |
| 4 | Stowage compartment drain plug | 10 | Engine oil drain access plug |
| 5 | Fuel drain valve access plate | 11 | Steering unit oil tank and coolant drain access plug |
| 6 | Escape hatch | | |

Fig 6 Hull bottom plate



432/062


1	Cap nut	9	Copper washer
2	Copper washer	10	Rubber washer
3	Rubber washer	11	Washer
4	Bowl	12	Bolt retainer
5	Element	13	By-pass valve
6	Centre bolt	14	Valve spring
7	Cork seal	15	Rubber sealing ring
8	Spring	16	Nut retainer

Fig 7 Engine oil filter

Cleaning the engine oil tank breather

10 The procedure for cleaning the engine oil tank breather is as follows:

- 10.1 Open the air inlet louvre (Chap 2-2 refers).
- 10.2 Pull off the breather unit (Fig 8(6)) from the oil filler branch pipe.
- 10.3 Using approved cleaning agent, thoroughly clean the breather and allow it to dry.
- 10.4 Soak the breather in clean engine oil, allow the surplus oil to drain, and then wipe away any excess.
- 10.5 Refit the breather and close the air outlet louvre.



- | | | | |
|---|---|----|---------------------------------|
| 1 | Air cleaner indicator | 7 | Clamp plate |
| 2 | Hydraulic tank filler plug and dipstick | 8 | Firewire |
| 3 | Louvre retaining pin | 9 | Cupola |
| 4 | Clamp plate | 10 | Battery vent |
| 5 | Coolant filler cover | 11 | Lifting eye |
| 6 | Engine oil tank breather | 12 | Engine crankcase breather cover |

Fig 8 Hydraulic fans

FUEL FILTER

11 The main fuel filter (Fig 1(17)) is secured to a bracket welded to the power pack superstructure. An overflow valve is fitted in a pipe from the top of the filter, this is designed to relieve fuel pressure delivered to the fuel injection pump by allowing excess fuel to return to the main tanks. The valve is non-adjustable and, if necessary, is renewed as an assembly.

Maintenance

Cleaning the fuel filter

- 12 The procedure for cleaning the fuel filter is as follows:
- 12.1 Switch both battery switches to OFF and fit the earth spike.
 - 12.2 Remove the power pack access plate (Cap 2-2 Para 39 refers).
 - 12.3 Pack cloth below the filter bowl (Fig 1(17)) or use a plastic bag to collect any fuel, which may spill.
 - 12.4 Unscrew and remove the centre bolt (Fig 9(9)) while supporting the bowl (1).
 - 12.5 Lower the bowl, pour off the fuel, and discard the element (2) in accordance with SOP.
 - 12.6 Thoroughly, clean the bowl and the parts contained in it.


12.7 Examine for serviceability, filter head (3) and the seal in the head against which the bowl seals.

12.8 Examine for serviceability the washer (9) under the head of the centre bolt.

12.9 Using a new element and renewing any unserviceable part reassemble in the reverse sequence. Fill the bowl with fuel before assembling it to the head.

12.10 When assembled, turn the fuel cock to ON, slacken the knurled air bleed screw (7) on the filter head, then switch ON the battery switches and engine switch. Tighten the bleed screw immediately bubble-free fuel is expelled; switch OFF the engine switch.

12.11 Using suitable materials remove any spilt fuel. Replace the power pack access plate and stow the earth spike.



430/20021

1	Bowl	7	Air bleed screw	12	Inlet
2	Element	8	Centre bolt	13	Circlip
3	Head	9	Washer	14	Spring seat
4	Plug	10	Leak 'OFF' connection	15	Spring
5	Air bleed orifice	11	Outlet	16	O Ring
6	Rubber washer				


Fig 9 Fuel filter

COOLING SYSTEM

13 The cooling system (Fig 10) comprises a header tank (3) with filler cap (2) a hydraulically driven fan (1), radiator (4), coolant pump (5), heat exchanger (9), thermostat (7) and drain (6).

14 When the engine is running, coolant is circulated round the cylinders and is then cooled again by being passed through a radiator. Before re-entering the engine it is circulated through a heat exchanger where, dependent on the relative temperatures, it cools or warms the engine oil, gearbox oil, steering unit oil and hydraulic oil for the fan drive.

15 Circulation of the coolant is by a pump. A thermostat fitted in the outlet on the engine causes the fan controller, radiator and heat exchanger to be by-passed while the engine is warming up so that the rise will be more rapid to an efficient working temperature. When this temperature is reached, the control unit in the coolant and fan drive circuits, operates, allowing oil to flow to the fan motors causing the fan to start rotating.



432/485

- | | | | |
|---|-------------------|---|--------------------------|
| 1 | Fans | 6 | Drain |
| 2 | Filler cap | 7 | Thermostat |
| 3 | Expansion Tank | 8 | Hydraulic fan controller |
| 4 | Two pass radiator | 9 | Heat exchanger |
| 5 | Coolant-pump | | |

Fig 10 Cooling System

16 The fans draw air in through the inlet louvres and radiator, round the engine and expel it through the outlet louvres. The control unit varies the fan speed. This is to maintain the engine coolant at an efficient working temperature.

17 The coolant system is drained from the underside of the vehicle. Access to the drain plug is through the steering unit access cover.

Checking and topping up the cooling system

18 The procedure for checking and topping up the cooling system is as follows:

WARNINGS

- (1) **PERSONAL INJURY. DO NOT REMOVE THE COOLANT FILLER CAP WHILE THE ENGINE IS RUNNING. ALWAYS WAIT UNTIL THE TEMPERATURE IS BELOW 93 deg C (200 deg F) BEFORE REMOVING THE COOLANT FILLER CAP OR SEVERE SCALDING MAY RESULT.**
- (2) **TOXIC HAZARD. ANTI-FREEZE IS BOTH TOXIC AND HAZARDOUS. MINIMUM PRECAUTION AFTER USE IS TO WASH THE AFFECTED SKIN AREAS WITH SOAP AND WATER.**
- (3) **HEAVY WEIGHT. THE POWER PACK ACCESS COVER IS EXTREMELY HEAVY. WHEN LIFTING/OPENING THE ACCESS COVER, CONSIDERATION SHOULD BE GIVEN TO THE REGULATIONS GOVERNING THE LIFTING OF HEAVY WEIGHTS.**

CAUTION

EQUIPMENT DAMAGE. Coolant may collect on top of the baffle so that at a glance a false impression of the level can be given.

- 18.1 Turn the handle on the filler cover (Fig 8(5)) to release the locking catch then lift out the cover.
- 18.2 Unscrew the filler cap, which is accessible through the cover aperture.
- 18.3 Add coolant, if necessary, to bring the coolant level up to the level of the radiator baffle plate, (approximately 38 mm (1½ in.) below the filler orifice). Do not overfill.
- 18.4 Replace the cap and cover.

Draining, flushing, and refilling the cooling system

19 The procedure for draining, flushing, and refilling the cooling system is as follows:


- 19.1 Remove the filler cover (Fig 11(4)) and cap.
- 19.2 Remove the access plug (Fig 6(11)) from the hull bottom plate.
- 19.3 Open the steering unit access cover, open the drain cock (Fig 10(6)) situated on the front of the power pack frame to the right of the crankshaft damper.

NOTE

The coolant contains anti-freeze mixture and should be drained in to a clean suitably sized receptacle for reuse.

- 19.4 Remove the receptacle, close the drain cock, and fill the system with clean water. Open the drain cock and, using a hosepipe or container to replenish the draining water, continue flushing until the water that is draining is clean.
- 19.5 Allow the system to drain completely, and then close the drain cock.
- 19.6 Fill the system with coolant and replace the filler cap and cover. If the coolant, which was drained, is to be reused, ensure it is perfectly clean.
- 19.7 Start the engine and run the engine to normal operating temperature.


- 19.8 Stop the engine and re-check the level. Top up if necessary.
- 19.9 Check for leaks. If a leak in the system is found report to REME.
- 19.10 Replace the access plug and close the steering unit access cover.



434/023

- | | | | |
|---|----------------------|----|-----------------------------|
| 1 | Turncatch (open) | 7 | Operator's door stop |
| 2 | Torsion bar tube | 8 | Operator's door catch |
| 3 | Inlet louvre | 9 | Outlet louvre |
| 4 | Coolant filler cover | 10 | Turncatch (closed) |
| 5 | Driver's hatch stop | 11 | Locking pin stowage bracket |
| 6 | Clamp plates | 12 | Locking pin holes |

Fig 11 Power pack covers



432/069

1	Heat exchanger	10	Gearbox coupling
2	Fan controller	11	Engine oil tank
3	Radiator	12	Filler connection
4	Air cleaner	13	Gearbox filter cover
5	Power pack junction panel	14	Gearbox drain plug
6	Injection pump governor	15	Gearbox
7	Coolant pump	16	Gearbox oil filler
8	Exhaust pipe	17	Fuel filter
9	Coolant drain cock	18	Fan motor

Fig 12 Power pack, front right

HYDRAULIC FAN DRIVE SYSTEM

20 The fans (Fig 10(1)) are driven hydraulically and the system comprises a pump (Fig 2(4)), a motor for each fan, a controller unit (Fig 10(8)), and a tank (Fig 2(10)) for the fluid. The fluid is passed through a section of the heat exchanger before being returned to the tank. The fan speed is controlled by coolant temperature and engine speed. The pump is shaft driven from the rear end of the engine. The controller is connected in both the coolant circuit and the hydraulic circuit and operates thermally. The thermostatic element in the controller is immersed in coolant, which, as it gets hot, causes the element to expand and gradually close the controller by-pass valve, which is in the hydraulic circuit.

21 When the engine is started from cold, the pump is rotated and fluid is drawn from the tank and delivered to the circuit. As the controller by-pass valve is almost wide open most of the fluid is returned to the tank via the section of the heat exchanger, so bypassing the fan motors. When the coolant temperature reaches that to which the controller is pre-reset, the expanding element further closes the by-pass valve and more fluid is diverted to the fan motors, which as the pressure builds up, begin to rotate faster. The heat of the coolant continues to close the by-pass causing the speed of the fans to increase until sufficient cooling is obtained to maintain the coolant at the pre-selected temperature.

Checking the hydraulic fan drive tank oil level

NOTE

Loss of fluid should not normally occur, so if the fluid level is low, check the system for leaks before topping up. If a leak in the system is found report to REME.

22 The procedure for checking the hydraulic fan drive tank oil level is as follows:

22.1 Open the outlet louvre (Fig 11(9)).

22.2 Unscrew the filler plug (Fig 8(2)) and check that the breather holes are clear.

22.3 Withdraw the dipstick, wipe it, re-insert it, then withdraw it again, and check the fluid level indicated.

22.4 If the level is low, new hydraulic oil (AESP 2350-T-250-601 refers) should be added, to bring the level up to the 'MAX' mark on the dipstick.

22.5 Replace the dipstick and filler plug and close the louvre.

Draining and refilling the hydraulic system

23 This procedure can only be undertaken when the power pack is removed from the vehicle. The procedure for draining and refilling the hydraulic system is as follows:

23.1 Arrange a suitably sized container under the reservoir to receive the draining fluid then unscrew the drain plug (Fig 2(9)) until the fluid is flowing freely. The flow will continue until the lower tank is drained.

23.2 Remove the plug completely and allow the upper tank to drain. To accelerate the flow, remove the magnetic filters (1), (Para 24 refers) taking care to prevent entry of dust and dirt into the system.

CAUTION

EQUIPMENT DAMAGE. Always stand the filter on the brass plug head; never place it on its side, especially on steel or iron as this may cause loss of magnetism.

23.3 When the tank has completely drained, check that the joint washer is serviceable, and then refit the drain plug. Clean and refit the magnetic filters, (para 24 refers).

23.4 Refill the system with new hydraulic oil (AESP 2350-T-250-601 refers) through the filler (Fig 8(2)) of the reservoir up to the 'MAX' mark on the dipstick.

23.5 Run the engine for several minutes, re-check the fluid level, and top up as necessary. Check for leaks and report to REME if any found.

Cleaning the hydraulic fan drive magnetic filters

24 This procedure can only be undertaken when the power pack is removed from the vehicle. The procedure for cleaning the hydraulic fan drive magnetic filters is as follows:

24.1 Unscrew each filter from the top of the oil tank, covering the holes immediately to stop any dust or dirt getting into the tank.

CAUTION


EQUIPMENT DAMAGE. Always stand the filter on the brass plug head; never place it on its side, especially on steel or iron as this may cause loss of magnetism.

24.2 Holding the brass plug head (Fig 13(4)), remove the nut (1) and shake proof washer retaining the filter cage (2).

24.3 Withdraw the filter cage.

24.4 Wash the components thoroughly in an approved cleaning agent and wipe them clean.

24.5 Reassemble in the reverse sequence.



432/067

1 Nut
2 Filter cage

3 Sealing washer
4 Plug head

Fig 13 Magnetic filter

AIR CLEANER

25 The air supply to the engine is delivered via a two-stage air cleaner.

26 The first stage of the air cleaner (Fig 2(12)) is a cyclone type, which extracts the heavier particles of dirt. The particles fall to the bottom of the first stage compartment and are blown out of the compartment (11) by a stream of air by-passed from the blower unit.

27 The air supply passes from the first stage to a chamber (13) containing two replaceable paper elements by which the remaining dust is extracted.

28 When the second stage elements start to become choked and requires cleaning, an indicator unit (Fig 8 (1)) mounted on the fan cowling, which gives a visual warning. When the restriction has built up sufficiently, the green sleeve is drawn into the indicator body exposing the red coloured part of the indicator and the elements must be replaced or cleaned. When the elements have been replaced or cleaned, reset the indicator by pressing the rubber button on the end of the unit. If the red portion again covers the green as soon as the engine is run report to REME.


Changing the air cleaner elements

29 The procedure for changing the air cleaner elements is as follows:

- 29.1 Open the inlet louvre (Chap 2-2 refers).
- 29.2 Unscrew the captive wing nuts (Fig 14(8)), and then lift off the covers (7) from the secondary stage chamber.
- 29.3 Unscrew the captive wing nuts (3), and then lift out each element by the rings provided and discard the elements; should replacement elements not be available, the vehicle is to be sentenced 'VOR'. Under no circumstances are the filters to be shaken or banged to remove debris and replaced. Unserviceable filters must be discarded.
- 29.4 Insert each new element (or cleaned ones) and secure them with the wing nuts; replace the covers, ensuring that the rubber seals are undamaged and secure the wing nuts.
- 29.5 Close the air inlet louvre.
- 29.6 Open the outlet louvre (Fig 11(9)) and reset the air cleaner indicator (Fig 8(1)), then close the louvre.

NOTE

If the elements have been reused, replacement elements must be obtained and fitted as soon as possible.



432/068a

- | | | | |
|---|-------------------------|---|------------------|
| 1 | Element securing bolt | 5 | Radiator |
| 2 | First stage air cleaner | 6 | Air inlet louvre |
| 3 | Captive wing nut | 7 | Cover |
| 4 | Second stage element | 8 | Captive wing nut |

Fig 14 Air cleaners and radiator

TRANSMISSION

Gearbox

30 The vehicle is fitted with an Allison TX200-4A, hydraulically operated, semi automatic gearbox (Fig 1(15)). It comprises a 3-element torque converter, with an automatic lock up clutch, epicyclic gearing and speed range clutches.

31 Six forward speed ranges and one reverse range is manually selected, automatic gear changes take place in each forward speed range.

32 The torque converter is a hydraulic coupling used to replace a conventional clutch. It provides an infinite variation in drive, from full slip to 1:1 drive.

Transfer gearbox

33 The purpose of the transfer gearbox (Fig 2(5)) is to transfer the output of the engine across the rear of the pack to the input of the gearbox. It provides, through a dog clutch, a simple means of disconnecting the engine from the transmission to make starting easier in cold weather, and provides a power take off if required.

Checking the gearbox oil level and topping up

34 The procedure for checking the gearbox oil level and topping up is as follows:

34.1 **Cold check** Open the gearbox filler access cover (Fig 14(1)) on the power pack compartment partition sill and open the hinged filler cap (Fig 5(2)), withdraw the dipstick, wipe it, re-insert it, withdraw it again and check to ensure there is sufficient oil to allow the engine to be started. The 'safe to start' level is approximately 25.4 mm (1 in.) above the 'SAFE RANGE' zone upper mark on the dipstick.

34.2 **Hot check** Drive the vehicle for approximately 5 km (3 miles) ensuring that all gears, including reverse, are selected.

34.2.1 When the gearbox oil temperature reaches 82 deg C (180 deg F) that is indicated by a yellow line on the gearbox temperature gauge (AESP 2350-T-250-821 Misc Instr No 1/15), stop the vehicle on level ground.

34.2.2 Move the gear selector lever to neutral and run the engine at 2,000 rev/min for 15 seconds to purge the air from the gearbox lubrication system.

34.2.3 Reduce the engine speed over a 4 second period to 800 rev/min.


34.2.4 Wait one minute with the engine idling at 800 rev/min, then with a temperature gauge reading of 82 deg C (180 deg F), check the gearbox oil level reading on the dipstick. The ideal level is in the centre of the 'SAFE RANGE' zone but if it is anywhere within the zone the vehicle can be used safely.

NOTE

Do not rush the check; the oil level will remain stable for approximately 3 minutes.

34.2.5 If the oil level is outside the 'SAFE RANGE' zone, the vehicle must not be run and REME informed.

35 Between checks, when running the vehicle, observe the gearbox temperature gauge at frequent intervals and ensure that the temperature is within the normal range 82 deg C - 105 deg C (180 deg F - 220 deg F). If the temperature should rise to 121 deg C (250 deg F) indicated in red on the gearbox temperature gauge (AESP 2350-T-250-821 Misc Instr No 1/15), stop the engine and REPORT to REME.



1 Gearbox filler access cover

Fig 15 Driver's compartment

Changing the gearbox oil (power pack removed)

36 The procedure for changing the gearbox oil with the power pack removed, is as follows:


- 36.1 Place in position a suitable sized container to collect the oil. Remove the gearbox drain plug (Fig 1(14)) from the bottom end of the gearbox filler pipe and allow the oil to drain.
- 36.2 When oil has finished draining, change the oil filter element (see Para 37). Check that the washer and plug are serviceable and replace.
- 36.3 Refill the gearbox to one inch above the 'SAFE RANGE' zone upper mark on the dipstick.
- 36.4 Check and top up if necessary as in Para 34

Changing the gearbox oil filter element

37 The procedure for changing the gearbox oil filter element is as follows:

- 37.1 Place beneath the end cover, (Fig 16(1)) a suitable container or sufficient cloth to absorb any oil that may be present in the element housing.
- 37.2 Release the filter end cover retaining strap (5) and swing it to one side. Do not remove the nut from the bolt (6).
- 37.3 Remove the filter end cover (1).
- 37.4 Withdraw the element retainer (2), which positions the element.
- 37.5 Withdraw the element (4) and dispose of in accordance with local regulations.
- 37.6 When all oil has drained from inside the filter housing, clean the housing and the parts removed.

- 37.7 Inspect the parts and exchange, any which are not serviceable.
- 37.8 Insert the new element in the housing ensuring that the inner end is correctly located. This can be done by moving the element up and down and crosswise until it is felt to seat correctly.
- 37.9 Holding the element in position fit the element retainer (2) with its seal ring (3) fitted.
- 37.10 Replace the end cover, refit, and tighten the end cover-retaining strap.



432/070


- | | | | |
|---|------------------|---|---------------------------|
| 1 | End cover | 5 | End cover retaining strap |
| 2 | Element retainer | 6 | Bolt |
| 3 | Seal ring | 7 | Seal ring |
| 4 | Filter element | | |

Fig 16 Gearbox oil filter

Changing the gearbox oil (power pack fitted)

- 38 The procedure for changing the gearbox oil with the power pack fitted, is as follows:
- 38.1 Ensure the oil is still warm after the vehicle has been run.
- 38.2 Remove the access plug (Fig 6(7)) from the bottom plate and place a suitable receptacle beneath the access to collect the draining oil. Slide the driver's seat clear of the slides (see Chap 2-2).
- 38.3 Remove the two bolts securing the driver's seat base frame at the rear, and tilt it fully forward.
- 38.4 Ensure the radio battery switched to OFF.
- 38.5 Slacken the two nuts on the battery clamp bolts, (Fig 17(5)) securing the battery clamp bar and remove the bar (6).
- 38.6 Disconnect the cable from the negative terminal (2) on the battery, carefully lift the rubber cover from the positive terminal to obtain access to the connector and then disconnect. Similarly, disconnect the battery inter-connector from one of the terminals.

- 38.7 Withdraw the flexible vent tubes from the batteries and carefully lay the tube assembly (3) to one side.
- 38.8 Lift out the batteries then remove the glass fibre container.
- 38.9 Remove the access plate (9) from the power pack compartment division plate.
- 38.10 Remove the filter element; Para 37 refers.
- 38.11 Replace the components in the reverse sequence.
- 38.12 Refill the gearbox to 25.4mm (one inch) above the 'SAFE RANGE' zone upper mark on the dipstick.
- 38.13 Check and top-up if necessary as in Para 34.




430/20087

- | | | | |
|---|-----------------------------|----|------------------------------|
| 1 | Seat frame | 7 | Container housing frame |
| 2 | Negative terminal | 8 | Container |
| 3 | Vent tube assembly | 9 | Access plate, gearbox filter |
| 4 | Rubber cover | 10 | Footrest bracket |
| 5 | Battery clamp bolt | 11 | Seat bracket |
| 6 | Battery clamp bar (removed) | 12 | Inter-connector |

Fig 17 Radio batteries (Maintenance free)

Gearbox coupling lubrication

39 Two lubricating nipples (Fig 18(2)) are fitted to the coupling, one on each universal joint. Lubricate using a grease gun until grease exudes from the relief valves.



432/071

- | | | | |
|---|---------------------|---|------------------|
| 1 | Gearbox | 3 | Gearbox coupling |
| 2 | Lubricating nipples | 4 | Engine oil tank |

Fig 18 Gearbox coupling

CHAPTER 2-4
FINAL DRIVE, SUSPENSION AND TRACKS

CONTENTS

Para

- Introduction
- 1 General
- 2 Vehicle tools
- 3 Final drive
- 4 Checking and topping up the final drive oil level
- 5 Changing the final drive oil
- 6 Final drive hub lubrication
- 7 Suspension (WARNING)
 - Hydraulic Lockout System
- 8 Suspension units
- 10 Road wheel hubs
- 11 Axle arm bearing
- 12 Shock absorbers
- 13 Road wheels
- 14 Road wheel nuts (CAUTION)
- 16 Raising a road wheel using the axle arm-jacking strut (WARNING)
- 17 Removing the axle arm-jacking strut and lowering the road wheel (WARNING)
- 18 Torsion bars
- 19 Track adjusters
- 21 Checking the track adjuster
- 22 Lubrication of the track adjusters
- 23 Guide rollers
- 24 Tracks
 - 27 Track inspection (WARNINGS)
 - 32 Track tension
 - 33 Checking the track tension
 - 34 Adjusting the track tension
 - 36 Breaking and removing a track (WARNINGS)(CAUTION)
 - 37 Moving the vehicle with one track removed
 - 38 Replacing a track
- Steering unit
- 39 Steering unit
 - 41 Checking the oil level and topping up
 - 42 Changing the oil
 - 43 Cleaning the breather
 - 44 Steering/brake levers (WARNING)
 - 46 Steering linkage lubrication

Fig

Page

1	Final drive and suspension layout	3
2	Final drive sprocket.....	4
3	Suspension unit	5
4	Shock absorber / lock out strut	6
5	Jacking strut.....	8
6	Track adjuster	9
7	Rubber bushed and padded track	10
8	Track splitting / joining	13
9	Attaching track rope and using sprocket as a capstan.....	15
10	Front of vehicle	17
11	Steering brake linkage.....	17
12	Steering lever cross-shaft lubricator.....	18
13	Steering and accelerator linkage lubricators	19/20

INTRODUCTION

General

1 This chapter describes the operation and maintenance tasks required on the final drive, suspension and tracks. A schematic layout of the final drive and suspension system is shown in Figure 1.

Vehicle tools

2 Vehicle tools associated with the final drive, suspension and tracks for this vehicle are listed in AESP 2350-T-250-741.

FINAL DRIVE

3 Drive from the power pack is transmitted to the track driving sprockets through the steering box to the couplings (Fig 1(2,3 and 4)) and final drives (1 and 5). The final drives are reduction gearboxes and their casings serve as a mounting for the gear assemblies, and as a reservoir for oil to lubricate the gears and bearings. Each casing is provided with a filler/drain plug (Fig 2(1)) to enable oil level filling, draining and checking and a lubricating nipple (2) in the face of each hub provides the means to feed grease into the space between the final drive outer casing and the labyrinth a lubricator. The RH unit drives the speedometer. It should be noted that the differences between the FV432 and FV434 is the Final Drives (Ratio), Hydraulic Lockouts (To stabilise the vehicle during crane operation) and the number of track links (AESP 2350-T-251-302 refers).


Checking and topping up the final drive oil level

4 The procedure for checking and topping up each final drive oil level is as follows:

4.1 With the vehicle on a level standing, clean the area around the filler plug (Fig 2 (1)) and then remove the filler plug from the top of the elbow on the casing.

4.2 Check that the oil level is up to the bend of the elbow. Add oil if necessary to the correct level. Allow sufficient time for the oil to find its true level (AESP 2350-T-250-601 refers).


4.3 Replace the filler plug.



434/172

- | | | | |
|---|-----------------------------|----|--------------------|
| 1 | LH Final drive | 8 | Axle arm |
| 2 | Muff Coupling | 9 | Lock out strut |
| 3 | Muff Coupling | 10 | Torsion bars |
| 4 | Half shaft Axle arm housing | 11 | Idler Arm |
| 5 | RH Final drive | 12 | Track adjuster arm |
| 6 | Axle arm housing | 13 | Road wheels |
| 7 | Anchor block | 14 | Power Pack |
| | | 15 | Left sprocket |

Fig 1 Final drive and suspension layout



432/074

1 Filler plug

2 Lubricating nipple

Fig 2 Final drive sprocket

Changing the final drive oil

- 5 The procedure for changing the oil in each final drive is as follows:
- 5.1 Park the vehicle on a level standing.
 - 5.2 Clean the area round the filler plug, and then remove the plug (Fig 2(1)) from the top of the elbow on the casing.
 - 5.3 Place a suitable receptacle under the drain plug, remove the plug and allow the oil to drain.
 - 5.4 When the oil has completely drained, replace the drain plug and washer after checking for serviceability. Tighten securely.
 - 5.5 Fill through the filler elbow until the oil level is up to the bend in the elbow. Allow sufficient time for the oil to find its true level (AESP 2350-T-250-601 refers).
 - 5.6 Replace the filler plug.

Final drive hub lubrication

- 6 A lubricating nipple (Fig 2(2)) in the face of each hub provides the means to feed grease into the space between the final drive outer casing and the labyrinth. Grease (AESP 2350-T-250-601 refers) should be injected until clean grease can be seen coming from the inner end of the hub.

SUSPENSION**WARNING**

SAFETY HAZARD. BEFORE PERSONNEL ARE ALLOWED UNDERNEATH, THE VEHICLE IS TO BE PARKED ON FIRM LEVEL GROUND WITH THE PARKING/STEERING BRAKE FULLY APPLIED, THE ENGINE STOPPED, AND THE VEHICLE SECURED AGAINST ANY MOVEMENT.

- 7 Each side of the vehicle is supported on each side by five suspension stations (Fig 3). Each station comprises of a transverse torsion bar (Fig 1(9)) and on trailing axle arm suspension arrangement (8), carrying twin rubber tyred road wheels (12). Each track forms a continuous flexible surface for the vehicle to run on, with the drive transmitted to the track by a sprocket (14) fitted to the final drive (1 and 5). The sprocket (14), two support/guide rollers, and idlers wheels on a track tensioner assembly (11) support the top-run of the track.

Hydraulic Lockout System


NOTE

The hydraulic lockout system for the FV434 is covered in Chapter 3 of this publication.

Suspension units

8 The inner suspension units (Fig 3) comprise of an axle arm (8), shock absorber (13), road wheel hub (3), a pair of wheels, bump stop (2) and a guide roller. The axle arm's upward travel is limited by a rubber/steel bump stop. Each pair of wheels is mounted on the road wheel hub, which revolves on a stub axle. The axle arm pivots in two bushes in a bracket welded to the hull. The pivot tube of the axle arm is connected to a torsion bar, which extends across the hull to a fixture on the axle arm bracket on the opposite side.

9 The front and rear wheel stations are fitted with telescopic hydraulic shock absorbers, which have a built in lock out device (Fig 4), the shock absorbers operate as normal suspension dampers when the vehicle is travelling, but on the introduction of a controlled pressurized fluid supply from the crane hydraulic system, the dampers are locked rigid to permit crane operation without the vehicle tilting.



430/20085

- | | | | |
|---|------------------------------------|----|------------------------------------|
| 1 | Retaining plate | 6 | Positioning arrow |
| 2 | Torsion bar access plug, inner end | 7 | Filler level plug |
| 3 | Guide roller lubricating nipple | 8 | Wheel locating pins |
| 4 | Bump stop | 9 | Axle arm |
| 5 | Road wheel hub | 10 | Torsion bar access plug, outer end |

Fig 3 Suspension unit

Road Wheel hubs

10 Each road wheel hub is lubricated by means of a filler/level plug (Fig 3(5)). The track adjusting wheel hubs are similarly lubricated. The plug is brought to the correct position for filling by turning the hub to bring an arrow (4), cast on the face of the hub, to the 12 o'clock position.


- 10.1 With the arrow in the 12 o'clock position, remove the plug.
- 10.2 Add oil to the level of the plughole (AESP 2350-T-250-601 refers).
- 10.3 Check that the plug and washer are serviceable, then replace and tighten the plug.

Axle arm bearings

11 The axle arm bearings are lubricated through two nipples on either side of each axle arm housing. Inject 15 shots of grease with a grease gun into each nipple (AESP 2350-T-250-601 refers).

Shock absorbers

12 Check hose connections for tightness and hoses for damage. Examine gaiter (Fig 4 (4)) for leaks and security of hose clips (2).



434/078

- | | | | |
|---|--------------------------------|---|---------------|
| 1 | Hose clips | 4 | Gaiter |
| 2 | Shock absorber / lock out unit | 5 | Breather hose |
| 3 | Pressure hose | | |

Fig 4 Shock absorber / lock out strut

Road wheels

13 The road wheels comprise of twin rubber tyred wheel discs bolted on to hubs. The individual wheels are fully interchangeable.

NOTE

A road wheel pair may be jacked up using either the hydraulic jack or the jacking strut provided.

Road wheel nuts

CAUTION

EQUIPMENT DAMAGE. If for any reason the wheel nuts have been slackened and re-tightened, they must be checked for tightness daily for the next three days that the vehicle is operated. The wheel nuts must be tightened by one man using the torque wrench supplied for this purpose. Pipes, bars etc must not be used to increase the leverage, as the torque must not exceed 163 nm (120 lb/ft).

14 The tightness of each nut securing the road wheels must be checked or tightened in a diagonal sequence (AESP 2350-T-251-601 refers).

Raising a road wheel using the axle arm jacking strut

15 To raise wheels using a jacking strut (Fig 5), proceed as follows:

15.1 Halt vehicle on firm level ground.

15.2 Apply steering/parking brake and stop engine.

15.3 Locate the jacking strut (Fig 5(5)) (AESP 2350-T-250-741 refers), using the end with the larger radius, in the vee formed between the distance piece (Fig 6(1)) and the axle arm (3), with the lug fitted within the wheel rim. Position the track end of the strut on the track in line with the sprocket tooth slots (6). The strut can be inclined towards the front or rear of the vehicle.

15.4 Check that all personnel are clear of the vehicle.

15.5 Start engine and select reverse gear range.

15.6 Release steering/parking brake and ease vehicle rearward, until strut is vertical (Fig 6(5)).

15.7 Apply steering/parking brake fully and stop engine.

15.7 Apply parking brake and stop engine.

16 To remove and refit a pair of road wheels, proceed as follows:

16.1 Park vehicle on firm level ground, fully apply parking brake and stop engine.

16.2 Slacken nuts of road wheel to be removed, one complete turn.

16.3 Jack up wheel station as detailed in Para 15.


16.4 Remove wheel nuts and remove wheels from hub, taking care not to damage the wheel studs.

16.5 Fit road wheels using the reverse of removal sequence after making sure that mating faces of wheels, hub, studs and nuts are clean and undamaged.

16.5 Lower the wheel station as detailed in Para 17 and with wheels in lowered position, torque road wheel nuts in diagonal sequence to 163Nm (120lb/ft).

Removing axle arm jacking strut and lowering the road wheel

- 17 To lower wheels using a jacking strut, proceed as follows:
- 17.1 Check that all personnel are clear of vehicle.
 - 17.2 Start engine and select lowest forward gear range.
 - 17.3 Release parking brake and ease vehicle forward until jacking strut is free of load.
 - 17.4 Stop vehicle, apply parking brake and stop engine.
 - 17.5 Remove jacking strut.



432/076

- | | | | |
|---|---------------------|---|----------------------|
| 1 | Axle distance piece | 4 | Mandrel socket |
| 2 | Road wheel | 5 | Jacking strut |
| 3 | Axle arm | 6 | Sprocket tooth slots |

Fig 5 Jacking strut

Torsion bars

18 Check for broken torsion bars by viewing the road wheel tyre bulge where it contacts the track. If the torsion bar has broken, the wheel will not be sharing the vehicle load and a bulge will not occur. Lifting the arm by means of a crowbar will confirm the breakage.


TRACK ADJUSTERS

19 Adjustment of the tension of each track is achieved by moving the idler wheels rearward (to increase tension) and forward (to decrease tension) by use of a hydraulic ram.

20 Track tension is altered by the track adjuster (Fig 6). The adjusting movement is effected by a hydraulic ram. The ram is extended by pumping grease through a nipple (15) in the head and retracted by unscrewing a relief screw (14), which is adjacent to the nipple. A lug welded to the rear of the stub axle extension contacts the adjuster bracket and acts as a limit stop when the full effective travel of the ram plunger has been reached.

Checking the track adjuster

21 Check the tightness of the tensioner bracket bolts and the track adjusting wheel nuts (AESP 2350-T-251-601 refers). If for any reason the nuts securing the adjusting wheel discs have been slackened, they must be tested for tightness and tightened if necessary. They should then be tightened daily for the next three days that the vehicle is operated.



432/077

- | | | | |
|---|---------------------|----|-----------------------|
| 1 | Locating plates | 9 | Hub cap |
| 2 | Ram plunger | 10 | Hub positioning arrow |
| 3 | Stub axle extension | 11 | Lubricating nipple |
| 4 | Adjuster bracket | 12 | Trunnion |
| 5 | Hull sideplate | 13 | Ram cylinder |
| 6 | Cranked axle arm | 14 | Relief screw |
| 7 | Wheel locating pins | 15 | Nipple, extending ram |
| 8 | Filler/level plug | | |

Fig 6 Track adjuster

Lubrication of the track adjusters

22 One lubrication nipple (Fig 6(11)) is provided on each track adjuster pivot arm. When injecting grease into the pivot arm bearing do not use excessive force as the end faces are sealed. For lubrication of the track adjuster wheel hubs, see Para 10.

GUIDE ROLLERS


23 The double rubber tyre guide roller assemblies are fitted with a lubrication nipple (Fig 3(1)) on the hubcap. Grease should be injected until it exudes from the labyrinth cover at the inner face of the roller.

TRACKS

24 New tracks each comprise ninety-one rubber-padded links connected by hexagonal pins (Fig 7 (6)). A polyurethane washer (7) is fitted under each pad to provide a firm but resilient seating. When re-padding, the washers should be re-used, unless cracked or broken, as they are designed to last the life of the track. Four spare links are carried in the vehicle stowage. Each link weighs approximately 8.3 Kg (18.3 lbs).

25 There must be the same number of links in each track. When removing tracks always renew sprockets if they are at all worn. The tracks must be fitted so that the spud (2) face of each link is trailing as the links pass over the sprockets. Replace tracks in pairs.

26 When driving on a straight course and the vehicle does not maintain a reasonably straight course, the cause is probably in the tracks (see Para 27 to 31). If in any doubt report to REME.



432/078

- | | | | |
|---|--|---|---------------------|
| 1 | Hexagon sleeves in rubber bushes | 5 | Guide horns |
| 2 | Spuds | 6 | Link pins |
| 3 | Rubber pads | 7 | Polyurethane washer |
| 4 | Nuts and spring washers securing rubber pads | | |

Fig 7 Rubber bushed and padded track

Track inspection

WARNING

(1) **SAFETY HAZARD. PERSONNEL INSPECTING TRACKS MUST REMAIN IN SIGHT OF THE COMMANDER. THEY ARE NOT TO STAND BEHIND THE VEHICLE WHILST IT IS IN MOTION. THEY ARE TO RETAIN VISUAL CONTACT WITH THE COMMANDER. THEY ARE NOT TO MAKE PHYSICAL CONTACT WITH ANY PART OF THE TRACK AND RUNNING GEAR WHILST THE VEHICLE IS IN MOTION.**

(2) **SAFETY HAZARD. THE COMMANDER MUST ALWAYS REMAIN IN SIGHT OF THE DRIVER AND MAINTAIN VISUAL CONTACT WITH PERSONNEL INSPECTING THE TRACKS. SHOULD ANY OF THE PERSONNEL DISAPPEAR FROM VIEW OR NOT RESPOND TO HIS COMMANDS HE IS TO IMMEDIATELY INSTRUCT THE DRIVER TO HALT THE VEHICLE.**

(3) **SAFETY HAZARD. THE DRIVER MUST HALT THE VEHICLE IF THE COMMANDER GOES OUT OF HIS SIGHT.**

(4) **SAFETY HAZARD. IT IS NOT SAFE PRACTICE TO HAVE BOTH TRACKS REMOVED AT THE SAME TIME, AS NO VEHICLE BRAKING IS AVAILABLE. IF TWO TRACK REMOVALS IS UNAVOIDABLE SECURE THE VEHICLE BY CHOCKING THE ROAD WHEELS BEFORE SPLITTING THE SECOND TRACK.**

(5) **SAFETY HAZARD. BEFORE PERSONNEL ARE ALLOWED UNDER THE VEHICLE, THE STEERING/PARKING BRAKE MUST BE FULLY APPLIED, THE ENGINE STOPPED AND THE VEHICLE SECURED TO PREVENT MOVEMENT.**

27 Ensure that the path of the vehicle is clear of obstructions and stand at the front of the vehicle facing the inside of one track. Signal the driver to reverse.

28 While the vehicle is being driven in reverse inspect the track:

28.1 For faulty or bent pins.

28.2 Check that the pads are secure and there is sufficient rubber to prevent the metal link contacting the ground. Torn or missing pads must be replaced, when replacing pads ensure that the polyurethane washer is fitted under each pad.

28.3 Ensure bushes do not protrude from the lugs. Check for collapsed or badly worn bushes, this is indicated by links sagging on the top run of the track.

28.4 Check for any signs of cracking on the links. Cracks normally appear at either side of the lugs.

29 Stop the vehicle. Stand at the side of the vehicle facing the outside of the track.

30 Signal the driver to drive slowly forward and inspect the outside of the track similarly to inspecting the inside of the track. Halt the vehicle.

NOTE

On new tracks, the pads are liable, after supporting the vehicle weight, to bed down and loosen. It is necessary therefore, that during the first 80 km (50 miles) running of a new track, the stud nuts securing the pads should be checked frequently for tightness.

31 Repeat operations in Para 28 to 31 for the other track.

Track tension

32 The tension of the tracks must be set to 25.4 to 38.1 mm (1 to 1-1/2 in.) sag (clearance) midway between the guide rollers with no slack under the sprocket or track-adjusting wheel. The adjustment must be carried out so that there is the correct clearance when the vehicle is fully laden. Both tracks must be adjusted to the same tension.

Checking the track tension

33 The procedure to check the track tension is as follows:

33.1 With the vehicle on hard level ground, slacken the six nuts securing the rear track guard and lift the guard off by allowing the clearance holes to pass over the nuts and washers.

33.2 Slacken the five nuts securing the front guard and similarly remove.

33.3 Slacken the securing bolt on either side of the rear track shield and raise the shield.

33.4 Start the engine and engage reverse gear. Release the steering/parking lever for the track that is to be checked.

33.5 Gently accelerate the engine and immediately the vehicle starts to turn, decelerate to stop the drive, re-apply the brake/steering lever, and engage the parking control to prevent the sprocket being turned forward by the track resettling. Stop the engine.

33.6 Check for clearance mid-way between the two guide rollers. This can be measured by using a length of string stretched taut along the track.

33.7 If necessary, adjust the track tension (Para 34 and 35).

33.8 Repeat for the other track.

33.9 Replace the track shield.

NOTE

Before replacing the guards, check that the studs are serviceable and that the guards are not damaged or distorted.

33.10 Replace the track guards in the reverse sequence and secure.

Adjusting the track tension

34 If the track is to be tightened, inject grease with a grease gun through the nipple (Fig 6(15)) in the head of the ram cylinder (13) until the tension is correct.


35 If the track is to be slackened, unscrew the relief screw (14) until grease escapes through the drilling in the screw. Re-tighten the screw securely when the track has slackened sufficiently. If necessary, gather any slack from under the track adjusting wheel and recheck.

Breaking and removing a track

36 The procedure for breaking and removing a track is as follows:

36.1 Tracks are normally broken between the sprocket and first road wheel as this position facilitates the operation.

36.2 Drive the vehicle onto hard level ground, bringing the track pin to be removed into position between the sprocket and first road wheel. Apply the steering/brake levers and apply the parking controls. Stop the engine.



430/20053

- | | | | |
|---|---|---|--------------------|
| 1 | Track clamps in position | 3 | Drive pin |
| 2 | Track pin - to be removed (splitting) or fitted (joining) | 4 | Sleeve/handle tool |

Fig 8 Track splitting/joining

36.3 Fit the track lifting and pulling adaptor (AESP 2350-T-250-741 refers) onto the protruding end of the dowel pin securing each guide roller spindle.

36.4 Fully slacken the track by means of the adjuster (Fig 6(14)). Fit the track clamps (AESP 2350-T-250-741 refers) on the inside of the track into the sprocket holes in the track links either side of where the track is to be 'broken'. Tighten the screws to relieve the tensional load from the track pins held in the clamps. Continue tightening until an angle of 10 deg is obtained between the links on the pin to be removed. At this angle, the torsional load on the bushes will be relieved. Remove the nut from the outer end of the track pin. Drive out the track pin using the drifts (AESP 2350-T-250-741 refers). Take care not to burr the end of the non-hardened track pin. Slacken and remove the clamps then lower the end of the track to the ground.

36.5 Fit the track lifting and pulling adaptor (AESP 2350-T-250-741 refers) to the end of the top run of the track and attach a rope. Start the engine, engage reverse gear, apply the brake on the opposite side to the broken track and drive the vehicle as slowly as possible, steadying the end of the track with the rope. Before the track is clear of the adjusting wheel, stop the vehicle, apply the steering/brake lever, and stop the engine. Pull the track clear while controlling it with the rope, if necessary taking a bight around the sprocket.

36.6 Lay out the track and remove the adaptor and rope.

Moving the vehicle with one track removed

37 Start the engine and put the gear control lever to 1-2 range or reverse as required. Release the brakes, gently accelerate the engine to take up the drive and apply either steering lever. If the steering brake on the same side as the 'broken' track is applied, the vehicle will move quickly, if the other brake is applied, the vehicle will move slowly.

Replacing a track

38 The procedure for replacing a track is as follows:

38.1 Before fitting a track, lay it out beneath the vehicle and check for bend. If the bend exceeds 100 mm (4 in.) over the track length, the faulty link(s) must be replaced.

38.2 Fit the track-pulling adaptor refers and rope (AESP 2350-T-250-741 refers) to the end of the track, pass the rope over the support rollers and take one turn round the sprocket hub. A member of the crew will be required to keep the rope taut. (See Fig 9)

38.3 Start the engine and put the gear control lever in the 1-2 range. Release the steering/brake levers and gently accelerate the engine to take up the drive. Apply the steering/brake lever to the unbroken track so that the vehicle will move forward slowly. Using the hub as a windlass, draw the track over the support rollers and into engagement with the sprocket.

38.4 Stop the vehicle and remove the rope from the hub.


38.5 Continue to drive the vehicle forward, working the slack of the track over the sprockets until the ends of the track are close enough together to fit the track clamps. Stop the vehicle and switch 'OFF' the engine. Support the ends of the track with a crowbar and fit the clamps (AESP 2350-T-250-741 refers).

38.6 Tighten the clamps taking care that as the lugs and recesses of the links come into mesh the ends of the bushes are not damaged, and then continue tightening until the hexagonal liners in the bushes align. This can be checked by sighting through.

38.7 Fit a lead pin to one end of a track pin and a striker to the other.

38.8 Insert the greased pin ensuring that it is pushed in as far as the second lug before tapping home carefully with a hammer. Remove the lead pin and striker, fit a nut to each end of the pin, and then remove the track clamps. Remove the track-fitting tool.

38.9 Adjust the track to the correct tension (Para 32 refers).



1 Track lifting and pulling adaptor used to attach track rope to track broken end

2 Using sprocket as capstan for track rope

Fig 9 Attaching track rope and using sprocket as capstan

432/492

STEERING UNIT

Steering unit

39 The steering unit directs the power from the pack to the left and right sides of the vehicle through a crown wheel and pinion.

40 The unit contains a spur gear differential, which can be controlled by adjustable brakes, which when applied individually, varies the speed of the outputs thus causing the vehicle to steer.

Checking the oil level and topping up

41 The procedure for checking the steering unit oil level and topping up, is as follows:

41.1 Stop the vehicle on level ground.

41.2 Remove the domed plug (Fig 10(1)) in the front sloping plate of to the left of the steering unit access cover (2).

41.3 Withdraw the dipstick, wipe it, re-insert it, ensuring it goes right down, withdraw it again and check the oil level.

41.4 Add oil, if necessary, to bring the oil level to the 'MAX' mark on the dipstick. Do not overfill.

41.5 Replace the dipstick and replace the domed plug.

Changing the oil

42 The procedure for changing the steering unit oil, is as follows:

42.1 Ensure the oil is still warm after the vehicle has been run and stop the vehicle on level ground.

42.2 Position a suitably sized receptacle under the vehicle and remove the access plug under the oil tank and the access plate from under the steering unit.

42.3 Remove the drain plugs from the oil tank and the steering unit.

43.4 Check the drain plugs and washers for serviceability and replace when the oil has completely drained. Tighten the plugs securely.

43.5 Refill with oil, check the level and top up as Para 41.

43.6 Replace the access plug and plate, ensuring that both make watertight joints.

Cleaning the breather

43 The procedure for changing the steering unit breather is as follows:


43.1 Open the steering unit access cover (Fig 10 (2)).

43.2 Pull the breather (Fig 11(1)) off the atmosphere pipe.

43.3 Wash the breather using an approved cleaning agent, and then allow it to drain.

43.4 Re-oil the steel wool allowing any surplus oil to drain before replacing.


43.5 Wipe the breather clean and refit.



430/20140

- 1 Steering unit oil tank access plug
- 2 Steering unit access cover

Fig 10 Front of vehicle



432/072

- 1 Steering unit breather
- 2 Brake operating lever
- 3 Half shaft coupling
- 4 Lubricators
- 5 Rollers

Fig 11 Steering brake linkage

Steering/brake levers**WARNING**

PROLONGED APPLICATION OF THE STEERING/BRAKE LEVERS COULD LEAD TO OVERHEATING OF THE STEERING/BRAKE SYSTEM, WHICH COULD CAUSE PREMATURE FAILURE.

44 The vehicle is steered by pulling back on the relevant steering/brake levers. The left tiller will turn the vehicle left and right tiller will turn the vehicle right, which will apply the brake band in the steering unit. Continuous application of the steering levers could cause the steering drum to overheat. This could cause damage to both the brake drum and brake bands, therefore when it is intended to turn the vehicle it should be steered by pulling hard on the relevant tiller (Left or right) and then releasing (i.e. turning a corner should be done in a series of arcs). When both steering/brake levers are applied simultaneously the vehicle can be slowed, stopped or parked.


44.1 The normal movement of the levers at the handles should be approx 150 mm (6 in.).

45 From a safety point view, it is essential to check the balance of the brakes by ensuring that the levers have an equal travel and that this amount is not excessive. If the movement is less than 150 mm (6 in.), greater than 200 mm (8 in.), or if the pair of levers has unequal movement, report. For further information refer to AC64193, Warning card for Steering and Braking.

Steering linkage lubrication

46 The steering lever cross-shafts are lubricated through four lubricating nipples, the three forward nipples (Fig 13(8)) on the row of five located in the driver's compartment to the right of the steering/brake levers and the fourth nipple (Fig 12(1)) on the main cross-shaft sleeve which is accessible when the steering unit access plate is open.

47 Each steering unit brake-operating shaft has a lubricating nipple (Fig 11(4)) on the inner end face. The fork end connecting pins and rollers (5) must be oilcan lubricated.




432/073

1 Lubricating nipple
2 Steering unit

3 Steering unit access sill

Fig 12 Steering lever cross-shaft lubricator



432/061

- | | | | |
|---|-------------------|----|-------------------------------------|
| 1 | Accelerator pedal | 7 | Accelerator cross-shaft lubricators |
| 2 | Quadrant | 8 | Steering linkage lubricators |
| 3 | Toothed washer | 9 | Steering/brake lever return spring |
| 4 | Knurled nut | 10 | Steering/brake levers |
| 5 | Spring | 11 | Fuel stop control pedal |
| 6 | Guard | | |

Fig 13 Steering and accelerator linkage lubricators

CHAPTER 2-5
VENTILATION CONTROL SYSTEM

CONTENTS

Para

- 1 Ventilation system
- 3 Operating the air condition system
- 8 Filter check
- Maintenance
- 9 Cleaning the filter (WARNING)
- 11 Cleaning the moisture trap bowl

Fig

Page

1	Distribution panel No. 6, Mk 1	2
2	Crew compartment, right side.....	3
3	Ventilation fan controls	4
4	Ventilation access door	5
5	Ventilation filters	6

VENTILATION SYSTEM

NOTE

The battery supply is only sufficient to run the fan at maximum speed for approximately 2½ hours; it is therefore, essential to conserve the supply as much as possible. Always switch 'OFF' at the distribution panel No. 6, Mk1, when the fan is not being used.

1 Clean air is drawn into the vehicle through two pairs of filter elements by a fan and is then circulated through ducting fitted with diffusers and flexible nozzles.

2 The outer filter (particulate) contain paper elements, which extract the solid particles from air passing through; the inner filter (charcoal anti-vapour) absorb the vaporized impurities. Dummy inserts for training purposes may replace the anti-vapour filters.

Operating the ventilation system

3 The system can only be used when the vehicle is closed down.

4 Switch on the fan circuit at the distribution panel No. 6 Mk 1 (Fig 1(1)). The battery master switch (2) must be 'ON' for the fan to operate.

5 Set the fan control (Fig 2(1)) at the slowest speed that will maintain the internal air pressure at a reading of +3 on the gauge (Fig 3(2)). At this pressure the relief valve in the roof plate to the left rear of the mortar hatch will be at the point of lifting off its seating.

6 Adjust the diffusers for crew comfort.


6.1 In warm humid atmospheres, the diffusers can be directed to pass air over the personnel to suit conditions.

6.2 When the ambient temperature is high, the diffusers can be reversed to produce a direct stream of air.

7 Adjust the flexible nozzles to suit requirements.

Filter check

8 To check the condition of the particulate filter, press the test button and the gauge vacuum reading will give an indication of the amount of dust built up on the elements. Should the reading on the gauge exceed -5 inches WG, it is necessary to remove the filters for cleaning.




432/039

1 Fan switch

2 Battery master switch


Fig 1 Distribution panel No. 6, Mk 1



430/20166

- | | | | |
|---|-----------------------------|----|---------------------------------|
| 1 | Fan speed control | 7 | Reservoir filler cap |
| 2 | Head rest | 8 | Backrest |
| 3 | Roof light | 9 | Reservoir |
| 4 | Crane operators switchboard | 10 | Slewing rack lubricating nipple |
| 5 | Reservoir vent | 11 | King post lubricating nipple |
| 6 | Auxiliary junction box | | |

Fig 2 Crew compartment, right side



434/021

1	Vent tube to atmosphere	4	Commander's cupola	6	Water trap
2	Vacuum/pressure gauge	5	Tube to filter housing	7	Fan speed control
3	Test button				

Fig 3 Ventilation fan controls

MAINTENANCE**Cleaning the filter**

9 The particulate filter may be cleaned three times only by shaking to remove the dust build up. After this, a replacement filter must be obtained and installed.

10 To remove and replace the particulate filter for cleaning, proceed as follows:

10.1 Switch 'OFF' the fan circuit (Fig 1(1)) at the Distribution Panel No. 6, Mk 1.

10.2 Release the sealing clamp bolts (Fig 4(4)) and catch handles (6) and open the filter housing access covers.

WARNING

ALWAYS USE THE HANDLE WHEN OPENING OR CLOSING THE COVER TO AVOID TRAPPING FINGERS BETWEEN THE COVER AND THE EXHAUST PIPE.

10.3 Remove the spanner (Fig 5(6)) stowed in a spring clip on the side of the filter housing and unscrew the clamping bolt (8) to release the clamp bar (3).

NOTE

It is essential that the fan is switched 'OFF' while servicing the filters and must not be run if the filters are not installed.





Fig 4 Ventilation filter access door

- 10.4 Withdraw the filter holder (2) with the particulate filter (7) inside it.
- 10.5 Slide the filter from the holder, keeping the filter square with the holder. Clean the element by shaking until as much dust as possible has been removed. If the element has already been cleaned three times by this method, discard it and a fit replacement filter.
- 10.6 If anti-vapour element filters are fitted, remove the gaskets, which separate the two filters.
- 10.7 Withdraw the anti-vapour element filters using the rings provided and discard them. New filters must be fitted.
- 10.8 Replace the filter and the filter holder in the reverse order in which they are removed. Locating strips welded to the filter frames ensure that the filters are correctly installed. Tighten the clamping bolt only sufficiently to make an effective seal without straining the holder.

Cleaning the moisture trap bowl

- 11 With the fan motor switched off, unscrew the bowl clamping ring (Fig 3(6)) and lower the bowl slide the sleeve from the filter screen
- 12 Remove and check the sealing washer.
- 13 Empty the bowl and wash in a suitable solution.
- 14 Dry the bowl thoroughly, then replace. Ensure that the sealing washer is correctly positioned.



434/024

- | | | | |
|---|---------------------------------|---|--------------------|
| 1 | Access cover | 6 | Spanner |
| 2 | Filter holder | 7 | Particulate filter |
| 3 | Clamp bar | 8 | Clamping bolts |
| 4 | Seal | 9 | Cover seal |
| 5 | Air inlet from external ducting | | |

Fig 5 Ventilation filters

CHAPTER 2-6
ELECTRICAL SYSTEM
CONTENTS

Para	
1	General (WARNING)
5	Circuit breakers
6	Fuses
7	Lamps
8	Distribution panel No. 6 Mk 1
9	Resetting a circuit breaker
10	Radio distribution box
11	Changing a fuse (WARNING)
12	Warning light – radio distribution box
14	Changing a lamp
15	Instrument panel
16	Instrument panel lights
18	Changing an instrument panel lamp
19	Driver's switchboard
20	External lighting switchboard (WARNING)
22	Dipswitch
23	Warning lights – oil pressure and main indicator generator
24	Warning lights – turn-light and main beam
27	Auxiliary junction box
28	Changing a fuse
29	Horn push button
30	Smoke grenade dischargers
31	Fire alarm system
32	Wiper switch
33	Distribution link box warning light
34	Changing a lamp
35	Alternators (WARNING)(CAUTIONS)
36	Charging the batteries with the vehicle stationary (CAUTION)
	Batteries
37	General (WARNING)(CAUTION)
41	Maintenance free batteries
44	Cleaning and checking maintenance free batteries (WARNINGS)
45	To remove a battery from the vehicle (WARNINGS)
46	Refitting
47	Testing
48	Battery lifting tool
49	Inspection light sockets
50	Interior lights
53	Spotlight
57	Changing a lamp
58	Amber rotating beacon
60	External lighting socket
	Headlight
61	Changing a lamp (WARNING)
62	Adjustment of beam setting
63	IR driving lights (WARNING)
64	Changing a lamp
65	Adjustment of beam setting
66	Side, turn, tail/stop and fire warning lights
68	Changing a lamp
69	Registration plate light and convoy light
70	Registration plate light

(continued)

CONTENTS (continued)

Para

71	Changing a registration plate lamp
72	Convoy light
73	Changing a convoy lamp
	Rectifier unit
74	Changing a main fuse
75	Bulkhead and locker lights
78	Changing a bulkhead or locker lamp light
82	Starter lubrication
83	Crane operator's engine switchboard
84	Boiling vessel sockets
86	Boiling vessel (WARNING)
92	Boiling (CAUTIONS)
93	Making beverages (CAUTION)
94	Heating compositions - decanted
95	Heating compositions - undecanted (WARNING)
96	Frying (WARNINGS)(CAUTION)
	Boiling vessel servicing (WARNING)
99	Cleaning inner food container
100	Cleaning water compartment
101	Drain tap
102	Lid
	Maintenance
103	Suppression of electrical interference to radio services

Table

	Page
1	Circuit breakers..... 4
2	Fuses 5
3	Lamps 5
4	Distribution panel No. 6 Mk 1 6
5	Radio distribution box 10
6	Instrument panel 13
7	Driver's switchboard 15
8	External lighting switch combinations 17
9	Auxiliary junction box 18
10	Times for water to boil 36

Fig

	Page
1	Driver's controls and instruments 6
2	Distribution panel No. 6 Mk 1 9
3	Radio distribution box 12
4	Instrument panel 14
5	Driver's switchboard 16
6	Auxiliary junction box 19
7	Gear range selector 21
8	Driver's compartment 23
9	Radio batteries (Maintenance free type) 24
10	Headlight 27
11	Amber rotating beacon 28
12	Crane controls 28
13	Rear of vehicle 29
14	Sidelight 31
15	Registration plate light 32
16	Convoy light 33
17	Load compartment, front right corner 34

(continued)

CONTENTS (continued)

Fig		Page
18	Crane operator's switchboard and speed control.....	35
19	Boiling vessel.....	38
20	Drain tap	40

GENERAL

1 The vehicle is fitted with two sets of batteries, automotive and radio, which are charged by the rectified output of two alternators.

2 The outputs of the two alternators are connected in parallel to a rectified unit and the rectified output is connected to the vehicle wiring and is indicated by an ammeter on the driver's instrument panel. The field circuit of each alternator is connected to transistor type regulators housed in separate control panels which control the rectified voltage at 28.5 V over an engine speed range of 600 rev/min (1,750 rev/min alternator speed), up to its governed speed.

WARNING

PERSONNEL HAZARD. THE VOLTAGES USED ON SOME OF THE EQUIPMENT ON THE VEHICLE, EG RADIOS, CAN BE LETHAL. DO NOT TAMPER WITH THESE EQUIPMENTS OR ATTEMPT ANY REPAIR OR ADJUSTMENT WITH THE BATTERY SWITCHES ON.

3 A hand control is provided which can be adjusted to vary engine speed to give a sufficient battery charging rate with the vehicle stationary.

4 Battery master switches are provided for the automotive and radio batteries.

Circuit breakers

5 Table 1 details the ratings of the Circuit Breakers (CB's).

TABLE 1 CIRCUIT BREAKERS

Circuits (1)	Circuit breaker (2)			
	Location (a)	Identification (b)	Type and rating (c)	
Circuit controlled by fuses F1, F2, F3, F4 and F5 in auxiliary junction box and smoke dischargers.	Distribution panel No. 6 Mk 1	A	15 A	
Horn, 12 point socket, Lights: head, side, tail, convoy, registration plate, turn stop, IR driving, locker.		B	15 A	
Fire alarm warning lights.		C	10 A	
Distribution panel inspection light sockets.		D	10 A	
(Not fitted)		E		
External lighting sockets and bench light socket.		F	25 A	
Ventilating fan motor relay.		Fan switch (CBR FV 436, 439)	G	5 A
Heater circuit		Fan switch (NBC FV 436, 439)	H	35 A
Circuits controlled by engine switch			K	15 A
Fuel pump, injection pump stop solenoid, battery analogue.			L	15 A
Engine coolant thermometer, fuel gauge, gearbox oil thermometer, oil pressure switch, alternator (GEN) warning lights (driver and crane operator), starter switch, alternator boost and instrument panel lights fuse.		M	10 A	

Fuses

6 Table 2 details the ratings and type of the fuses fitted to the vehicle.

TABLE 2 FUSES


Circuits (1)	Fuses (2)		
	Location (a)	Identification (b)	Type and rating (c)
Driver's periscope wiper motor, IR periscope.	Auxiliary junction box	F1	5 A cartridge
One interior light, bulkhead lights		F2	5 A cartridge
Spotlight socket inspection light socket (crane position).		F3	5 A cartridge
Three interior lights		F4	5 A cartridge
Navigational aid, Fuses F2 and F4		F5	10 A cartridge
Instrument panel lights	Instrument panel		5 A cartridge
Charging	Rectifier unit		250 A English Electric

Lamps

7 Table 3 details the ratings and type of the lamps fitted to the vehicle.

TABLE 3 LAMPS

Light (1)	Volts (2)	Watts (3)	Type (4)
Head, spot	26	50/50	British pre-focus
Tail/stop	28	30/7	Small Bayonet Cap (SBC) index pins
Side, Registration plate, Convoy and interior, locker, bulkhead.	26	6	Small Centre Contact (SCC)
Warning and Instrument panel	28	(0.04A)	Midget flange
IR driving	26	100/100	European cap
Turn and Fire warning	24	24	SCC



430/20163

- | | | | |
|---|----------------------------------|----|-------------------------------------|
| 1 | Fire warning light | 8 | Distribution link box |
| 2 | Interior light | 9 | Distribution link box warning light |
| 3 | Instrument panel | 10 | Driver's lighting switchboard |
| 4 | Distribution panel | 11 | Steering/brake lever |
| 5 | Firewire control box test switch | 12 | Horn push |
| 6 | Firewire control box | 13 | Parking control button |
| 7 | Automotive batteries | | |

Fig 1 Driver's controls and instruments

Distribution panel No. 6 Mk 1.

8 The distribution panel No. 6 Mk 1 is equipped with circuit breakers, Table 4 details the functions of the controls on the distribution panel No. 6 Mk 1; the number in brackets in the control/instrument column (2) refers to the key identification of Fig 2

TABLE 4 DISTRIBUTION PANEL NO. 6 MK 1.

Serial (1)	Control/instrument (2)	Description (3)	Identification (if any) (4)
1	Inter vehicle starting socket (1)	An Inter vehicle starting socket, covered by a protective cap when not in use.	
2	Inspection light socket (2)	An inspection light socket covered by a protective cap when not in use.	
3	Desiccator (3)		

(continued)


TABLE 4 DISTRIBUTION PANEL NO. 6 MK 1 (continued)

Serial (1)	Control/instrument (2)	Description (3)	Identification (if any) (4)
4	Boiling vessel sockets (4)	Two sockets for the connection of the boiling vessel harness.	
5	Waterproof test plug (5)		
6	Fan switch (6)	Controls the operation of the ventilating fan. The switch must always be set in the OFF position when the fan is not in use.	FAN
7	Heater switch (7)	Controls the operation of the heater unit if fitted.	HEATER
8	External lighting switch (8)	Controls the four way socket on the power tool assembly at the rear of the vehicle. The socket is provided for external lighting, the switch must always be set in the OFF position when not in use.	EXT LIGHTING
9	Battery switch position indicator (9)	Indicates position of battery switch	
10	Battery indicator switch (10)	A two-position switch, having a lockable cover. Switch must be set to position 2 for normal use and position 3 when the vehicle is converted to the Ambulance role.	BATTERIES
11	Locking screw (11)	Captive screw for locking the battery switch in position.	
12	Cover (12)	Circuit Breaker cover and Circuit Breaker identity label.	
13	Circuit breaker (13)	5A C B to protect the ventilating fan relay circuit. (CBR on FV 436, FV 439)	G
14	Circuit breaker (14)	35A C B to protect the heater unit circuit. (NBC on FV 436, FV 439)	H
15	Circuit breaker (15)	15A CB to protect the fire alarm circuit.	J
16	Circuit breaker (16)	15A CB to protect circuits protected by the engine switch.	K
17	Circuit breaker (17)	15A CB to protect the fuel pump, injection stops solenoid and battery analogue circuits.	L

(continued)

TABLE 4 DISTRIBUTION PANEL NO. 6 MK 1 (continued)

Serial (1)	Control/instrument (2)	Description (3)	Identification (if any) (4)
18	Circuit breaker (18)	10A CB to protect the engine coolant thermometer, gearbox oil thermometer, oil pressure switch, alternator (GEN) warning light, starter switch, alternator boost and instrument panel lights circuits.	M
19	Circuit breaker (19)	25A CB to protect the external lighting sockets circuit.	F
20	(20)	Not in use	E
21	Circuit breaker (21)	10A CB to protect the distribution panel inspection light socket circuit	D
22	Circuit breaker (22)	10A CB to protect the fire alarm warning lights circuit	C
23	Circuit breaker (23)	15A CB to protect the horn, head lights, side lights, tail lights, mini-fascine lighting, convoy light, registration light, turn lights, stop lights and IR driving lights circuits	B
24	Circuit breaker (24)	15A CB to protect the smoke grenade discharger and circuits controlled by fuses F1, F3 and F5 in the auxiliary junction box circuits	A
25	Battery switch (25)	A semi rotary switch. Turn handle clockwise for the ON position and counter clockwise for the OFF position. In the OFF position the automotive and ventilation battery positive terminals are isolated from all circuits except the fire warning horn.	BATTERY



- | | | | | | |
|---|--------------------------------------|----|--------------------------|----|---------------------|
| 1 | Inter-vehicle starting socket | 10 | Battery indicator switch | 18 | Circuit breaker (M) |
| 2 | Inspection light socket cap | 11 | Locking screw | 19 | Circuit breaker (F) |
| 3 | Desiccator | 12 | Cover | 20 | Circuit breaker (E) |
| 4 | Boiling vessel socket caps | 13 | Circuit breaker (G) | 21 | Circuit breaker (D) |
| 5 | Waterproof test plug | 14 | Circuit breaker (H) | 22 | Circuit breaker (C) |
| 6 | Fan switch (CBR Switch on FV 439) | 15 | Circuit breaker (J) | 23 | Circuit breaker (B) |
| 7 | Heater switch (NBC Switch on FV 439) | 16 | Circuit breaker (K) | 24 | Circuit breaker (A) |
| 8 | External lighting switch | 17 | Circuit breaker (L) | 25 | Battery switch |
| 9 | Battery switch position indicator | | | | |

Fig 2 Distribution panel No. 6 Mk1

432/431

Resetting a circuit breaker

9 The procedure for resetting a circuit breaker in the distribution panel No. 6 Mk 1 is as follows:

9.1 Switch off the relevant faulty circuit.

9.2 Release the circuit breaker cover (Fig 2(12)), which is secured by a hinged bolt with a knurled nut.

9.3 Press the button of the appropriate circuit breaker to reset the circuit breaker. A white collar on the stem of the button shows when the circuit breaker is in the tripped position.

9.4 Switch on the appropriate circuit. If the circuit breaker trips again report to REME.

9.5 Replace the cover.

9.6 To manually open a circuit breaker pull the bottom of the circuit breaker until the pressure of an integral mechanical latch is overcome.

Radio distribution box

10 Mounted on the upper sideplate to the rear of the radio batteries. Table 5 details the functions of the controls on the radio distribution box, the number in brackets in the control/instrument column (2) refers to the key identification of Fig 3 and Fig 4.

TABLE 5 RADIO DISTRIBUTION BOX

Serial (1)	Control/instrument (2)	Description (3)	Identification (if any) (4)
1	Radio Battery switch (2)	A semi rotary switch. Turn handle clockwise for the ON position and counter clockwise for the OFF position. In the OFF position the radio battery positive terminals are isolated from all circuits except the fire warning horn.	BATTERY
2	External charge switch (3)	Provides a facility for charging external batteries. When not charging external batteries the switch must be in the OFF position, if left in the ON position the GEN warning light is inoperable.	EXT CHARGE
3	GEN warning light (4)	The lamp illuminates when the radio battery switch is in the ON position, providing the external charge switch is in the OFF position and is extinguished when charging starts. It also illuminates when external batteries are connected and the external charge switch is in the ON position and extinguishes when external charging starts.	GEN
4	Fuse cover and fuse (5)	Cover housing a 100A link type fuse.	LOAD

Changing a fuse

WARNING

PERSONNEL HAZARD. THE VOLTAGES USED ON SOME OF THE EQUIPMENT ON THE VEHICLE, EG RADIOS, CAN BE LETHAL. DO NOT TAMPER WITH THESE EQUIPMENTS OR ATTEMPT ANY REPAIR OR ADJUSTMENT WITH THE BATTERY SWITCHES ON.



- 11 The procedure for changing a fuse in the radio distribution box is as follows:
 - 11.1 Put the radio battery switch (Fig 3(2)) to OFF.
 - 11.2 Remove the fuse cover (5) that is secured by two captive knurled nuts.
 - 11.3 Ensure the contact surfaces of the fuse link terminals are clean and free from burns.
 - 11.4 Fit the new fuse link and replace the cover.
 - 11.5 Check the circuit and if the fuse blows again report to REME.

Warning light - radio distribution box

- 12 The light is similar to those fitted to the instrument panel but have a coloured lens in place of the moulded holder.
- 13 The radio distribution box has a Gen warning light (Fig 3(6)) or (Fig 4(6)) which has a red lens.

Changing a lamp

- 14 The radio distribution box Gen warning light is a press to test type light. The procedure for changing a press to test lamp is as follows,
 - 14.1 Ensure the relevant circuit is turned OFF.
 - 14.2 Unscrew the lampholder.
 - 14.3 Withdraw the lamp from the holder.
 - 14.4 Check that the spring-loaded centre contact is satisfactory.
 - 14.5 Fit the new lamp into the holder.
 - 14.6 Ensure the rubber washer is in place on the holder and then screw the holder in the panel.
 - 14.7 Press to test the operation of the lamp and if it still does not function report to REME.



430/20164

- | | | | |
|---|-------------------------|---|--------------------------|
| 1 | Mounting bracket | 5 | External charging switch |
| 2 | VUDT | 6 | Fuse cover |
| 3 | Radio battery switch | 7 | Terminal cover |
| 4 | Generator warning light | | |


Fig 3 Radio distribution box

Instrument panel

15 Mounted to the right of the driver's switchboard. Table 6 details the functions of the controls on the instrument panel; the number in brackets in the control/instrument column (2) refers to the key identification of Fig 4.

TABLE 6 INSTRUMENT PANEL

Serial (1)	Control/instrument (2)	Description (3)	Identification (if any) (4)
1	Tachometer (1)	Indicates engine output shaft speed. Readings must be multiplied by 100.	
2	Coolant temperature gauge (3)	Indicates engine coolant temperature displayed in degrees Fahrenheit. Readings must be multiplied by 10.	
3	Fuel gauge (4)	Indicates the amount of fuel in the tanks. Graduated 0, 1/4, 1/2, 3/4 and F. Total capacity 454 litres (100 gallons imperial)	
4	Ammeter (5)	Indicates the rectified output current of the alternators.	
5	Panel light switch (6)	A combined switch and dimmer resistance controlling the eight panel lights.	DIMMER
6	Gearbox oil temperature gauge (7)	Indicates gearbox oil temperature displayed in degrees Fahrenheit. Readings must be multiplied by 10.	
7	Fuse (8)	5A cartridge fuse protecting the panel lights circuit.	5A
8	Speedometer trip reading reset knob (9)	Allows the speedometer trip reading to be reset.	RESET
9	Speedometer (10)	Indicate vehicle road speed in mph. An odometer records total vehicle mileage in the lower half of the gauge and a trip mileage indicator in the upper half.	



432/085

- | | | | |
|---|---------------------------|----|-------------------------------------|
| 1 | Tachometer | 6 | Panel lights switch |
| 2 | Panel light | 7 | Gearbox oil temperature gauge |
| 3 | Coolant temperature gauge | 8 | Fuse |
| 4 | Fuel gauge | 9 | Speedometer trip reading reset knob |
| 5 | Ammeter | 10 | Speedometer |

Fig 4 Instrument panel

Instrument panel lights

16 Illumination of the driver's instruments is effected by eight lights, (Fig 4(2)), having flanged midget lamps, which are push fit into holders screwed into the face of the panel.

17 The lamps are controlled by a dimmer resistance switch on the panel.

Changing an instrument panel lamp

18 The procedure for changing an instrument panel lamp is as follows:

- 18.1 Put the instrument panel lights switch to OFF (Fig 4(6)).
- 18.2 Unscrew the lampholder.
- 18.3 Withdraw the lamp from the holder.
- 18.4 Check that the spring-loaded centre contact is satisfactory.
- 18.5 Fit the new lamp into the holder.
- 18.6 Ensure the rubber washer is in place on the holder and then screw the holder in the panel.
- 18.7 Test the operation and if it still does not function report to REME.

Driver's switchboard

19 Located in front of the driver and containing three separate panels, the turn lights switchboard, the engine switchboard and the external lighting switchboard. Table 7 details the functions of the controls on the driver's switchboard; the number in brackets in the control/instrument column (2) refers to the key identification of Fig 5.

TABLE 7 DRIVER'S SWITCHBOARD

Serial (1)	Control/instrument (2)	Description (3)	Identification (if any) (4)
1	Turn light switch (1)	Contained within the turn light switchboard and controls the turn lights at the front and rear of the vehicle. To operate the rotate the switch in the direction indicated on the panel. When a trailer is connected to the vehicle and the switch is operated, the front turn lights and the trailer rear turn lights operate but the vehicle rear turn lights are inoperative.	TURN INDICATOR
2	Turn light warning Light (8)	Contained within the turn light switchboard and fitted with an amber lens, the light flashes synchronously with the turn lights. If the light does not flash when the switch is operated a turn light lamp failure is indicated.	TURN LIGHT
3	Main beam warning Light (7)	Contained within the turn light switchboard and fitted with a blue lens, the light illuminates when the main beam of the headlights are switched on.	MAIN BEAM
4	Main indicator (GEN) (2)	Contained within the engine switchboard. A press to test type light fitted with a red lens. The light illuminates when the engine switch is put to ON and extinguishes when the alternators reach the charging voltage. If the light does not illuminate when the engine switch is put to ON, press the lens, if the light does not illuminate, renew the lamp, if it does illuminate – REPORT.	GEN
5	Low oil pressure warning light (3)	Contained within the engine switchboard. A press to test type light fitted with an amber lens. The light illuminates when the engine switch is put to ON and extinguishes when the engine oil pressure reach a preset safe operating pressure. The light will illuminate if the engine oil pressure falls to a dangerously low pressure	OIL
7	Starter switch (5)	Contained within the engine switchboard. A toggle switch, spring loaded to the OFF position and protected by a spring-loaded cover to prevent accidental operation. The range selector must be in neutral and the engine switch ON before the starter motor can be operated.	START
8	External lighting switchboard (4)	Para 21 refers	


External lighting switchboard

20 Located to the right of the engine switchboard, the external lighting switchboard (Fig 5(4)), and houses four switches that controls the vehicle external lighting. The bottom right hand switch is used to select NORMAL (toggle up) or BLACKOUT (toggle down) lighting. This switch has a spring-loaded cover to prevent accidental operation.

21 Table 8 details the switching combinations required to meet operational requirements. With the toggles up, the switches are in the positions designated OFF in the table and with the toggles down the positions are designated ON.

WARNING

DAMAGE TO EYESIGHT. THE INFRA RED (IR) DRIVING LIGHTS ARE FITTED WITH 100 WATT LAMPS. THESE LIGHTS SHOULD NO LONGER BE USED. NEVER LOOK AT THE IR LIGHT WHEN THE FILTER IS FITTED AND THE LIGHT IS SWITCHED ON AS SERIOUS AND PERMANENT DAMAGE TO THE EYE MAY RESULT.



432/456

- | | | | |
|---|--------------------------------|---|--------------------------|
| 1 | Turn light switch | 5 | Starter switch |
| 2 | Main indicator (GEN) | 6 | Engine switch |
| 3 | Low oil pressure warning light | 7 | Main beam warning light |
| 4 | External lighting switchboard | 8 | Turn light warning light |

Fig 5 Driver's switchboard

TABLE 8 EXTERNAL LIGHTING SWITCH COMBINATIONS

SWITCH SELECTION				LIGHTS						
Blackout	Tail/side	Head/IR	Convoy	Tail	Side	Head	Reg.plate	Convoy	IR	Turn and stop
NORMAL CONDITIONS										
OFF	OFF	OFF	OFF	N/A	N/A	N/A	N/A	N/A	N/A	YES
OFF	ON	OFF	OFF	ON	ON	N/A	ON	N/A	N/A	YES
OFF	ON	ON	OFF	ON	ON	ON	ON	N/A	N/A	YES
CONVOY CONDITIONS										
OFF	OFF	OFF	OFF	N/A	N/A	N/A	N/A	ON	N/A	N/A
OFF	ON	OFF	ON	N/A	ON	N/A	N/A	ON	N/A	N/A
BLACKOUT CONDITIONS										
ON	OFF	OFF	OFF	N/A	N/A	N/A	N/A	N/A	N/A	N/A
ON	OFF	OFF	ON	N/A	N/A	N/A	N/A	ON	N/A	N/A
ON	ON	OFF	OFF	ON	N/A	N/A	N/A	N/A	N/A	N/A
ON	OFF	ON	OFF	N/A	N/A	N/A	N/A	N/A	ON	N/A
ON	ON	ON	OFF	ON	N/A	N/A	N/A	N/A	ON	N/A
ON	OFF	ON	ON	N/A	N/A	N/A	N/A	ON	ON	N/A

Dipswitch

22 The dipswitch is a foot-operated switch on the vehicle floor plate, adjacent to the driver's left foot. With the headlights switched on, operation of the switch changes the light beams from dipped to main beam or vice versa. A warning light on the turn light switchboard illuminates when the main beams are on.

Warning lights - oil pressure and main indicator generator

23 The oil pressure and main indicator Gen warning lights are press to test type lights. To change a lamp, refer to Para 14.1.

Warning lights – turn-light and main beam

24 These lights are similar to those fitted to the instrument panel but have a coloured lens in place of the moulded holder.

25 The turn-light and main beam warning lights are fitted at the left side of the driver's switchboard (Fig 6) and have an amber and a blue lens respectively

26 To change a lamp ensure the relevant circuit is turned OFF and refer to Para 14.1.

Auxiliary junction box

27 Table 9 details the functions of the controls on the auxiliary junction box; the number in brackets in the control/instrument column (2) refers to the key identification of Fig 6.

TABLE 9 AUXILIARY JUNCTION BOX

Serial (1)	Control/instrument (2)	Description (3)	Identification (if any) (4)
1	Fuse (1)	10A cartridge fuse to protect the navigational aid and fuses F2 and F4.	F5
2	Fuse (2)	5A cartridge fuse to protect three interior lights.	F4
3	Fuse (3)	5A cartridge fuse to protect the spotlight socket inspection light socket (crane position).	F3
4	Fuse (4)	5A cartridge fuse to protect one interior light and bulkhead lights.	F2
5	Fuse (5)	5A cartridge fuse to protect the driver's periscope or wiper motor and IR periscope.	F1
6	External light switch (6)	Switch controlling the spotlight and inspection light socket at the crane position.	SWITCH No. 1
7	Interior light switch (7)	Switch controlling the interior lights , bulkhead lights and navigational aid.	SWITCH No. 2

Changing a fuse

28 Switch off the relevant circuit (Fig 6), proceed as detailed in Para 11.2.

Horn push button


29 The horn push button (Fig 1(13)) is located to the right of the driver's switchboard and operates the traffic horn.

Smoke grenade dischargers

30 Refer to Chap 2-2 of this publication.

Fire alarm system

31 Refer to Chap 2-1 of this publication.



434/028

- 1 Fuse F5
- 2 Fuse F4
- 3 Fuse F3
- 4 Fuse F2

- 5 Fuse F1
- 6 Switch No.1
- 7 Switch No.2

Fig 6 Auxiliary junction box

Wiper switch

32 A toggle switch located to the right of the driver's periscope screen washer unit and controls the operation of the periscope (or hood) wiper motor

Distribution link box warning light

33 The distribution link box warning light (Fig 1(10)) is a small press to test type warning light fitted to the left hand side of the distribution link box, below the instrument panel. Under normal conditions, with the alternators charging, the light is dim, if the radio batteries positive line is earthed, the light is bright. If the radio battery connections are reversed, the light is bright before the engine is started, if the engine is started in this condition the lamp will glow excessively and burn out Internal damage will also be caused to the charging system.

Changing a lamp

34 The distribution link box warning light (Fig 1(10)) is a press to test type light. Refer to Para 14.1 for the procedure to change a press to test lamp.

Alternators

WARNING

PERSONAL INJURY. THE ALTERNATORS GET EXTREMELY HOT WHEN RUNNING.

35 Two alternators mounted back to back, are driven at 2.94 times the engine output speed, which is shown, on the tachometer (Fig 4(1)). Each alternator is a 228.6 mm (9 in.), oil cooled, 3-phase alternator having a solid rotor and hence no slip rings and brushes. Special insulating material is used in the windings to permit working at high temperatures.

Charging the batteries with the vehicle stationary

CAUTION

EQUIPMENT DAMAGE. When working in sub-zero conditions the batteries must be kept fully charged, otherwise the electrolyte may freeze. For further maintenance, reference should be made to the appropriate AESP listed under Associated Publications.

36 The procedure to charge the batteries with the vehicle stationary is as follows:


36.1 Start the engine.

36.2 Slacken the wing nut (Fig 7(1)) on the engine speed hand control and turn the knurled head (2) of the screw to increase the engine speed until the generator warning lights on the engine switchboard (Fig 5(2) and radio distribution box (Fig 3(3)) extinguish.

NOTE

(1) The generator warning light illuminates when the engine switch is put to ON and extinguishes when the alternators reach the charging voltage. If the light does not illuminate when the engine switch is put to ON, press the lens, if the light does not illuminate, renew the lamp, if it does illuminate report to REME.

(2) The generator lamp illuminates when the radio battery switch is in the ON position, providing the external charge switch is in the OFF position and is extinguished when charging starts.



432/087a

1 Wing nut locking control

2 Engine speed hand control

Fig 7 Gear range selector

Batteries

General

37 Two sets of batteries are fitted - automotive and radio. The automotive batteries (Fig 8(1)) are located on the sill to the right of the driver's seat and the radio batteries (Fig 9) beneath the driver's seat (to obtain access to the batteries beneath the driver's seat, see Chap 2-2).

38 Each pair of batteries is housed in a fibreglass container (Fig 9(2)), which in turn is located in an angle framework (7) bolted to the vehicle. The batteries sit on felt strips located on a teak framework. A clamp bar with felt strip straddles the two batteries and is held by two hinged bolts (5) attached to the frame and fitted with a seating collar, a shock absorbing spring, washer and nut.

CAUTION

EQUIPMENT DAMAGE. Each pair of batteries must be of the same type, (i.e. both maintenance free)

39 There are two types of battery, maintenance free or maintenance required. Either type can be fitted to the vehicle. Maintenance free batteries are issued as replacements for maintenance required batteries. However, it is imperative that batteries are of the same type, are fitted throughout the vehicle, so it may be necessary to change all six batteries even though only one has failed, assuming they were all maintenance required.

40 The radio batteries are provided to meet the requirements of any radio equipment which may be fitted, these batteries are charged simultaneously with the automotive batteries providing the radio switch is on.

WARNING

FIRE HAZARD. THE GASES RELEASED FROM THE BATTERY ARE HIGHLY INFLAMMABLE. IT IS IMPORTANT THEREFORE THAT THE BATTERY VENTING SYSTEM IS MAINTAINED IN GOOD CONDITION. IT IS ALSO IMPORTANT ELECTRICAL CONNECTIONS MUST BE MAINTAINED CLEAN AND TIGHT TO PREVENT ARCING AND POSSIBLE IGNITION OF GASES. A NAKED LIGHT MUST NEVER BE USED WHEN EXAMINING A BATTERY.

Maintenance free batteries

41 Maintenance free lead acid batteries must be fitted in sets. Each set consists of two 12 V 110Ah batteries connected in series to give a 24V 110Ah supply.

42 Each battery connector is a split clamp type, enclosed by a flexible insulating cover. To safe guard against inadvertently reversing battery connections, the positive and negative terminal posts of each battery are of different diameters. As a further safeguard the positive terminal is encircled by a red collar and the negative terminal by a blue collar.

43 When maintenance free type batteries are fitted, the battery venting system of the vehicle is connected to a venting manifold on top of the battery.

Cleaning and checking maintenance free batteries

44 To check and clean maintenance free batteries proceed as follows:

WARNINGS

(1) LETHAL VOLTAGE. BEFORE REMOVING OR REPLACING BATTERY CONNECTION, ENSURE THAT THE ENGINE IS STOPPED. SET THE BATTERY SWITCH, LOCATED ON THE DISTRIBUTION PANEL AND RADIO DISTRIBUTION BOX, TO OFF.

(2) HEAVY WEIGHT. EACH BATTERY WEIGHS APPROXIMATELY 38Kg (84 lb).

44.1 Examine the battery for damage, included cracked, split or overheated/distorted case, loose or burnt away terminals and corrosion.


WARNING

LETHAL VOLTAGE. WHEN DISCONNECTING BATTERIES, REMOVE ALL THE TERMINALS FROM THE EARTH (NEGATIVE) (-) TERMINAL POSTS BEFORE REMOVING THE SUPPLY (POSITIVE) (+) TERMINALS. REPLACE IN THE REVERSE ORDER (POSITIVE TERMINALS FIRST).

44.2 Ensure the battery terminals are clean. If corrosion is visible, carefully lift the connector cover and then disconnect the faulty connector from its post. To prevent short-circuiting to nearby metal, always disconnect the negative terminal first. Scrape away corrosion and wash the connector and post with ammonia or soda solution to neutralize the acid. Replace the connector. Always fit the positive terminal first.

44.3 Ensure the batteries are secure within the tray.


44.4 Ensure the connector terminals are tight.



430/20171

1 Automotive batteries

Fig 8 Driver's compartment



430/20085

1	Seat frame	7	Container housing frame
2	Negative terminal	8	Container
3	Vent tube assembly	9	Access plate, gearbox filter
4	Rubber cover	10	Footrest bracket
5	Battery clamp bolt	11	Seat bracket
6	Battery clamp bar	12	Inter-connector

Fig 9 Radio batteries (Maintenance free type)

To remove a battery from the vehicle

NOTE

For manufacturing details of the battery-lifting tool, refer to AESP 2350-T-251-522.

WARNINGS

- (1) **LETHAL VOLTAGE. WHEN DISCONNECTING BATTERIES, REMOVE ALL THE TERMINALS FROM THE EARTH (NEGATIVE) (-) TERMINAL POSTS BEFORE REMOVING THE SUPPLY (POSITIVE) (+) TERMINALS. REPLACE IN THE REVERSE ORDER (POSITIVE TERMINALS FIRST).**
- (2) **LETHAL VOLTAGE. BEFORE REMOVING OR REPLACING BATTERY CONNECTION, ENSURE THAT THE ENGINE IS STOPPED. SET THE BATTERY SWITCH, LOCATED ON THE DISTRIBUTION PANEL AND RADIO DISTRIBUTION BOX, TO OFF.**
- (3) **HEAVY WEIGHT. EACH BATTERY WEIGHS 38 KG (84 LB). DUE CONSIDERATION MUST BE GIVEN TO THE REGULATIONS GOVERNING THE LIFTING OF HEAVY WEIGHTS WHEN MOVING EQUIPMENT.**

(4) PERSONAL INJURY. THE ACID IN THE CELLS IS HARMFUL AND MUST NOT BE ALLOWED TO CONTACT THE EYES, SKIN OR CLOTHING.

- 45 The procedure to remove any of the batteries is similar and is as follows:
- 45.1 Switch all battery master switches to OFF.
 - 45.2 For the radio batteries, remove the driver's seat assembly.
 - 45.3 Release the nuts holding clamp (Fig 9(5)) and the remove clamp.
 - 45.4 Remove the ventilation tube (3) and the T-connection.
 - 45.5 Remove the battery negative connection (2).
 - 45.6 Remove the battery positive connection and connecting strap (12).
 - 45.7 For the hull batteries, remove battery container securing strip and slide container with batteries onto driver's seat.
 - 45.8 For the radio batteries, lift commander's seat foot platform to vertical position.
 - 45.9 Using special battery lifting tool, detailed at Para 50, move batteries from vehicle individually out through the driver's hatch or back through the crew compartment.

Refitting

- 46 Refit in reverse order to removing.

Testing

- 47 Depending on which set of batteries have been replaced, carry out functional test on corresponding system: hull - ensure engine starts; radio - ensure radio operates under all conditions; ventilation - ensure fan operates.

Battery lifting tool

- 48 To facilitate removing and refitting of batteries, a special tool may be manufactured locally. For manufacturing details see AESP 5230-T-251-522 Chap 5.

NOTES

(1) There are currently two types of batteries fitted to the FV430 Series. These are Maintenance Free (New type (Grey coloured)) and Non-maintenance free (Old type (Black)). The 'Old type' battery is no longer issued and has been superseded by the new maintenance free type battery. It is imperative that each pair of batteries is of the same type, (i.e. both maintenance free)

(2) The care and maintenance of maintenance required lead acid batteries is detailed in AESP 6160-T-100-013.

Inspection light sockets

- 49 An inspection light or AFV spotlight socket is incorporated in the distribution panel. A captive protective screw cap (Fig 2(2)) is provided and must be fitted when the socket is not in use.

Interior lights

- 50 Four interior lights are provided which are controlled by switch No. 2 (Fig 6(7)) on the auxiliary junction box; each light incorporates its own switch and dimmer resistance.

51 Under normal conditions put switch No. 2 on the auxiliary junction box to 'ON' then switch 'ON' the individual lights as required.

52 Under blackout conditions put switch No. 2 to 'OFF' then set the individual light switches to provide the minimum amount of light for the task in hand.

Spotlight

53 Two spotlights are normally stowed in the cargo compartment locked. They are similar in construction, but one is fitted with a two-pin plug for use in the distribution panel inspection light socket (Fig 2(2)) and the other with a four-pin plug for use in the four-pin sockets on the exterior of the vehicle (Fig 11(1), adjacent to the crane controls.

54 A mounting bracket for use with the lights is located on the cupola periscope guard.

55 The light is similar to the headlight; the same type of light unit and lamp is fitted but, in this instance, only the main filament is used. The light has an 'ON-OFF' switch and 9m (30ft) of cable which terminates on a 2-pin plug to fit into the distribution panel socket.

56 When not in use the cable may be wrapped round the body to locate against the stem, handle and two brackets fitted at each side of the light. A dummy socket to house the plug is fitted to the light handle.

Changing a lamp

57 The procedure for changing a spotlight is as follows:

57.1 Put the spotlight switch to OFF.

57.2 Slacken the screws securing the clips to the rim until the clips can be swung aside (Fig 10)

57.3 Support the rim, swing aside the clips, and withdraw the rim and light unit (1) assembly.

57.4 Whilst supporting the rim and light unit press the lamp adaptor (4) and lead assembly towards the light unit, turn it anti-clockwise and withdraw the adaptor.

57.5 Withdraw the lamp and fit a new one, taking care to engage the slot of the lamp plate with the key of the lampholder.

57.6 Check that the spring-loaded contacts of the adaptor (4) are satisfactory. Engage the projections on the adaptor with the slots of the lampholder. Press the adaptor onto the holder and secure it by turning clockwise.

57.7 Test the lamp. If it still does not function report to REME.

57.8 Locate the light unit and rim assembly in position in the body (5), ensuring that the TOP marks are at the top. Check that the sealing gasket (7) fits correctly, press the unit into position, and secure it with the clips.


Amber rotating beacon

58 An amber rotating beacon (Fig 11) is mounted to the right hand side of the king post and is locked into a vertical pipe type mounting by a locking lever. The beacon is used when the vehicles are to be driven on public roads to warn other road users of a slow moving vehicle.

59 The rotating beacon is connected via a cable harness tie wrapped to the flexible hydraulic pipes and plugs into the external lighting socket by the crane operator's hatch. To operate the rotating beacon, switch on the normal driving lights.

External lighting socket


60 Connection points are provided, for external lighting purpose, by means of four 4-way sockets with captive screws on covers. Two are adjacent to the crane control, (Fig 12(1)) one (Fig 12(3)) one and one on the vehicle rear plate (8) above the workbench.



- 1 Rim
- 2 Light unit
- 3 Lamp
- 4 Adaptor
- 5 Body


- 6 Terminal block
- 7 Rear gasket
- 8 Stem mounting
- 9 Front gasket

Fig 10 Headlight



434/005a


Fig 11 Amber rotating beacon



434/032

1 Light sockets

Fig 12 Crane controls



430/20011

- | | | | |
|----|-----------------------|----|----------------------------------|
| 1 | Fire extinguisher | 13 | Turnlight |
| 2 | Trailer socket | 14 | Tail/stop light |
| 3 | Light socket | 15 | Track pad deflector stowing hook |
| 4 | Earthing terminal | 16 | Rear stowage compartment door |
| 5 | Light mounting bosses | 17 | Track pad deflector |
| 6 | Bench locking pin | 18 | Towing eye brackets |
| 7 | Vice mounting bracket | 19 | Tow bar securing pins |
| 8 | Light socket | 20 | Tow bar |
| 9 | Bench step | 21 | Clamping plates |
| 10 | Bench support chains | 22 | Convoy light |
| 11 | Stowage locker doors | 23 | Registration plate light |
| 12 | Locker door clamp | 24 | Jerrican stowage bracket |

Fig 13 Rear of vehicle

Headlight

Changing a lamp

WARNING

DAMAGE TO EYESIGHT. THE INFRA RED (IR) DRIVING LIGHTS ARE FITTED WITH 100 WATT LAMPS. THESE LIGHTS SHOULD NO LONGER BE USED. NEVER LOOK AT THE IR LIGHT WHEN THE FILTER IS FITTED AND THE LIGHT IS SWITCHED ON AS SERIOUS AND PERMANENT DAMAGE TO THE EYE MAY RESULT.

61 To change a headlight lamp turn put the headlight switch to 'OFF' and proceed as Para 57.2

Adjustment of beam setting

62 To adjust the beam setting the vehicle should be normally loaded and standing on level ground with the front of the vehicle at least 6m (20 ft) from a suitable screen or wall. The lights should be set straight ahead with the main beam of each light parallel with the beam of the other light and with the ground. Proceed as follows:

62.1 Unscrew the four screws fitted with spring washers securing the side and turn light mounting plate, the nuts are captive to the bracket.

62.2 Carefully move aside the plate.

62.3 Slacken the fixing nut at the base of the light stem and move the light on its adjustable mounting to the required position. Finally, tighten the fixing nut.

62.4 Replace the side and turn light mounting plate.

62.5 Check the side and turn lights to ensure that these lights have not become disconnected.

IR driving lights

63 The IR driving lights are the inner pair of lights mounted on the same channelling as the headlights. The general design of the lights is similar to that of the headlights but a different type of lampholder is used. When required, an IR filter unit is secured to the front of the light by the rim securing clips and when the light is switched on, light is not visible to the unaided eye but heat from lamp can be felt.

WARNING

PERSONAL INJURY. NEVER GAZE AT THE IR LIGHT WHEN IT IS SWITCHED ON. DAMAGE TO THE EYE MAY RESULT IF THIS WARNING IS IGNORED.

Changing a lamp

64 Put the IR switch to 'OFF' and proceed as Para 57.2.

Adjustment of beam setting

65 Proceed as for the headlights (Para's 62), but remove the blank plate instead of the side and turn light mounting plate.

Side, turn, tail/stop and fire warning lights

66 The side, turn, and fire warning lights have an SCC lampholder assembly (Fig 14(3)) fitted in a rubber body (7), which in turn locates in a metal base (1) bolted to the mounting plate. The sidelights have a white domed lens (6) which screws into the light base, the turnlights have an amber lens, and the fire warning lights a red lens.

67 The tail/stop lights are similar to the sidelights but have a red lens and a double contact lampholder fitted with a 7/30 W double filament lamp. The 7 W filament provides the taillight and the 30 W the stoplight. The lamp cap has index type pins to ensure correct fitting.

Changing a lamp

68 The procedure to change a lamp is as follows:


68.1 Put the appropriate light switch to OFF.

68.2 Unscrew the domed lens (Fig 14(6)) from the light. In the case of the fire warning light in the personnel compartment, it will be necessary to first remove the guard.

68.3 Remove the bayonet-fixing lamp from its holder.

68.4 Check that the spring-loaded contact is satisfactory, and then fit a new lamp. When doing this on the tail/stop light make sure that the index type pins are in the correct location. Test the lamp, if it still does not function report to REME.

68.5 Screw on the domed lens, taking care to ensure the threads are correctly engaged, and remain securely engaged throughout the screwing motion.



432/095

- | | | | |
|---|---------------------|---|-------------|
| 1 | Base | 5 | Lamp |
| 2 | Contact ferrule | 6 | Lens |
| 3 | Lampholder assembly | 7 | Body |
| 4 | Earth ferrule | 8 | Cable gland |


Fig 14 Sidelight

Registration plate light and convoy light

69 The registration plate (Fig 15(3)) and convoy lights (15) are mounted on the rear door, connections to the lights being by an assembly of three spring-loaded plungers attached to the inside of the hull rear plate, making contact with plates mounted on the inside of the doors.

Registration plate light

70 The cover of the registration light is cylindrical with a 180-degree light aperture. Fitted on the cover is a light shield (Fig 15(1)) with two light apertures, one similar to that of the cover and diametrically opposite a 3/8 in. dia hole. The shield is slotted to engage a locating peg (2) fitted to the cover, and the shield may be rotated on the cover, within the limits set by the peg, to give varying degrees of registration plate illumination.



432/096

1	Light shield	8	Lampholder cup
2	Locating peg	9	Rear rubber mounting
3	Backplate and bush	10	Locking ring
4	Lampholder	11	Case
5	Front rubber mounting	12	Gland nut
6	Earthing ring	13	Ferrule
7	Insulating washer		

Fig 15 Registration plate light

Changing a registration plate lamp

71 The procedure for changing a registration plate lamp is as follows:

71.1 Put the tail/side switch to OFF (Fig 5).


71.2 Unscrew the three slotted hexagon headed screws securing the front cover and carefully withdraw the cover together with its gasket.

71.3 Fit a new lamp (see Table 3), and replace the cover and gasket.

71.4 Test the lamp and if it still does not function report to REME.

Convoy Light

72 The convoy light (Fig 16) is a stem-mounted unit fitted in the bottom centre of the rear door. The light has a brass screwed cap (1) which has a plain glass window to permit illumination of the convoy markings, and a small red lens (3) which permits a small red light to be visible to the driver of a closely following vehicle in convoy.



432/097

- | | | | |
|---|---------------|----|----------------------|
| 1 | Cap | 8 | Locking ring |
| 2 | Sealing ring | 9 | Case |
| 3 | Red lens | 10 | Bush |
| 4 | Body | 11 | Locking nut |
| 5 | Lampholder | 12 | Window retaining cap |
| 6 | Earthing ring | 13 | Window |
| 7 | Rubber sleeve | | |

Fig 16 Convoy light

Changing a convoy lamp

73 The procedure for changing a convoy lamp is as follows:

- 73.1 Put the convoy switch to OFF (Fig 5).
- 73.2 Remove the guard on the inside of the door, which is secured by two nuts with spring and plain washers.
- 73.3 Unscrew the knurled ring nut on the light and withdraw the lampholder (Fig 16(5)).
- 73.4 Remove the bayonet fixing lamp and fit a new lamp, (see Table 3).
- 73.5 Refit the lampholder and test the light if it still does not function report to REME.
- 73.6 Replace the guard.

Rectifier unit

Changing a main fuse

74 The procedure for changing the main fuse in the rectifier unit is as follows:


- 74.1 Put the battery switch (Fig 2(25)) to OFF
- 74.2 Remove the fuse cover, secured by eight screws.
- 74.3 Release the fuse link, secured by two setscrews with plain and spring washers.
- 74.4 Ensure that the contact surfaces are clean and free from burns.
- 74.5 Fit the new fuse link and replace the cover.
- 74.6 Check the charging circuit.

Bulkhead and locker lights

75 The bulkhead (Fig 17(9)) and locker lights are identical types and are located in the load compartment on the main bulkhead, and on the rear plate in the rear stowage compartment respectively.

76 Each light comprises a body fitted with a cover glass, gasket and guard and housing an S.C.C. lampholder, terminal block and switch.

77 The toggle type switch is located in one side of the lamp body and a cable outlet at each end.



434/019

1	Operators hatch	5	Fuel filler tube	8	Hull drain plug
2	Air inlet cover	6	Dust cap	9	Bulkhead light
3	Fuel filler cover	7	Accumulator	10	Ventilation ducting
4	Fuel tank vent				

Fig 17 Load compartment, front right corner

Changing a bulkhead or locker lamp


- 78 Put the light switch to 'OFF'.
- 79 Spring the guard from the body.
- 80 Release the securing screws and remove the glass.
- 81 Fit new lamp, replace glass and guard, and test operation.

Starter lubrication

82 The starter is lubricated with special grease on assembly and additional lubrication is unnecessary between overhauls.

Crane operator's engine switchboard

83 The crane operator's engine switchboard is mounted adjacent to and above the crane operator's crew seat.



430/20167

- | | | | |
|---|-----------------------|---|-----------------------------------|
| 1 | Auxiliary switchboard | 4 | Quadrant |
| 2 | Wingnut | 5 | Linkage to governor control lever |
| 3 | Handle | 6 | Bulkhead |

Fig 18 Crane operators switchboard and speed control

Boiling vessel sockets

84 Two sockets are provided on the distribution panel (Fig 2(4)) into which the plugs of boiling vessels may be fitted. The sockets are 'dead' unless the alternators are operating. Captive screw caps are provided for the sockets when not in use.

85 When the engine is running and a boiling vessel is in use, the connection, and disconnection, of the boiling vessel harness must be made at the boiling vessel end by means of the push-on/pull-off connector, which is specially designed to prevent burning of the pins.

Boiling vessel**CAUTION**

EQUIPMENT DAMAGE. Connection and disconnection of the harness must be made at the boiling vessel by means of the push-on/pull-off connector.

NOTE

To ensure the correct use of the boiling vessel, No 1 Mk 1 and to safeguard the element, a warning plate has been secured above the drain tap.

86 Before using the boiling vessel it should be properly secured in the stowage provided on the power pack sill

87 The boiling vessel can provide boiling water for beverages, shaving, washing, etc and at the same time heat up tinned or decanted foods. It can also be used for frying.

88 The vessel comprises a stainless steel, corrosion-free water compartment (Fig 19(14)), a removable stainless steel inner food container (7) and a removable lid (3). The water compartment and lid are insulated to reduce heat loss and to reduce the possibility of accidental burns and scalds.

89 Power is supplied via two sockets (Fig 2(4)) on the distribution panel No. 6 when the alternators are 'on-line'. When the connecting cable is coupled to the vessel socket (Fig 19(12)) a relay closes and the vessel-heating element is energized.

90 The drain tap (11) has a push button operated valve, which can be dismantled for cleaning. The dismantling does not require any special tools.

91 When the lid is closed it forms a watertight seal and the vent (1) is necessary to allow steam to escape. The vent must be kept clear at all times. The lid can be used as illustrated for the removal of the inner food container during cooking operations.

Boiling**CAUTION**

(1) EQUIPMENT DAMAGE. To avoid seriously damaging the electrical element, the inner container must be in place within the vessel when boiling less than 1.14 litres (2 pints) of water.

(2) EQUIPMENT DAMAGE. Do not make coffee, soups etc in the water compartment, as this heavy fluid will cause the drain tap to malfunction.

92 Release the toggle clips (Fig 19(13)), remove the lid, and lift out the inner food container. Pour the required measure of water into the container but **DO NOT FILL ABOVE THE 7 PINT (3.9 LITRE) LEVEL LINE ENGRAVED WITHIN THE WATER COMPARTMENT.** Replace the lid, fasten the toggle clips and engage the cable socket to the plug (12) then switch ON. Approximate times for water to boil are shown in table 9.

TABLE 10 TIMES FOR WATER TO BOIL

Quantity (1)	Time (2)
1.1 litres (2 pints)	9 minutes
1.7 litres (3 pints)	11 minutes
2.2 litres (4 pints)	13 minutes
2.8 litres (5 pints)	16 minutes
3.4 litres (6 pints)	19 minutes
3.9 litres (7 pints)	25 minutes

Making beverages

CAUTION

EQUIPMENT DAMAGE. Do not make coffee, soups etc in the water compartment, as this heavy fluid will cause the drain tap to malfunction.

93 Place tea, coffee, cocoa or soup powder, etc into the inner food container. Boil the water (Para 92), switch OFF, and disconnect the plug. Position food container under tap and draw off by pressing the tap push-button.

NOTE

The food container capacity is approximately 2.56 litres (4.5 pints).

Heating compo rations - decanted

94 Release the toggle clips, remove the lid, and lift out the inner food container. Measure 1.1 litres (2 pints) of water into the water compartment, DO NOT FILL ABOVE THE 1.1 LITRE (2 PINT LEVEL). Pour the contents of five tins of compo rations into the food container, replace the container in the vessel, then replace and secure the lid. Engage the cable socket to the plug and switch on, leave for approximately 25 minutes, for the food to heat. Switch 'OFF', disconnect the cable, and then using the out-turned clip hooks on the lid to engage the inner container-folding handle, lift the container out.

NOTE


Food left in the vessel will remain hot for up to 4 hours. The boiling water remaining in the water compartment can be used for beverages or washing etc.

Heating compo rations - undecanted

WARNING

PERSONAL INJURY. TO AVOID CANS PRESSURISING IT IS ESSENTIAL WHEN HEATING COMPO RATIONS UNDECANTED THAT THE TOPS OF THE CANS ARE PIERCED AND THAT THE TINS ARE NOT TO BE PLACED ONE ON TOP OF THE OTHER.

95 Proceed as in Para 94 but placing up to three tins of compo rations, with TOPS PIERCED, in the inner container. When heated, remove the compo ration tins, open them carefully, and serve.



432/371

- | | | | |
|---|-------------------------|----|------------------------|
| 1 | Domed vent | 10 | Warning plate |
| 2 | Lifting handle | 11 | Drain tap |
| 3 | Insulated lid | 12 | Electrical supply plug |
| 4 | Locating hooks | 13 | Lid toggle clips |
| 5 | Handle hinge posts | 14 | Water compartment |
| 6 | Foldaway lifting handle | 15 | Front hooks |
| 7 | Inner food container | 16 | Spacer |
| 8 | Seal | 17 | Plastic lining |
| 9 | Lid hook studs | 18 | Gasket |

Fig 19 Boiling vessel

Frying**WARNINGS**

- (1) **PERSONNEL INJURY. DEEP FRYING MUST NOT BE ATTEMPTED. THE OIL/FAT COULD BOIL OVER AND A SERIOUS FIRE OR INJURY RESULT**

(2) **PERSONNEL INJURY. THE BASE OF THE WATER COMPARTMENT BECOMES RED HOT WHEN FRYING, DO NOT ATTEMPT TO COOL BY POURING WATER INTO THE COMPARTMENT. SERIOUS SCALDING MAY RESULT.**

(3) **PERSONNEL INJURY. CARE MUST BE TAKEN WHEN REFILLING WITH WATER SOON AFTER FRYING. SERIOUS SCALDING MAY RESULT.**

CAUTION

EQUIPMENT DAMAGE. The vessel must not be stood on a damp surface, especially if the vessel is hot, as moisture can be drawn up into the insulation material.

96 Remove lid and inner container, drain off inner container, and ensure water compartment is clean.

97 Place a small quantity of cooking fat in the bottom of the inner food container and replace the container.

98 Engage the cable socket to the plug and switch on. At the first indication of the blue smoke arising from the melted fat, place food for frying (sausages, bacon, eggs, etc) into the hot fat and fry until cooked. Switch 'OFF' and unplug the cable. Lift out container and serve food. Approximate cooking times are:

Sausages	10 minutes
Rashers of bacon	2-3 minutes
Eggs	1-2 minutes

Boiling vessel servicing

WARNING

PERSONAL INJURY. PETROL OR OIL DERIVATIVES MUST NOT BE USED UNDER ANY CIRCUMSTANCES. THEY CAUSE SILICONE SEALS TO SWELL AND SEALS THAT HAVE SWOLLEN ARE TOXIC. ANY SEAL THAT HAS BECOME CONTAMINATED MUST BE CHANGED BEFORE THE VESSEL IS AGAIN USED.

Cleaning the inner food container

99 Remove the inner food container (Fig 19(8)) and clean by scouring, rinse, drain and wipe dry.

Cleaning the water compartment

100 Clean the water compartment (Fig 19(14)) by scouring, rinse, drain, and wipe dry. Alternatively, cleaning can be effected using boiling water to which soda or detergent has been added and running the water through the drain tap; the compartment and tap must be rinsed thoroughly before use.

Drain tap


101 The procedure to clean the drain tap is as follows:

101.1 Unscrew slotted end stop (Fig 20(4)), using a coin or suitable implement.

101.2 Remove the spring (3).

101.3 Remove the valve plunger assembly (2).

101.4 Clean all parts, dry off, and reassemble in reverse sequence.



432/100

Fig 20 Drain tap

Lid

102 The procedure to clean the drain tap is as follows:

- 102.1 Remove the domed vent cap (Fig 19(1)) and spacer (16) by unscrewing the countersunk retaining screw.
- 102.2 Unscrew the remaining two countersunk screws, which secure the handle (2), from the inner face of the lid.
- 102.3 Dismantle the lid and clean.
- 102.4 Reassemble in reverse sequence, ensuring that the vent apertures align, and the sealing gasket (18) seats correctly.

MAINTENANCE**Suppression of electrical interference to radio services**

103 The use of VHF radio sets calls for a high standard of vehicle suppression if interference is to be effectively suppressed and full advantage of the sets obtained. Good servicing of the electrical system is therefore essential and it must be remembered that although a vehicle is not carrying a radio set, it can cause interference to nearby radio sets. The important points are:

- 103.1 Make sure that there is no intermittent contact on any fuse, switch, or terminal.
- 103.2 Keep all connections and mating surfaces clean and free from paint, corrosion, and lubricant.
- 103.3 Keep all bonding strips and earth braids free from corrosion, paint, or dirt, and ensure that they are properly secured.
- 103.4 Do not paint under bonding strips or other parts intended to be in electrical contact.
- 103.5 Ensure that no cable screening is corroded or frayed and is properly earthed at both ends. Metal-to-metal contacts must be maintained throughout all screened circuits.
- 103.6 Ensure that all components, covers, and brackets are firmly secured.
- 103.7 Do not interfere with the vehicle wiring or make improvised connections.
- 103.8 Do not remove any suppression equipment that may be fitted.
- 103.9 Refrain from using any switch unnecessarily.
- 103.10 Report immediately to REME any defect, which may affect the standard of suppression of the vehicle.

CHAPTER 2-7
VEHICLE OPERATION
CONTENTS

Para

- 1 General
- Starting and driving
- 3 Pre-start checks (CAUTION)
- 4 Normal starting (CAUTION)
- 5 Emergency starting
- 6 Starting by using the batteries of another vehicle (CAUTION)
- 7 Starting by towing (WARNING)(CAUTION)
- 8 Stopping the engine
- 9 Engine emergency stop
- 10 Moving off
- 11 Changing gear (WARNING)(CAUTION)
- 15 Driving up an incline
- 16 Steering/brake levers (WARNING)
- 17 Stopping the vehicle
- 19 Parking
- 23 When being towed (WARNING)
- 25 Use of the tow bar
- 27 Towing and recovery
- 28 During towing
- 31 During recovery
- 34 Preparation for deep wading and fording
- 35 Deep wading and fording
- 37 Servicing after deep wading and fording

Table

Page

- 1 Engine gear ranges 14
- 2 Gears and permissible downshift speeds..... 14


Fig

Page

- 1 Driver's compartment..... 2
- 2 Driver's controls and instruments 3
- 3 Radio distribution box 4
- 4 Engine/transverse gearbox dis-connector control handle 5
- 5 Gear range selector 6
- 6 Steering and accelerator linkage lubricators 7
- 7 Distribution panel No. 6 Mk1 8
- 8 Driver's switchboard 9
- 9 Instrument panel 9
- 10 Engine speed hand control 13
- 11 Rear of vehicle 16
- 12 Front of vehicle 17
- 13 Rear stowage door 19
- 14 Exhaust pipe and extension 19
- 15 Hull drain points 21/22

GENERAL


- 1 This chapter provides a reference for basic vehicle operation, containing instructions on the main automotive functions. It is essential that the operator is conversant with the equipment and the contents of the previous chapters, before attempting to start the engine or drive the vehicle.
- 2 Driver's controls, instruments and layout of the driver's compartment are illustrated in figures 1 and 2.



430/20162

- | | | | |
|---|---------------------------------------|----|---------------------------------------|
| 1 | Power pack access plate upper section | 6 | Accelerator pedal |
| 2 | Wiper/IR sight switch | 7 | Engine fuel stop control |
| 3 | Steering/brake levers | 8 | Engine speed hand control |
| 4 | Driver's turn light switchboard | 9 | Gear range selector lever |
| 5 | Instrument panel | 10 | Power pack access plate lower section |

Fig 1 Driver's compartment



- | | | | |
|---|----------------------------------|----|-------------------------------------|
| 1 | Fire warning light | 7 | Automotive batteries |
| 2 | Interior light | 8 | Distribution link box |
| 3 | Instrument panel | 9 | Distribution link box warning light |
| 4 | Distribution panel | 10 | Driver's switchboard |
| 5 | Firewire control box test switch | 11 | Steering/brake lever |
| 6 | Firewire control box | 12 | Horn push |
| | | 13 | Parking control button |

Fig 2 Driver's controls and instruments

STARTING AND DRIVING

Pre start checks

CAUTION

EQUIPMENT DAMAGE. If the engine is started with the distribution link box warning light illuminated, internal damage to the generating system will result.

3 To carry out pre start checks, proceed as follows:



3.1 Ensure that all necessary servicing has been completed as required by the Maintenance Schedule, ASEP 2350-T-250-601 refers.

NOTE

None of the pre start checks detailed override any of the checks detailed in the Maintenance Schedule Running Checks Before Use, AESP 2350-T-250-601 refers.

3.2 Put the radio distribution box battery switch (Fig 3(3)) to 'ON'. If the radio batteries are disconnected do not put this switch to 'ON'.

3.3 Check that the external charge switch (Fig 3(5)) is at 'OFF' and that the GEN warning light (Fig 3(4)) glows.




430/20164

- | | | | |
|---|-------------------------|---|--------------------------|
| 1 | Mounting bracket | 5 | External charging switch |
| 2 | VUDT | 6 | Fuse cover |
| 3 | Radio battery switch | 7 | Terminal cover |
| 4 | Generator warning light | | |

Fig 3 Radio distribution box


3.4 If the temperature is sub-zero, disengage the engine/transverse gearbox disconnector by pushing the control handle (Fig 4(4)) down.



432/048

Fig 4 Engine/transverse gearbox dis-connector control handle

- 3.5 Check that the parking brakes are on (Para 26).
- 3.6 Switch 'ON' the radio and intercommunications and fit headsets (IETP TBA).
- 3.7 Adjust the driver's seat (Chap 2-2).
- 3.8 Adjust the accelerator pedal (Fig 5(1)). Slacken the knurled nut (4) until the toothed washer (3) is free, move the pedal to the required position on the quadrant (2), secure by re-tightening the knurled nut.
- 3.9 Once the accelerator pedals have been adjusted fit driver's safety harness.
- 3.10 Adjust the driving mirrors to obtain a clear view, rearwards.
- 3.11 Check that the gear range selector lever (Fig 6(1)) is at neutral.
- 3.12 Put the distribution panel battery switch (Fig 7(2) to 'ON' and check that the warning light (Fig 2(10)) on the distribution link box does not glow. If it glows, report immediately to REME.
- 3.13 Put the engine switch to 'ON' (see Fig 8(6)).
- 3.14 Check that the OIL and GENERATOR warning lights glow (Fig 8) and that the fuel gauge, coolant thermometer and gearbox oil thermometer register (Fig 9). If any of the lights do not glow, test the lamp with the engine switch 'ON'. The light should glow when the lens is pressed. If the lamp glows constantly, the circuit is at fault and must be rectified before proceeding; refer to Table 3 Chap 2-7 of this publication.




432/088

- 1 Gear range selector lever
- 2 Engine speed hand control

- 3 Wing nut


Fig 5 Gear range selector



432/061

- | | | | |
|---|-------------------|----|-------------------------------------|
| 1 | Accelerator pedal | 7 | Accelerator cross-shaft lubricators |
| 2 | Quadrant | 8 | Steering linkage lubricators |
| 3 | Toothed washer | 9 | Steering/brake lever return spring |
| 4 | Knurled nut | 10 | Steering/brake levers |
| 5 | Spring | 11 | Fuel stop control pedal |
| 6 | Guard | | |

Fig 6 Steering and accelerator linkage lubricators




432/041

1 Inter-vehicle starting socket

2 Battery master switch


Fig 7 Distribution panel No. 6, Mk 1



432/456

- | | | | |
|---|--------------------------------|---|--------------------------|
| 1 | Turn light switch | 5 | Starter switch |
| 2 | Main indicator (GEN) | 6 | Engine switch |
| 3 | Low oil pressure warning light | 7 | Main beam warning light |
| 4 | External lighting switchboard | 8 | Turn light warning light |

Fig 8 Driver's switchboard



432/085

- | | | | |
|---|---------------------------|----|-------------------------------------|
| 1 | Tachometer | 6 | Panel lights switch |
| 2 | Panel light | 7 | Warning temp indicating mark |
| 3 | Coolant temperature gauge | 8 | Gearbox oil temp gauge |
| 4 | Fuel gauge | 9 | Fuse |
| 5 | Ammeter | 10 | Speedometer trip reading reset knob |
| | | 11 | Speedometer |

Fig 9 Instrument panel

Normal starting**CAUTION**

EQUIPMENT DAMAGE. Running the engine for long periods with the engine/traverse gearbox dis-connector clutch out of engagement may damage the clutch.

4 Carry out normal start procedure as follows:

4.1 Carry out the pre check checks (Para 3 refers)

4.2 Fully depress the accelerator pedal (Fig 6(1)), lift the spring-loaded cover (Fig 8(5)) and operate the starter switch, release the starter switch and the accelerator pedal as soon as the engine starts.

4.3 If the engine does not start in five or six seconds, release the switch and pedal, wait ten seconds then try again. Prolonged use of the starter will result in its cutting out due to overheating and the starter will not operate until it cools.

4.4 Check that the OIL and both GEN warning lights (Fig 8(2 & 3)) and Fig 3(3)) go out as the engine speed is increased, also check that the warning light on the distribution link box glows dimly. If any fail to do so, stop the engine immediately and report to REME.

NOTE

Due to wide pressure tolerance, the oil warning light may not go out until the engine speed (Fig 9(1)) is increased to approximately 1000 rev/min.

4.5 Fully apply both steering/brake levers, move the gear range selector to the 3-6 positions, and run the engine at 1000 rev/min as displayed on the rev counter (Fig 9(1)) to bring the engine up to working temperature.

4.6 If the transverse gearbox has been disconnected run the engine for four minutes, then STOP THE ENGINE and re-engage the engine/transverse gearbox using the dis-connector control handle (Fig 4(4)). Re-start the engine.

4.7 When coolant temperature reaches, 90.5 to 93.3 deg C (195 to 200 deg F) select neutral and adjust idling speed to 800 rev/min (tachometer) using the engine hand speed control (Fig 5).

4.8 Check the coolant temperature (Fig 9(3)) at frequent intervals while the engine is running. The coolant operating temperature will vary according to operating conditions but, in areas where normal ambient temperatures prevail (i.e. Europe), the maximum temperature should not exceed 94 deg C (200 deg F). Where high ambient temperatures are encountered, REME advice should be obtained and the coolant temperature must never be allowed to exceed 105 deg C (220 deg F).

NOTE

To keep the radio batteries fully charged the radio battery switch must be kept in the ON position whenever the engine is running.

Emergency starting

5 If the automotive batteries are in such low state of charge that they cannot operate the starter motor efficiently, a slave battery carrier or batteries of a similar capacity on another vehicle can be used to start the engine.

Starting by using the batteries of another vehicle

CAUTION

EQUIPMENT DAMAGE. The engine must not be run with the automotive batteries disconnected.

- 6 If engine starting is unsuccessful due to discharged vehicle batteries, proceed as follows;
 - 6.1 Position the donor vehicle so that the inter-vehicle cable can be plugged into both inter-vehicle sockets (Fig 7(1)).
 - 6.2 Disconnect the transfer gearbox dis-connector lever.
 - 6.3 Ensure that the battery switches of the vehicles are turned to the 'OFF' position.
 - 6.4 Remove the protection cap (Fig 7(1)) from the inter-vehicle starting socket on each vehicle and connect the inter vehicle cable to the inter vehicle socket of each vehicle.
 - 6.5 Turn the battery switches, to the 'ON' position, then start and run the engine of the donor vehicle at fast idling speed (approx 1000 rev/min).
 - 6.6 Attempt to start the vehicle.
 - 6.7 When the engine has started and running smoothly (or if the engine fails to start), stop the engine of the donor vehicle and set the 'Battery Master' switch of the donor vehicle to 'OFF'
 - 6.8 Dis-connect the inter-vehicle cable, firstly from the recipient vehicle and then the donor vehicle. Replace the socket caps and stow the cable.
 - 6.9 Re-engage the transfer gearbox dis-connector lever.
 - 6.10 If the engine fails to start, refer to the failure diagnosis tales in Chap 2-8 of this publication.

Starting by towing**WARNING**

PERSONNEL INJURY. WHEN TOW STARTING WITH A CHAIN, WIRE ROPE OR KINETIC ENERGY ROPE, BOTH DRIVER AND COMMANDER MUST BE CLOSED DOWN. ONCE THE VEHICLE HAS STARTED, THE VEHICLE IS TO BE HALTED IN A SAFE PLACE AND THE TOWING EQUIPMENT DISCONNECTED

CAUTIONS

- (1) **EQUIPMENT DAMAGE.** The engine must not be run with the automotive batteries disconnected.
- (2) **EQUIPMENT DAMAGE.** The 'towed/dead' vehicle must be towed in as near a straight line as possible (minimum).
- (3) **EQUIPMENT DAMAGE.** When the engine of the 'towed/dead' vehicle starts, stop both vehicles immediately and dis-connect the tow equipment.
- (4) **EQUIPMENT DAMAGE.** If using chains or ropes to tow start a vehicle, and drivers have to baton down, the 'towed/dead' vehicle and the towing vehicle must have inter-vehicle communications.

7 To start the engine by towing proceed as follows;

- 7.1 Position the towing vehicle and connect the towing ropes (diagonally crossed) or 'A' Frame (Hollebones).
- 7.2 Ensure that the towing vehicle is in the lowest forward gear.
- 7.3 Put the battery switches and the engine switch to 'ON'.

NOTE


If the radio batteries are disconnected, do not put the radio battery switch to 'ON'.

- 7.4 Put the gear range selector lever to neutral.
- 7.5 Release the brakes on the towed vehicle and commence towing.
- 7.6 When the vehicle attains a speed of 16 km/h (10 mph), engage 3-4 range and when the engine starts, signal the towing vehicle to stop immediately, return the gear range selector lever to neutral and apply the vehicle brakes. Keep the engine running at approximately 1000 rev/min until it is warmed up and running satisfactorily. Check that the warning generator lights go out.
- 7.7 Remove the towing gear.

Stopping the engine

8 To stop the engine proceed as follows;

- 8.1 Slacken the wing nut (Fig 12(1)) on the engine speed hand control (2) and turn the knurled head of the screw to increase the engine speed to 1000 rev/min, run the engine at this speed for a minimum of 3 minutes, or until the coolant temperature drops to 185 deg F, whichever is the longer period.
- 8.2 Reset the engine speed with the hand control to 800 rev/min, tighten wing nut.
- 8.3 Switch off the engine (Fig 8(6)).



432/087a

1 Wing Nut

2 Engine speed hand control

Fig 10 Engine Speed Hand Control

Engine emergency stop

9 In the event of a fault, which causes the engine to 'run away', depress the engine fuel stop control pedal (Fig 6(11)). Report to REME immediately, the vehicle should be VOR.

Moving off

10 To move off proceed as follows;

10.1 The prevailing driving conditions must determine the gears to be used and these selected by the position of the gear range selector lever.

NOTE

When driving on public roads, ensure that the amber rotating beacon is switched 'ON' to warn other road users of a slow moving vehicle

10.2 Position the gear range selector lever in the required range; see Table 1.

NOTE

To engage reverse gear, pull the knob on the side of the selector lever bracket, move the lever to the position marked 'R' and release the knob.

10.3 Release the parking brake controls by pulling back on the steering/brake levers.

10.4 Allow the steering/brake levers to move to the forward position.

10.5 Gradually accelerate the engine speed by depressing the accelerator pedal (Fig 6(1)). As the engine speed increases, the drive will be taken up and the vehicle will move off smoothly, the gears changing automatically within the range selected to suit engine conditions. To decrease the engine speed release the accelerator pedal.

TABLE 1 ENGINE GEAR RANGES.

Terrain and Driving conditions	Gear range	
	Road	Cross country
Light traffic	3-6	-
Fairly heavy traffic	3-5	-
Heavy traffic	3-4	-
Light ground	-	3-5
Heavy ground	-	3-4
Speeds below 8 kph (5 mph)	1-2	1-2
Manoeuvring in confined space	1-2	1-2
Steep gradient (ascending or descending)	1-2	1-2
Undulating terrain	3-5	3-5
Reversing	R	R

Changing gear**WARNING**

ROAD SAFETY HAZARD. DEPRESSING THE ACCELERATOR FULLY TOO RAPIDLY CAN CAUSE A DOWN CHANGE AND RELEASING IT QUICKLY, AN UP CHANGE. THE CONTINUAL EMPLOYMENT OF THIS TYPE OF DRIVING AND CAN BE DANGEROUS WHEN DRIVING IN TRAFFIC.

CAUTION

EQUIPMENT DAMAGE. Serious damage can be caused to the gearbox if downshifts are made manually when the vehicle is travelling at speeds exceeding those given in Table 2 below.

11 Up and down gear changes are made automatically in the gearbox, within the range selected, to suit engine conditions. Incorrect operation of the accelerator pedal can, however, create abnormal conditions, which cause automatic changes to occur more frequently than conditions necessitate. Depressing the accelerator fully too rapidly can cause a down change and releasing it quickly, an up change. The continual employment of this type of driving can result in damage to the gearbox and can be dangerous when driving in traffic.

12 Always endeavour to operate the accelerator with a firm, steady movement as when driving a vehicle fitted with a manually operated gear change mechanism.

TABLE 2 GEARS AND PERMISSIBLE DOWNSHIFT SPEEDS.

Gear range		Maximum permissible downshift speed
From	To	
3-6	3-5	35 km/h (22 mph)
3-5	3-4	25 km/h (16 mph)
3-4	1-2	13 km/h (8 mph)

13 Before descending a steep hill, use the brakes to slow the vehicle speed, select the appropriate gear range as defined in Table 1. Descend the hill using the accelerator pedal to adjust engine speed and use the brakes intermittently to control the speed of the vehicle.

14 Before attempting to engage reverse gear, stop the vehicle.

Driving up an incline

15 To prevent crankcase pressurization it has been found necessary to re-introduce an open type breather on the K60 engine. When driving up an incline the following advise is given to users to avoid oil spillage from the crankcase breather:

- 15.1 DO NOT exceed an engine speed of 3000 rev/min when driving up a 1 in 3 (18½ deg) slope.
- 15.2 DO NOT exceed an engine speed of 2000 rev/min when driving up a 1 in 2 (26½ deg) slope.

NOTE

There is NO restriction on engine speed for slopes less than 1 in 3.

Steering/brake levers

WARNING

PROLONGED APPLICATION OF THE STEERING/BRAKE LEVERS COULD LEAD TO OVERHEATING OF THE STEERING/BRAKE SYSTEM, WHICH COULD CAUSE PREMATURE FAILURE.

16 The vehicle is steered by pulling back on the relevant steering/brake levers (Fig 1(3)). The left tiller will turn the vehicle left and right tiller will turn the vehicle right, which will apply the brake band in the steering unit. Continuous application of the steering levers, during normal driving, could cause the steering drum to overheat. This could cause damage to both the brake drum and brake bands, therefore when it is intended to turn the vehicle it should be steered by pulling hard on the relevant tiller (left or right) and then releasing (i.e. turning a corner should be done in a series of arcs). Whilst manoeuvring or negotiating tight turns the steering lever is to be applied fully and then released when the manoeuvre is complete. Engine speed is to be increased to provide sufficient power to complete the manoeuvre. When both steering/brake levers are applied simultaneously the vehicle can be slowed, stopped or parked.

Stopping the vehicle

17 Release the accelerator pedal and apply the brakes by pulling back both steering/brake levers (Fig 2(12)) simultaneously; apply and release the brakes intermittently until the vehicle is stopped. Simultaneous operation of both levers causes the vehicle to slow down and the stoplights to come on, while greater pressure sustained on the levers causes the vehicle to stop. Only when essential, as in an emergency, should the levers be held continually.

18 If the vehicle is to remain stationary with the engine running, fully apply the brakes by pulling both steering/brake levers simultaneously rearwards and engage the parking controls (Fig 2(14)) in the top of each lever. Put the gear range selector lever to neutral.

Parking

19 Stop the vehicle, apply the brakes to the hard on position and engage the parking controls in the top of each lever. The levers are locked in the on position, when parking, by means of the pawl and ratchet mechanism, after depressing the plungers. A slight backward movement given to the levers causes the pawls to be released by the reaction of the plunger return springs. Whenever possible, park the vehicle on level ground. If sloping ground is unavoidable, position the vehicle across the slope. Scotch the road wheels using scotch blocks (AESP 2350-T-250-741).

- 20 Switch 'OFF' the engine (Para 8).
- 21 Put the automotive battery switch to 'OFF' (Fig 7(2)).
- 22 Put the radio battery switch to 'OFF' (Fig 3(3)).

When being towed**WARNING**

PERSONAL INJURY. WHEN TOWING WITH A CHAIN, WIRE ROPE OR KINETIC ENERGY ROPE, BOTH DRIVER AND COMMANDER'S HATCHES MUST BE CLOSED DOWN.

23 In an emergency the vehicle may be towed forward up to half a mile without too serious a risk of causing damage. The vehicle must never be towed in reverse. Like or other FV430 series vehicles can be used for towing, using the tow ropes of both vehicles, with the ropes crossed diagonally and connected to the towing eyes (Fig 11(2) and Fig 12(2)).

24 If towing for a greater distance, or if the brakes are inoperative, report for instructions.


NOTE

The maximum towing speed must not exceed 16 kph (10 mph).

Use of the tow bar

25 The tow bar and hook are of comparatively light construction and should be used only for towing reasonable loads and never for recovery purposes. For recovery, the towing eyes under the towing brackets should be used.

26 Before fitting the tow bar, the rear stowage compartment door must be closed and secured. The bar can then be positioned in the brackets disposed each side of the door and retained by the drop-in pins provided.




430/20012

1 Tow bar bracket

2 Towing eye

Fig 11 Rear of vehicle



430/20172

1 Steering unit access cover

2 Towing eyes

Fig 12 Front of vehicle

Towing and recovery

27 It may be necessary for the vehicle to be used for towing and recovery of other FV430 series vehicles in the absence of a recovery vehicle. If this situation does arise, the following points must be observed.

During towing

28 Gear range selector 1-2 or 3-4 when appropriate

29 Speeds:

29.1 Cross country 8 km/h (5 mph) (maximum)

29.2 Road 16 km/h (10 mph) (maximum)

30 Gearbox temperature must not exceed 121 deg C (250 deg F).

During recovery


- 31 Gear range selection 1-2 only.
- 32 Speed limited to 3 to 5 km/h (2 to 3 mph).
- 33 Gearbox temperature must not exceed 121 deg C (250 deg F).

NOTE

It is probable that recovery will be limited by track slip or excessive gearbox temperature.

Preparation for deep wading and fording

- 34 To prepare the vehicle for deep wading and fording the following procedures must be carried out:
 - 34.1 Lubricate the following until grease (AESP 2350-T-250-601 refers) is forced through the labyrinth at the back of the hub
 - 34.1.1 Final drive labyrinths (refer to Chap 2-4).
 - 34.1.2 Track support guide rollers (refer to Chap 2-4).
 - 34.2 Lubricate the axle arm bearings by injecting 15 pumping strokes at each nipple (AESP 2350-T-250-601 refers).
 - 34.3 Lubricate each track adjuster pivot arm bearing (AESP 2350-T-250-601 refers).
 - 34.4 Check the security and sealing of each plug and access plate in the hull bottom plates. (Fig 15).
 - 34.5 Check the fitting and sealing of the steering unit access cover (Fig 12(2)) and the fire extinguisher equipment remote control handles.
 - 34.6 Check the fitting and security of the corrugated hose and lockout system hoses at each shock absorber.
 - 34.7 Seal the rear stowage compartment door (Fig 13(1)) by tightening the four turn catches.
 - 34.8 Check the security of the ventilation filter door locking catches and the sealing clamps.
 - 34.9 Fold the track pad deflectors (mud flaps) and engage them on the retaining hooks.
 - 34.10 Slacken the two brackets (Fig 14(4) and clamp (2) securing the exhaust pipe and turn the pipe until the elbow is upward. Fit the exhaust pipe extension (7) securing it to the exhaust pipe with the clamp (9). Fit the support struts (8). Tighten the brackets and clamps.
 - 34.11 Raise the catwalks.




430/20013

1 Clamping plates

2 Rear storage door

Fig 13 Rear storage door



434/080a

- 1 Silencer
- 2 Clamp
- 3 Fixed fire extinguisher cover flap
- 4 Exhaust pipe brackets
- 5 Extension pipe brackets

- 6 Exhaust cover plate
- 7 Extension
- 8 Support struts
- 9 Clamp

Fig 14 Exhaust pipe and extension

Deep wading and fording

35 Where possible, select an entry point to the water where the approach slope is gradual and when in convoy, allow the vehicle in front to get clear before following.

36 Engage the 1-2 range in the gearbox and approach at an angle, which will keep the vehicle as level as possible. Care must be taken when entering the water that the slope is not too steep or the speed too fast or the vehicle may be swamped; use the engine as a brake when descending the bank.

Servicing after deep wading or fording


37 As soon as possible after flotation, the following servicing must be carried out.

37.1 Remove the hull drain plugs (Fig 15)) and allow any water to drain. Replace and tighten the plugs after checking the plugs and washers for serviceability.

37.2 Check that the oil level in the final drives, road wheels, track adjusting wheels and steering unit has risen. If the presence of water is suspected, drain and refill with clean oil of the correct grade. (AESP 2350-T-250-601 refers)

37.3 Lubricate the final drive labyrinths and track support guide rollers until clean grease is forced from the labyrinth. Lubricate the axle arms and track adjuster pivot bearings.

37.4 Report any signs of faults.



430/2006

- | | | | |
|---|--------------------------------|----|--|
| 1 | Storage locker drain plug | 7 | Gearbox drain access plug |
| 2 | Locker plug | 8 | Driver's compartment drain plug |
| 3 | Load compartment drain plug | 9 | Steering unit drain access plate |
| 4 | Storage compartment drain plug | 10 | Engine oil drain access plug |
| 5 | Fuel drain valve access plate | 11 | Steering unit oil tank and coolant drain access plug |
| 6 | Escape hatch | | |

Fig 15 Hull drain points

CHAPTER 2-8
FAILURE DIAGNOSIS
CONTENTS

Para

- 1 General
- 2 Fire alarm system
- 3 Engine
- 4 Starting circuit
- 5 Charging circuit
- 6 Driving lights and horn
- 7 Engine auxiliaries
- 8 Auxiliaries
- 9 Crane

Table

Page

1	Fire alarm system- failure diagnosis	1
2	Engine - failure diagnosis	2
3	Starting circuit - failure diagnosis	3
4	Charging circuit - failure diagnosis	4
5	Driving lights and horn - failure diagnosis	5
6	Engine auxiliaries - failure diagnosis	6
7	Auxiliaries - failure diagnosis	6
8	Crane - failure diagnosis	9

GENERAL

1 This chapter details the operator actions, which can be taken to isolate and rectify failures to equipments and systems during vehicle operations. It is assumed that all routine maintenance tasks (Category 601 of the Variant Octad) and all operating procedures (Chap 2-7) have been carried out correctly.

FIRE ALARM SYSTEM

2 The fire alarm system fails to operate correctly, proceed as detailed in Table 1.

TABLE 1 FIRE ALARM SYSTEM - FAILURE DIAGNOSIS

Serial (1)	Symptoms (2)	Probable causes (3)	Action (4)
1	No warnings when test switch is operated (other circuits satisfactory).	Check circuit breakers C and J in distribution panel No. 6 Mk 1. Check security of harnesses throughout system.	Report to REME. Report to REME.
2	No buzz in a connected headset, horn sounds.	Fit another headset. Check that the intercom is switched on.	Report to REME. Report to REME.
3	Warnings continue when test switch is released.		Proceed as detailed in Chap 2-1. (continued)

TABLE 1 FIRE ALARM SYSTEM FAILURE - DIAGNOSIS (continued)

Serial (1)	Symptoms (2)	Probable causes (3)	Action (4)
4	Lights do not flash when test switch is operated, horn sounds.	Circuit breaker C. Check lamps. Check security of harnesses throughout system. Flasher unit possibly faulty.	Report to REME. Report to REME. Report to REME. Report to REME.
5	Horn no sound, lights flash.	Check horn connections.	Report to REME.

ENGINE

3 The engine fails to operate correctly, proceed as detailed in Table 2.

TABLE 2 ENGINE - FAILURE DIAGNOSIS

Serial (1)	Symptoms (2)	Probable causes (3)	Action (4)
1	Engine fails to start.		Check starting circuit (Table 3 refers).
2	Engine will not fire.	Air in the fuel system. Pipe connections loose. No fuel at injectors. No fuel at injectors. Choked feed pipes. Loose connections in pipe runs. Faulty electric fuel pump or dirty fuel filter. Fuel filters obstructed. Air cleaner obstructed. Fuel injection pump timing incorrect. Faulty injection pump.	Vent fuel system. Tighten pipe connections. Check fuel in tank. Check cock is turned on. Clear pipes. Tighten connections. Report to REME. Renew filter elements. Clean the air cleaner. Report to REME. Report to REME.
3	Engine fails to pick up.	Faulty fuel supply. Air cleaner obstructed. Faulty fuel injectors.	Vent fuel system. Clean the air cleaner. Report to REME.
4	Engine misfires.	Air in the fuel system. Fractured injector pipe. Faulty injector. Faulty fuel injector pump.	Vent fuel system. Renew pipe. Loosen feed pipe to each injector. The faulty injector will be indicated when no change occurs in running of engine. Report to REME.

(continued)

TABLE 2 ENGINE - FAILURE DIAGNOSIS (continued)

Serial (1)	Symptoms (2)	Probable causes (3)	Action (4)
5	Low oil pressure (relatively sudden pressure drop compared with progressive drop due to worn bearings).	Low oil level. Air filters choked. Faulty relief valve. Faulty oil pressure switch. Oil temperature high.	Check and fill up. Change filter elements. Report to REME. Report to REME. See Serial 6.
6	Engine overheats.	Loss of coolant. Obstructed air passages and radiator matrix. Fouled coolant system. Faulty thermostat. Fuel injection pump timing incorrect.	Check coolant level and drain cock. Check for leaks. Clear air passages and matrix. Drain. Clean and refill system with correct coolant. Report to REME. Report to REME.
7	Low power.	Fuel injection pump timing incorrect. Faulty injectors. Air cleaner obstructed. Seized air scavenge blower rotors.	Report to REME. Report to REME. Clean air cleaner. Report to REME.
8	Low fuel pressure.	Faulty fuel pump. Leak in fuel suction line. Fuel filter obstructed.	Report to REME. Check for loose connections or fouling. Renew filter element.
9	Black smoke from exhaust.	Air cleaner obstructed. Fuel pump timing incorrect. Seized air scavenge blower rotors. Over fuelling.	Clean air cleaner. Report to REME. Report to REME. If Max. Fuel stop is damaged, renew pump.

STARTING CIRCUIT

4 Vehicle fails to start, proceed as detailed in Table 3.

TABLE 3 STARTING CIRCUIT - FAILURE DIAGNOSIS

Serial (1)	Symptoms (2)	Probable causes (3)	Action (4)
1	GEN and OIL warning lights fail to glow when engine switch is put to ON.	Incorrect switches made. Blown fuse or popped circuit breaker. Loose battery connection.	Check that the automotive battery switch is ON. Check circuit breakers K and M in distribution panel No. 6 Mk 1. Check battery connections. (continued)

TABLE 3 STARTING CIRCUIT - FAILURE DIAGNOSIS (continued)

Serial (1)	Symptoms (2)	Probable causes (3)	Action (4)
2	Starter fails to rotate when starter switch is operated.	Gear range selector level in incorrect position. Loose battery connection. Low battery charge.	Check that gear range selector lever is in neutral. Check battery connections. Check that the batteries are not discharged.
3	Starter not rotating fast enough.	Low battery charge. Loose battery connection.	Check that the batteries are not partially discharged (Warning lights go dim). Check battery connections
4	Starter rotates but not the engine.		Report to REME.

CHARGING CIRCUIT

5 The charging circuit fails to operate correctly, proceed as detailed in Table 4.

TABLE 4 CHARGING CIRCUIT - FAILURE DIAGNOSIS

Serial (1)	Symptoms (2)	Probable causes (3)	Action (4)
1	GEN warning light fails to glow when engine switch is put to ON.	Incorrect switches made. Lamp broken. Loose connection.	See Table 3. Replace lamp. Check centre contact of lampholder.
2	Ammeter reading zero and warning lights remain ON.	Main fuse in rectifier unit blown. Loose connection.	Report to REME. Check security of cable harnesses in combined charging circuits, i.e. rectifier unit, power pack junction, distribution link box.
3	Warning lights remain ON ammeter showing charge.	Faulty relay in distribution panel.	Report to REME.
4	Warning light goes out, ammeter does not show charge.	Faulty ammeter.	Report to REME.

(continued)

TABLE 4 CHARGING CIRCUIT - FAILURE DIAGNOSIS (continued)

Serial (1)	Symptoms (2)	Probable causes (3)	Action (4)
5	Low charging rate (batteries gradually become discharged).		Report to REME.
6	High charging rate (lights excessively bright when engine is running).		Report to REME.

DRIVING LIGHTS AND HORN

6 Faults on driving lights and horn proceed as detailed in Table 5.

TABLE 5 DRIVING LIGHTS AND HORN - FAILURE DIAGNOSIS

NOTE

For Serial 2, 3, and 4 in Table 5, the following should also be checked. Check that the blackout and convoy switches are both OFF. The lights are inoperative if the gear range selector lever is in the neutral position and check the action of selector lever switch.

Serial (1)	Symptoms (2)	Probable causes (3)	Action (4)
1	No lights on when distribution battery switch and lighting switches are ON.	Popped circuit breaker. Loose battery connection. Loose connection.	Check circuit breaker B in distribution panel No. 6 Mk 1. Check the automotive battery connections. Check security of the connecting harnesses at the distribution panel and switchboard.
2	Rear turn lights not operating.	Loose connection.	Check connection at trailer relay.
3	Turn lights warning light not operating correctly.	Broken lamp.	Check the front and rear turn light lamps.
4	Stop lights not operating correctly.	Incorrect switches made.	Check the action of the switches operated by the steering levers.
5	Individual lights not working correctly.	Blown lamp.	Check the lamp.
6	Horn not working correctly.	Popped circuit breaker. Loose connection.	Check circuit breaker B in distribution panel No. 6 Mk 1. Check connections.

ENGINE AUXILIARIES

7 Faults on engine auxiliaries proceed as detailed in Table 6.

TABLE 6 ENGINE AUXILIARIES - FAILURE DIAGNOSIS

Serial (1)	Symptoms (2)	Probable causes (3)	Action (4)
1	Engine auxiliaries fail to function when the engine switch is ON.	Popped circuit breaker. Loose connection.	Check circuit breakers K and M in distribution panel No. 6 Mk 1. Check security of the connecting harnesses at the distribution panel and switchboard.
2	Oil pressure warning light not working.	Blown lamp.	Check the warning lamp.
3	Instruments not working.		Report to REME.
4	Instrument panel lights not working.	Blown fuse. Blown lamp. Dimmer switch.	Check fuse in instrument panel. Check lamps. Check that the dimmer switch is ON.

AUXILIARIES

8 Faults with the auxiliary systems proceed as detailed in Table 7.

TABLE 7 AUXILIARIES - FAILURE DIAGNOSIS

Serial (1)	Symptoms (2)	Probable causes (3)	Action (4)
1	Interior lights not working correctly.	Incorrect switches made. Popped circuit breaker.	Check that switch No. 2 on auxiliary junction box is ON. Check circuit breaker A in distribution panel No. 6 Mk 1.
2	Driver's lights and two lights in personnel compartment not working correctly.	Loose connection.	Check security of appropriate cable harness (plug 5 on auxiliary junction box). (continued)

TABLE 7 AUXILIARIES - FAILURE DIAGNOSIS

Serial (1)	Symptoms (2)	Probable causes (3)	Action (4)
3	Commanders and two lights in personnel compartment not working correctly.	Blown fuse. Loose connection.	Check fuse F4 in auxiliary junction box. Check security of appropriate cable harness (plug 6 on auxiliary junction box).
4	Individual lights not working correctly.	Blown lamp.	Check lamp.
5	Exterior lights not working correctly.	Incorrect switches made. Loose connection. Loose connection. Blown fuse or popped circuit breaker.	Check that the EXT LIGHTING switch on accessories control box or on distribution panel No. 6 Mk 1, is ON. Check the ventilation batteries and connections. Check security of cable harness (socket 7 on accessories control box or socket 17 on distribution panel No. 6 Mk 1). Check fuse 3 in accessories control box or circuit breaker F in distribution panel No. 6 Mk 1.
6	Ventilation fan not working correctly.	Incorrect switches made. Blown fuse. Loose battery connections. Low battery.	Check that the fan switch on accessories control box or on distribution panel No. 6 Mk 1, is ON. Check FAN fuse 1 in accessories control box or circuit breaker G. Check ventilation battery connection particularly the earth connection. Check that the ventilation batteries are not discharged.

(continued)

TABLE 7 AUXILIARIES - FAILURE DIAGNOSIS (continued)

Serial (1)	Symptoms (2)	Probable causes (3)	Action (4)
7	Smoke dischargers not working correctly.	Popped circuit breaker. Loose connection.	Check circuit breaker A in distribution panel No. 6 Mk 1. Check grenade connections.
8	Periscope wiper not working correctly.	Loose connection Popped circuit breaker.	Check that harness is plugged into suppressor unit. Check circuit breaker A in distribution panel No. 6 Mk 1.
9	Boiling vessel not working correctly.	No power. Loose connection.	Check that alternators are charging (warning light out, ammeter registering). Check that plug of vessel is correctly inserted in socket.
10	Rotating beacon not working – no other lights operating.		Proceed as Table 5 Serial 1.
11	Rotating beacon not working – all other lights operating.	Loose connection. Broken lamp. Beacon assembly faulty.	Check that plug of beacon is correctly inserted in fascine lighting socket. Check the lamp Renew beacon assembly.
12	Boiling vessel fails to heat up.	Cable not connected correctly. Battery master switch not switched ON. Engine is not running. Boiling vessel can only operate when the alternators are on line. Engine running, ammeter not registering. Engine is not running. Boiling vessel can only operate when the alternators are on line.	Ensure connections at both ends of cable are correctly made. Ensure battery master switch is switched ON. Start engine. Report to REME. Start engine.

CRANE

9 Faults with the crane system proceed as detailed in Table 8.

TABLE 8 CRANE FAILURE DIAGNOSIS

Serial (1)	Symptoms (2)	Probable causes (3)	Action (4)
1	Crane fails to lift or only partially lifts load.	Load not within maximum weight and radius operating conditions. Low oil level. Oil filter choked. Seals or valves. Leak in pressure circuits.	Check load and radius at which lifting. Top up. Renew element. Report to REME. Report to REME.
2	Load lowers with controls in neutral position.	Pilot operated check valve faulty.	Report to REME.
3	Boom locks during lowering.	Reflux valves faulty. Hose failure check valve faulty.	Report to REME. Report to REME.
4	Crane movement erratic.	Low oil level. Oil filter choked. Faulty pump. Pivots seized. Seals or valves damaged. Engine speed low.	Top up. Renew element. Report to REME. Report to REME. Report to REME. Increase speed.

CHAPTER 3
CRANE AND HYDRAULIC LOCKOUT SYSTEM

CONTENTS

Para

	Crane and hydraulic lockout system
1	Crane
4	Hydraulic lockout system
6	Preparing the crane for hoisting
16	Crane standby position
18	Operating the crane
19	Stowing the crane
	Servicing
29	Checking and topping up the reservoir oil
35	Changing the oil
42	Changing the oil filter element
54	Crane lubrication
56	Crane pump drive housing
57	Checking the oil level and topping up
62	Checking the accumulator air pressure

Fig

Page

1	Slewing arc	2
2	Crane operators switchboard and speed control.....	2
3	Crane stowage.....	4
4	Crane controls	5
5	Crane signals.....	6
6	Crane	7
7	Crew compartment, right side.....	9
8	Crane oil filter and cock	10
9	Crane oil filter.....	11
10	Crane pump.....	12


CRANE AND HYDRAULIC LOCKOUT SYSTEM

Crane

1 The crane comprises a reservoir, king post, inner boom, outer boom, and an extension for the outer boom by which lighter loads may be lifted at an extended radius. The hydraulic power is provided by a gear type pump, which is driven by a power take-off on the transverse gearbox.


2 The king post (Fig 6(2)) slews through 190 deg on a vertical pivot incorporated in the fabricated reservoir. Single acting rams actuate the crane booms. Heavy lifts are connected to the hook (13) attached to the outer end of the outer boom (7). The extension (11) is retained in the outer boom by a pin (10) held by a spring clip. The extension carries a hook and chain. Rotating the chain wheel to release the chain and pulling the chain to the required position can adjust the operative length of the chain. Returning the wheel to its former position locks the chain. The loading of the hook jams the chain in position.

3 The controls are mounted on the roof plate at the front of the crane and are operated while standing in the operator hatch. The maximum movement of each lever at the knob is approximately 38 mm (1 1/2in.) in either direction. The function of each lever is indicated in Fig 4. (Type 2)



434/048

Fig 1 Slewing arc



430/20167

- | | | | |
|---|-----------------------|---|-----------------------------------|
| 1 | Auxiliary switchboard | 4 | Quadrant |
| 2 | Wingnut | 5 | Linkage to governor control lever |
| 3 | Handle | 6 | Bulkhead |

Fig 2 Crane operators switchboard and speed control

Hydraulic lockout system

4 The shock absorber units are lockable by hydraulic pressure supplied from the crane system. The locking of the units stabilizes the vehicle when lifting loads and relieves the torsion bars of the extra strain.

5 The lockout system includes a pressure gauge (Fig 4(5)), a relief valve set to open at 103.5 bar (1,500-lb sq in.), the control valve and hydro-pneumatic accumulator.

Preparing the crane for hoisting

6 Site the vehicle close to the load to be hoisted ensuring that load/radius limitations are not exceeded and the manoeuvre is within the slewing arc (Fig 1) and turn the cupola to a position where the periscope guard will not foul the crane hoses.

7 Ensure that the brakes are fully applied and the gear range selector lever is in the neutral position.

8 Stop the engine, engage the crane pump drive, and erect the operators platform.

9 Restart the engine at the crane operators engine switchboard (Fig 2(1)) and adjust the engine speed by means of the operators control lever (3) to run at a speed of 1,000 to 1,200 rev/min.

NOTE

The engine when started at one switchboard cannot be stopped at the other.

10 Operate the hydraulic lockout lever (Fig 4(4)) until the gauge (5) indicates a pressure of 1,500-lb/sq in. then return the lever to the central position.

11 Lower the catwalk platform.

12 Unfasten the clamp (Fig 3(7)) securing inner boom to the locker frame, and raise the inner boom until the end is above any vehicle mounted components and the outer boom ram link (Fig 6(14)) will clear the clamp bracket.

13 Release the locking catch (Fig 6(4)) securing the outer boom to the inner boom and manually raise the outer boom to the vertical position, then lower it onto the rear support bracket (Fig 3(6)).


14 Extend the outer boom ram until the outer boom is raised clear of the rear support bracket. Release the strap (4) securing the main hook (5).

15 If the extension is to be used, manoeuvre the crane to bring the outer boom to a convenient position, withdraw the locking pin (Fig 6(10)), and insert the extension (11) securing it by re-inserting the locking pin in the required holes.

Crane standby position

16 When manoeuvring the vehicle between hoisting operations the booms may be lowered to a supported position from which the crane can be made readily operable.

17 The outer boom (Fig 3(2)) rests on the rear support bracket (6) where it is secured by clamp (3), and the inner boom is supported by a strut (8), which engages a pin attached to the end face of the inner boom and a captive drop-plate pin secures the strut in position.




434/050

1	Inner boom	5	Hook
2	Outer boom	6	Rear support bracket
3	Clamp	7	Clamp
4	Strap	8	Strut

Fig 3 Crane stowage

Operating the crane

18 Operator's should familiarize themselves with the controls, and the use of hand and voice signals (Fig 5). Controls should be moved smoothly, any tendency to snatch at the levers must be avoided, and such treatment produces shock loads and renders impossible precise control of the crane. To alter the boom radius the smooth co-ordination of both ram controls is required. When the vehicle is standing on a gradient, a slewing action of 180 deg can alter the effective radius and so exceed the maximum load/radius conditions. The lockout struts must be unlocked before re-siting the vehicle, and re-locked when resuming lifting operations.



















434/014

- | | | | |
|---|-----------------|---|---------------------------------|
| 1 | Slewing lever | 5 | Lockout pressure gauge |
| 2 | Outer ram lever | 6 | Operators door padlock hasp ↗ |
| 3 | Inner ram lever | 7 | Operators door locking handle ↘ |
| 4 | Lockout lever | 8 | Light sockets |


Fig 4 Crane controls (New pattern)

TYPE 2

<p>ACTION</p> <p>RAISE HOOK</p> <p>CLENCH AND UNCLENCH FINGERS TO SIGNAL TAKE THE STRAIN</p> 	<p>VOICE</p> <p>"HOOK UP!"</p>	<p>ACTION</p> <p>LOWER HOOK</p> 	<p>VOICE</p> <p>"HOOK DOWN!"</p>
<p>ACTION</p> <p>RAISE JIB</p> 	<p>VOICE</p> <p>"JIB UP!"</p>	<p>ACTION</p> <p>LOWER JIB</p> 	<p>VOICE</p> <p>"JIB DOWN!"</p>
<p>ACTION</p> <p>SLEW LEFT</p> 	<p>VOICE</p> <p>"SLEW LEFT!"</p>	<p>ACTION</p> <p>SLEW RIGHT</p> 	<p>VOICE</p> <p>"SLEW RIGHT!"</p>
<p>ACTION</p> <p>TURN VEHICLE TO THE LEFT</p> 	<p>VOICE</p> <p>"LEFT HAND DOWN!"</p>	<p>ACTION</p> <p>TURN VEHICLE TO THE RIGHT</p> 	<p>VOICE</p> <p>"RIGHT HAND DOWN!"</p>
<p>ACTION</p> <p>MOVE VEHICLE FORWARD</p> 	<p>VOICE</p> <p>"COME FORWARD!"</p>	<p>ACTION</p> <p>MOVE VEHICLE BACKWARD</p> 	<p>VOICE</p> <p>"REVERSE!"</p>
<p>ACTION</p> <p>TROLLEY TO ME</p> 	<p>VOICE</p> <p>"COME FORWARD!"</p>	<p>ACTION</p> <p>TROLLEY FROM ME</p> 	<p>VOICE</p> <p>"REVERSE!"</p>
<p>ACTION</p> <p>EXTEND THE JIB</p> 	<p>VOICE</p> <p>"EXTEND!"</p>	<p>ACTION</p> <p>RETRACT THE JIB</p> 	<p>VOICE</p> <p>"RETRACT!"</p>
<p>ACTION</p> <p>MANOEUVRE IN PROGRESS STOPS</p> <p>CLENCH AND UNCLENCH FINGERS TO SIGNAL TAKE THE STRAIN</p> 	<p>VOICE</p> <p>"CHECK!"</p>	<p>ACTION</p> <p>EMERGENCY STOP</p> <p>ALL MOVEMENT STOPS IMMEDIATELY</p> 	<p>VOICE</p> <p>"STOP!"</p>

TC5478/181

Fig 5 Crane signals



434/052

- | | | | |
|---|--------------------|----|-----------------------|
| 1 | Crane control unit | 9 | Handle |
| 2 | King post | 10 | Extension locking pin |
| 3 | Inner boom pivot | 11 | Extension |
| 4 | Locking catch | 12 | Chain locking lug |
| 5 | Inner boom | 13 | Hook |
| 6 | Outer boom pivot | 14 | Outer ram pivot link |
| 7 | Outer boom | 15 | Outer boom ram |
| 8 | locking lug | 16 | Inner boom ram |

Fig 6 Crane

Stowing the crane

- 19 Remove and stow the extension. Strap the main hook to the boom lifting handle (Fig 6(9)).
- 20 Raise the inner boom to its maximum and lower the outer boom to fully retract the ram link (14).
- 21 Slew the crane, to position it over the stowing locating, and then lower the inner boom with a crewmember guiding the outer boom onto the rear support bracket.
- 22 Continue lowering the inner boom until the end of the boom is just above the strut bracket.
- 23 Raise the outer boom to fold back onto the inner boom. Engage the locking catch.
- 24 Fully lower the inner boom to rest on the locker frame and fasten the clamp.
- 25 Raise the catwalk platform.
- 26 Operate the hydraulic lockout control to release the lockout pressure. When the pressure gauge registers zero, return the control to the central position.

- 27 Return the operators engine speed control lever to the idling position.
- 28 Stop the engine and disengage the crane pump drive.

SERVICING

Checking and topping up the reservoir oil


- 29 Stand the vehicle on level ground with the crane in the stowed position.
- 30 Unscrew the filler cap (Fig 7(7)) and withdraw the attached dipstick.
- 31 Wipe the dipstick clean, re-insert it, then withdraw it again and note the level indicated.
- 32 If the level is below the full mark, add clean oil until the level is correct.
- 33 Replace the filler cap and screw it down securely.
- 34 Ensure that both rams are fully extended.

Changing the oil

- 35 Stand the vehicle on level ground with the crane in the stowed position.
- 36 Remove the drain plug (8) from the drainpipe under the tank and allow the oil to drain into a suitable container.
- 37 Service the oil filter (Para 54 and 55).
- 38 Replace the tank drain plug and refill with clean oil.
- 39 Run the pump for five minutes to remove any air from the system.
- 40 Operate the crane over the full range of movements at least five times to remove the air trapped in the system.
- 41 Recheck the oil level and top up to the correct level, if required.

Changing the oil filter element

- 42 Close the cock (Fig 8(7)), unless the tank is drained, and remove the drain plug (5) from the bottom of the filter. Allow the oil to drain into a suitable container.
- 43 Unscrew the wing nut (3) at the top of the filter and lower the bowl (4). If there is any difficulty in freeing the bowl, a light tap on the lower part of the bowl will free the joint.
- 44 Lift out the element assembly and the supporting spring (Fig 9(13)).
- 45 Dismantle the element assembly by removing the knurled nut (9) and pulling off the end caps (15), (18) and pads.
- 46 Slide the element out of the perforated case (17) and discard.
- 47 Clean the components in gasoline and dry thoroughly.
- 48 Clean the filter head and check the joint ring (19) for serviceability.




430/20166

- | | | | |
|---|-----------------------------|----|---------------------------------|
| 1 | Fan speed control | 6 | Auxiliary junction box |
| 2 | Head rest | 7 | Reservoir filler cap |
| 3 | Roof light | 8 | Backrest |
| 4 | Crane operators switchboard | 9 | Slewing rack lubricating nipple |
| 5 | Reservoir vent | 10 | King post lubricating nipple |

Fig 7 Crew compartment, right side


- 49 Slide the perforated case over the replacement element, replace the pads, end caps, and fibre washer (8), and tighten the knurled nut.
- 50 Replace the drain plug (11) and washer (10) in bowl.
- 51 Replace the supporting spring and slide the element assembly over the bowl centre bolt (7). Fill the bowl with oil.
- 52 Thread the centre bolt through the head and secure the filter body with the washer (2) and wing nut (1).
- 53 Open the cock.



434/053

- | | | | |
|---|----------------------------|---|------------------------------------|
| 1 | Hydraulic tank filler tube | 5 | Drain plug |
| 2 | Lockout breather tube | 6 | Crane engine speed control linkage |
| 3 | Bowl retaining wingnut | 7 | Cock |
| 4 | Filter bowl | | |

Fig 8 Crane oil filter and cock



434/054

- | | | | |
|----|--------------|----|---------------------------|
| 1 | Wingnut | 11 | Drain plug |
| 2 | Washer | 12 | Drain holes |
| 3 | Joint washer | 13 | Spring |
| 4 | Pad | 14 | Element |
| 5 | Bowl | 15 | Bottom cap |
| 6 | Centre tube | 16 | Element clip |
| 7 | Centre bolt | 17 | Perforated case |
| 8 | Washer | 18 | Top cap |
| 9 | Knurled nut | 19 | Filter head jointing ring |
| 10 | Washer | | |

Fig 9 Crane oil filter

Crane lubrication

54 Two nipples are provided, one for the lubrication of the slewing rack (Fig 7(9)), the other in the king post (10) for lubricating the king post pivot.

55 Oil can lubrication should be carried out on the moving parts of the controls, hook, outer boom extension and stowage clamps. Lubricate sparingly.

Crane pump drive housing


56 The housing (Fig 10(5)) containing the engagement gear for the hydraulic pump (3) driving the crane, forms and oil reservoir for pump lubrication.

Checking the oil level and topping up

- 57 Remove the knob and locknut from the engagement lever (2).
- 58 Unbolt and remove the pump access cover. Care should be taken no to damage the rubber gaiter
- 59 Remove the plug (4) and, if necessary, top up to bring the oil level to the bottom of the plughole.
- 60 Inspect the plug and washer for serviceability, then replace.
- 61 Replace the cover, locknut, and knob.

Checking the accumulator air pressure

- 62 Remove cap.
- 63 Apply pressure gauge to valve. If pressure is less than 69 Bar (1,000 lb sq in.), report.
- 64 Replace cap.



434/055

- | | |
|---|---------------------------|
| 1 | Power pack rear partition |
| 2 | Engagement lever |
| 3 | Hydraulic pump |

- | | |
|---|-------------------------------|
| 4 | Filler/level plug |
| 5 | Drive engagement gear housing |

Fig 10 Crane pump

CHAPTER 4
DESTRUCTION OF EQUIPMENT
CONTENTS

Para

- 1 Mandatory directive
- 3 Degree of damage
- 5 Spare parts
- 6 Means and procedures
- 8 Mechanical
- 9 Burning (WARNING)
- 10 Gunfire (WARNING)
- 11 Priorities

Table

Page

1	Priorities for destruction	3/4
---	----------------------------------	-----

MANDATORY DIRECTIVE

- 1 Destruction of the equipment, when subject to capture by the enemy, must be undertaken by the user arm **ONLY WHEN**, in the judgement of the unit commander concerned, such action is necessary in accordance with orders of, or policy established by, the Army or Divisional Commanders.
- 2 The reporting of the destruction of equipment is to be carried out through command channels.

Degree of damage

3 The degree of damage inflicted to prevent the equipment being used by the enemy, shall be as follows:

3.1 [REDACTED]

3.2 [REDACTED]

3.3 [REDACTED]

4 [REDACTED]

Spare parts

5 [REDACTED]

REDACTED.

Priorities

REDACTED

COMMENT(S) ON AESP*

To: DCCS
BFPO 794

From:
.....
.....
.....

Sender's Reference	BIN Number	Date
AESP* Title:		
Chapter(s)/Instruction	Page(s)/Paragraph(s)	
If you require more space please use the reverse of this form or a separate piece of paper. Comment(s):		

Signed: Telephone No.:
Name (Capitals): Rank/Grade: Date:
X

FOR AESP* SPONSOR USE ONLY

To: From:
.....
.....
.....

Thank you for commenting on AESP*:

Your reference: Dated:

Action is being taken to:	Tick		Tick
Issue a revised/amended AESP*		Under investigation	
Incorporate comment(s) in future amendments		No action required	
Remarks			

Signed: Telephone No.:
Name (Capitals): Rank/Grade: Date:
AESP* or EMER

~~UNRESTRICTED~~

~~UNRESTRICTED~~